

NOTE:

CONTROL VALVE OPT. "LOW-BUOY" , "A" OR "B" SETTING:

POSITION "A": VALVE IS OPEN,
AR FLOW BETWEEN SUPPLY (S) AND
DELIVERY (D), LOW-BUOY IS NOT IN FUNCTION.

POSITION "B": VALVE CLOSED,
AIR DOES'NT FLOW BETWEEN SUPPLY (S) AND
DELIVERY (D), LOW-BUOY IS IN FUNCTION.

FRONT REAR SUB-FRAME XL2-45 COACH

TUBE COLOR CODING			
ACTIVE	COLOR	CIRCUIT	
$\rightarrow \rightarrow \rightarrow$	RED	SECONDARY	
$\rightarrow \rightarrow \rightarrow$	GREEN	PRIMARY & SUPPLY	
$\rightarrow \rightarrow \rightarrow$	YELLOW	PARKING BRAKE	
$\rightarrow \rightarrow \rightarrow$	BLUE	SUSPENSION	
$\rightarrow \rightarrow \rightarrow$	BLACK	ACCESSORIES	

BALLOON	PIPE
*1	¾" O.D. BLUE
•2	½" O.D. BLUE
#3	¾" O.D. BLACK
#4	1/4" O.D. BLACK
	STD PIPING
***************************************	OPTIONAL PIPING

XL2-45 COACH, ENGINE 2002 WITH I.F.S.

WITH OPTION FRONT KNEELING, LOW-BUOY & HIGH-BUOY COMBINATION

D140300 P4 REV.A

DATE: 2003/02