



NOTE :

CONTROL VALVE OPT. "LOW-BUOY", "A" OR "B" SETTING:

POSITION "A": VALVE OPEN .
AIR FLOW BETWEEN SUPPLY (S) AND DELIVERY (D), LOW-BUOY IS NOT IN FONCTION.

POSITION "B": VALVE CLOSED .
AIR DOES NOT FLOW BETWEEN SUPPLY (S) AND DELIVERY (D), LOW-BUOY IS IN FONCTION.

ITEM	DESCRIPTION
500	3/8" O.D. BLUE
501	1/2" O.D. BLUE
516	3/4" O.D. BLACK
503	1/4" O.D. BLACK

COACH XL2
WITH INDEPENDENT SUSPENSION (I.S.S.)
WITH FRONT KNEELING , LOW-BUOY
AND HIGH-BUOY COMBINATION

D140256 P.5 REV.B