

110-120 VOLTS CONNECTOR ..... 16

**A**

ABBREVIATIONS ..... 175

ADJUSTABLE HVAC REGISTERS ..... 20

AIR SYSTEM ..... 169

AISLE MIRROR ..... 20

ALIGNMENT SPECIFICATIONS ..... 170

ALLISON AUTOMATIC TRANSMISSION ..... 81, 168

    DESCRIPTION OF AVAILABLE RANGES ..... 82

    MODE ..... 81

    OPERATION ..... 81

    PUSHBUTTON SHIFT SELECTOR ..... 81

    TRANSMISSION SERVICE INDICATOR ..... 82

ALLISON TRANSMISSION WARM-UP ..... 127

ANTILOCK BRAKING SYSTEM (ABS) 109, 169

    TROUBLESHOOTING AND TESTING ..... 169

APPENDIX A – SERVICE LITERATURE 177

    NOTICE ..... 179

    SERVICE LITERATURE ..... 178

APPENDIX B – TROUBLESHOOTING GUIDE FOR MULTIPLEX VEHICLES ..... 181

APPENDIX C – ALLISON DIAGNOSTIC TROUBLESHOOTING CODES ..... 187

    CONTROL SYSTEM PROGNOSTICS ..... 196

    DIAGNOSTIC TROUBLESHOOTING CODES (DTC) - ALLISON 4<sup>TH</sup> GENERATION CONTROLS ..... 188

APPENDIX D – SPHEROS PREHEATER FLASH CODES ..... 199

APPENDIX E – TPMS TROUBLESHOOTING GUIDE ..... 201

AUTOMATIC FIRE DETECTION AND SUPPRESSION SYSTEM (AFSS) ..... 37

AUTOMATIC TRACTION CONTROL (ATC) – ELECTRONIC STABILITY PROGRAM (ESP) ..... 109, 169

**B**

BACK-UP ALARM ..... 142

BACK-UP CAMERA AND MONITOR ..... 37

BACK-UP CAMERA ..... 16, 142

BAGGAGE COMPARTMENTS ..... 12

BELTS ..... 168

BRAKES ..... 169

    BRAKE CHAMBER EFFECTIVE AREA ..... 169

**C**

CAPACITIES ..... 167

CARE AND MAINTENANCE ..... 143

CATALYTIC CONVERTER ACCESS DOOR... 9

CLEANING ..... 145

    CARPET ..... 146

    EXTERIOR SURFACES ..... 146

    FLOOR CLEANING ..... 146

    FORMICA ..... 146

    PLASTIC AND VINYL ..... 146

    RUBBER COMPONENTS ..... 146

    SEAT UPHOLSTERY ..... 145

    STAINLESS STEEL ..... 146

    WINDOWS ..... 146

    WINDSHIELD ..... 147

COACH EXTERIOR ..... 5

COACH FINAL RECORD ..... 174

COACH INTERIOR ..... 19

COMPARTMENT LIGHTING ..... 142

CONDENSER COMPARTMENT (A/C) ..... 10

CONTROLS AND INSTRUMENTS ... 29

COOLANT HEATER COMPARTMENT ..... 11

COOLING SYSTEM ..... 171

CRUISE CONTROL ..... 38

    PREVOST AWARE – ADAPTIVE CRUISE BRAKING ..... 39

    REGULAR CRUISE CONTROL ..... 38

**D**

DASHBOARD ..... 48

    AIR VENTS ..... 59

    AUDIO-VIDEO SELECTOR FOR THE PASSENGER'S AREA ..... 56

    CONTROL SWITCHES ..... 49

DASHBOARD RADIO/MP3/POD/CD PLAYER .58

HVAC CONTROL UNIT.....54

L.H. DASHBOARD PANEL .....49

R.H. DASHBOARD PANEL.....52

DAYTIME RUNNING LIGHTS .....141

DEFENSIVE DRIVING PRACTICES .....2

DIAGNOSTIC DATA READER (DDR)  
RECEPTACLE .....37

DIAGNOSTIC TROUBLESHOOTING CODES  
(DTC) - ALLISON 4<sup>TH</sup> GENERATION  
CONTROLS .....188

    ALLISON TRANSMISSION DIAGNOSTIC  
    TROUBLESHOOTING CODES (DTC) AND  
    DESCRIPTIONS.....191

    ALLISON TRANSMISSION OIL LEVEL CHECK  
    USING THE PUSH-BUTTON SHIFT SELECTOR  
    .....195

    DIAGNOSTIC CODE DISPLAY AND CLEARING  
    PROCEDURE - ALLISON 4<sup>TH</sup> GENERATION  
    CONTROLS .....189

    DIAGNOSTIC CODE RESPONSE .....190

    DIAGNOSTIC CODES – ALLISON 4<sup>TH</sup>  
    GENERATION CONTROLS.....188

    DIAGNOSTIC TROUBLESHOOTING CODES  
    (DTC) OVERVIEW .....188

    EXITING FLUID LEVEL DISPLAY MODE.....195

DIMENSIONS AND WEIGHTS .....167

DRIVER CONTROLLED  
DIFFERENTIAL LOCK (DCDL).....109

    LOCKING THE DCDL .....110

    OPERATION TIPS .....109

    UNLOCKING THE DCDL .....110

DRIVER'S SEAT – ISRI .....21

    MECHANICAL ISRI SEAT.....21

    PNEUMATIC ISRI SEAT .....22

    SAFETY BELTS .....23

DRIVER INFORMATION DISPLAY (DID)  
MENUS .....98

DRIVING MODE MENU.....98

    FUEL DATA.....100

    GAUGES .....98

    RESET TRIP DATA.....101

    TIME/DISTANCE.....100

    VEHICLE MESSAGES .....101

**E**

ELECTRICAL SYSTEM.....170

ELECTRONIC DESTINATION SIGN.....20

ELECTRONIC STABILITY PROGRAM (ESP)  
.....109

EMERGENCY AIR-FILL VALVES .....140

EMERGENCY AND PARKING BRAKES .....141

EMERGENCY EQUIPMENT .....131

    FIRE EXTINGUISHERS .....136, 153

    FIRE HATCHET .....136

    FIRST AID KIT .....136

    JACK AND TOOLS.....137

    LIMP-HOME BELT .....137

    SPARE PARTS KIT.....137

    SUPPRESSION SYSTEM (AFSS) .....131

    TIRE PRESSURE MONITORING SYSTEM  
    (TPMS).....132

    WARNING REFLECTORS .....137

EMERGENCY EXITS .....130

    EMERGENCY ENTRANCE DOOR OPENING131

    ROOF HATCH.....130

    SIDE WINDOWS.....130

EMERGENCY/PARKING BRAKES OVERRULE  
CONTROL VALVE.....37

ENGINE .....168

    VOLVO D13 ENGINE .....168

ENGINE BLOCK HEATER .....127

ENGINE BRAKE .....107

    ENGINE BRAKE – AUTO MODE (WITH I-SHIFT  
    TRANSMISSION ONLY) .....108

    EXHAUST BRAKE .....108

    VOLVO ENGINE BRAKE (VEB).....108

ENGINE COMPARTMENT COMPONENTS....7

ENGINE COMPARTMENT .....8

    ENGINE COMPARTMENT CURB-SIDE DOOR 8

    ENGINE COMPARTMENT REAR DOORS.....8

ENGINE COOLANT HEATER .....111

    COOLANT HEATER TIMER .....112

    SWITCHING THE HEATER OFF .....112

    SWITCHING THE HEATER ON.....112

TROUBLESHOOTING AND MAINTENANCE .114  
 ENGINE RADIATOR DOOR.....9  
 ENGINE WARM-UP .....127  
 ENTRANCE DOOR.....14  
     DOOR OPERATION LOGIC .....14  
     EMERGENCY ENTRANCE DOOR OPENING .15  
 ESSENTIAL FUNCTIONS TO OPERATE THE VEHICLE (BASIC LIMP-HOME FUNCTIONS) .....142  
     AVAILABLE FUNCTIONS .....142  
 EVAPORATOR COMPARTMENT.....10  
 EXHAUST AFTERTREATMENT SYSTEM ....91  
     DEF QUALITY – DRIVER WARNING AND INDUCEMENT .....96  
     DEF TANK LEVEL – DRIVER WARNING AND INDUCEMENT .....95  
     FILTRATION AND REGENERATION UNIT .....91  
     SCR SYSTEM TAMPERING – DRIVER WARNING AND INDUCEMENT .....97  
     SELECTIVE CATALYTIC REDUCTION UNIT ..93  
 EXHAUST AFTERTREATMENT SYSTEM ACCESS DOOR.....9  
 EXHAUST SYSTEM .....171

**F**

FIRST SERVICE ON NEW VEHICLE.....158  
     COOLANT SYSTEM STRAINER .....158  
     ENGINE OIL.....158  
 FLUID LEVEL VERIFICATION .....148  
     COOLANT FLUID LEVEL.....151  
     COOLING FAN RIGHT ANGLE GEARBOX OIL LEVEL .....151  
     DRIVE AXLE WHEEL BEARING OIL LEVEL..151  
     ENGINE OIL LEVEL.....148  
     FRONT AND TAG AXLE WHEEL HUBS .....151  
     POWER STEERING FLUID LEVEL .....150  
     TRANSMISSION OIL LEVEL .....149  
     WINDSHIELD WASHER & HEADLIGHTS WASHER RESERVOIR.....152  
 FOG LIGHTS .....142  
 FOOT-OPERATED CONTROLS .....80  
     ACCELERATOR PEDAL.....81

BRAKE PEDAL .....80  
 FRONT ELECTRICAL AND SERVICE COMPARTMENT.....11  
 FUEL AND DIESEL EXHAUST FLUID (DEF) FILLER DOOR.....13  
 FUEL SYSTEM.....171  
 FUEL TYPE .....167  
     BIODIESEL FUELS .....167

**G**

GALLEY .....28  
 GENERAL RECOMMENDATIONS .....159

**H**

HEATING AND AIR CONDITIONING.....171  
 HI-BUOY .....110  
 HUBODOMETER.....16

**I**

IGNITION SWITCH.....31  
 IN-STATION LIGHTING .....111  
 INSTRUMENT CLUSTER .....60  
     ANALOG INDICATORS .....61  
     DRIVER INFORMATION DISPLAY .....68  
     TELLTALE LIGHTS.....64  
 I-SHIFT TRANSMISSION (VOLVO).....84  
     ACCELERATOR PEDAL.....85  
     DISPLAY .....84  
     DRIVING .....87  
     ECONOMY AND PERFORMANCE MODE.....85  
     ECO-ROLL MODE (FREEWHEEL FUNCTION)85  
     LIMP HOME MODE.....85  
     PUSHBUTTON SHIFT SELECTOR .....84  
     STARTING AND STOPPING.....86  
     STARTING THE VEHICLE UPHILL AND DOWNHILL.....86  
     TOWING .....88  
 I-SHIFT TRANSMISSION – STARTING THE VEHICLE AT LOW TEMPERATURES.127

**J**

JACKING POINTS ..... 138  
 HYDRAULIC JACK..... 139

**K**

KEYS.....31  
 ENTRANCE DOOR AND EXTERIOR  
 COMPARTMENT DOORS KEY .....31  
 FUEL FILLER DOOR KEY .....31  
 HAND TOWEL DISPENSER KEY.....31  
 LAVATORY DOOR KEY .....31  
 UTILITY AND VIDEO COMPARTMENT KEY ...31  
 UTILITY COMPARTMENTS KEY.....31  
 KNEELING SYSTEM ..... 110

**L**

LATERAL CONTROL PANEL.....34  
 12-VOLT APPLIANCES SOCKET .....37  
 ASHTRAY .....37  
 CIGARETTE LIGHTER .....36  
 CONTROL SWITCHES .....35  
 COOLANT HEATER TIMER .....36, 112  
 LOW BUOY CONTROL VALVE .....36  
 MIRROR CONTROLS .....36  
 PARKING BRAKES CONTROL VALVE.....36  
 TAG AXLE CONTROL VALVE .....36  
 TRAILER AIR SUPPLY CONTROL VALVE .....37  
 TRANSMISSION CONTROL PAD .....35  
 UTILITY COMPARTMENT .....37  
 LAVATORY MAINTENANCE..... 147  
 CLEANING CABINET.....148  
 DRAINING THE SUMP TANK.....148  
 FILLING THE SUMP TANK.....148  
 FRESH WATER RESERVOIR .....147  
 LAVATORY .....28  
 LOW-BUOY..... 111

**M**

MICROPHONE JACKS.....24  
 MUD FLAPS AND SPLASH GUARDS ..... 142

**N**

NON-DRIVING / STATIONARY MODE MENUS  
 ..... 101  
 AFTERTREATMENT .....106  
 DATA LOG .....105  
 DIAGNOSTICS.....103  
 DISPLAY SETTINGS .....101  
 PASSWORDS .....107  
 PRE-TRIP ASSISTANT .....104

**O**

OIL SPECIFICATIONS ..... 172  
 ALLISON TRANSMISSION .....172  
 DIFFERENTIAL .....172  
 ENGINE.....172  
 FAN RIGHT ANGLE GEARBOX .....172  
 I-SHIFT TRANSMISSION.....172  
 POWER STEERING RESERVOIR.....172

**OTHER FEATURES..... 89**

**OTHER PRECAUTIONS ..... 3**

**OTHER VERIFICATIONS..... 152**

A/C AND HEATING SYSTEM AIR FILTERS...155  
 A/C COMPRESSOR BELT TENSION  
 ADJUSTMENT .....154  
 AIR FILTER RESTRICTION INDICATOR .....154  
 AIR TANK PURGE .....152  
 BACK-UP CAMERA .....154  
 EXTERIOR LIGHTING VERIFICATION .....157  
 FAN AND ALTERNATOR DRIVE BELTS.....154  
 FIRE EXTINGUISHERS .....153  
 HOSE INSPECTION .....156  
 LUBRICATION .....156  
 PARKING BRAKE TEST .....157  
 PRIMARY FUEL FILTER.....153  
 SERVICE BRAKE TEST .....157  
 WHEELS AND TIRES .....156  
 WHEEL BEARINGS .....157

**OVERHEAD COMPARTMENTS ..... 27**

**OVERHEAD CONSOLE ..... 25**

ADJUSTABLE AIR REGISTERS.....26

READING LIGHTS .....	26	TRANSMISSION RETARDER .....	80
SERVICE BELL .....	26	STEERING WHEEL ADJUSTMENT .....	20
<b>P</b>		STEERING.....	170
PASSENGER SEATS .....	24	SUSPENSION .....	170
CARD TABLES .....	25	DRIVE AXLE .....	170
FOLDING TRAYS.....	24	I-BEAM AXLE FRONT SUSPENSION .....	170
QUICK-LOUNGE SYSTEM .....	25	INDEPENDENT FRONT SUSPENSION .....	170
SWIVEL SEATS .....	24	TAG AXLE .....	170
PLATES AND CERTIFICATION .....	173	<b>T</b>	
DOT CERTIFICATION PLATE .....	174	TECHNICAL INFORMATION.....	163
SAFETY CERTIFICATION .....	174	TIRE PRESSURE MONITORING SYSTEM (TPMS).....	39
PRE-HEATING SYSTEM.....	172	TOUR GUIDE SEAT .....	24
PROPELLER SHAFT.....	169	TOWING .....	140
<b>R</b>		TRAILER HITCH.....	16
REAR VIEW MIRRORS .....	15	TRANSMISSION RETARDER.....	80, 107
RETRACTABLE TAG AXLE .....	111	<b>U</b>	
<b>S</b>		UNLOADING TAG AXLE .....	111
SAFE OPERATING PRACTICES .....	2	UTILITY COMPARTMENTS.....	20
SAFETY FEATURES AND EQUIPMENT .....	129	<b>V</b>	
SAFETY PRECAUTIONS .....	1	VEHICLE IDENTIFICATION NUMBER (VIN).....	174
SCENIC VIEWING SYSTEM CAMERA.....	37	VENTILATION HATCH .....	27
SPARE WHEEL AND TIRE .....	137	VOLVO I-SHIFT TRANSMISSION .....	84
CHANGING A WHEEL .....	137	<b>W</b>	
SPARE WHEEL COMPARTMENT .....	13	WALK-AROUND INSPECTION (BEFORE EVERY TRIP) .....	161
STARTING AND STOPPING PROCEDURES .....	123	WASTE CONTAINER.....	28
STARTING THE ENGINE .....	124	WHEELCHAIR LIFT ACCESS DOORS .....	15
COLD WEATHER STARTING .....	125	WHEELCHAIR LIFT SYSTEM.....	114
JUMP STARTING.....	125	EMERGENCY OPERATION .....	118
STARTING FROM THE DRIVER'S SEAT .....	124	INTERIOR APPOINTMENTS .....	117
STARTING FROM THE ENGINE COMPARTMENT .....	124	OPERATING THE WHEELCHAIR LIFT .....	115
STEERING COLUMN CONTROLS .....	77	THRESHOLD WARNING SYSTEM (TWS) ADJUSTMENT .....	116
HORNS .....	79	WHEELCHAIR LIFT AND ACCESS DOORS..	114
MULTI-FUNCTION LEVER .....	77	WHEELCHAIR LIFT INSTALLATION.....	121
STEERING WHEEL CONTROLS.....	78	WHEELCHAIR LIFT REMOVAL FOR STORING	

OR MAINTENANCE PURPOSES .....	120
WHEELS AND TIRES.....	168
RECOMMENDED TIRE INFLATION PRESSURE AT MAXIMUM COLD LOAD .....	168
WINDOWS .....	26
DRIVER'S POWER WINDOW.....	27
PANORAMIC WINDOWS .....	26