Instruction Sheet

IS-99113

WATERTIGHTNESS SEAL ON CLEARANCE AND IDENTIFICATION LIGHT ASSEMBLY

MATERIAL

Kit #430538 includes the following parts:

Part No.	Description	Qty
930344	Gasket, self-adhesive	14
IS-99113	Instruction Sheet	1
FI-99113	Feuille d'instructions	1

DESCRIPTION

Every time a clearance or identification light is removed, a new gasket (#930344) must be installed. When the vehicle is delivered from the factory, temporary gaskets (#430438) are installed. These must be replaced by permanent, self-adhesive gaskets (#930344) once the vehicle is painted.

A kit #430538 is included in the vehicle spare parts.

PROCEDURE

Warning: Park vehicle safely, apply parking brake, stop engine and set battery master switch(es) to the OFF position prior to working on the vehicle.

- 1. Clean the back side of the clearance or identification light with isopropyl alcohol, make sure the surface is clean and smooth;
- 2. Peel off the backing strip from the gasket;
- 3. Apply the sticky side to the back of the light;
- 4. Plug the connector;
- 5. Install the light using the existing screws and torque to 13 lbf•in (1.5 N•m).

Note: Remove the gasket and clean contact surface thoroughly every time such a light is replaced.

Note: Be careful to replace the amber-colored lights in front and red-colored lights in back of vehicle.

