
# Dana® Spicer®



## IPL-0171

## **ILLUSTRATED PART LIST**



Dana Holding Corporation

Technical Publications CVPE © 2008 Dana Limited
Commercial Vehicle Products – Europe

for more information www.dana.com

The description, testing procedures, and specifications contained in this parts / service publication were current at time of writing. This manual will not be updated. If in doubt about any aspect of maintenance or servicing of the axle please contact the vehicle builder or our service department directly.

**SPICER**® products are subject to continuos development and we reserve the right to modify procedures and to make changes in specifications at any time without prior notice and without incurring in any obligation.

The recommendations of the vehicle manufacturer should be considered as the primary source of service information regarding this **SPICER**® product. This manual is intended to be used as a supplement to such information.

Any references to brand names in this publication are made simply as an example of the types of tools and materials recommended for use and, as such, should not be considered as an endorsement.


This manual is the property of **Commercial Vehicle Products – Europe**, a division of **Dana Holding Corporation**, and may not be copied or disseminated without prior agreement of **Commercial Vehicle Products – Europe**, a division of **Dana Holding Corporation**.

**Commercial Vehicle Products – Europe**, a division of **Dana Holding Corporation**, recommends following all manufacturers recommendations for the proper handling and disposal of lubricants and solvents. For further information please contact the lubricants and solvents supplier.

EVERY EFFORT HAS BEEN MADE TO ENSURE THE ACCURACY OF THE INFORMATION CONTAINED WITHIN THIS MANUAL.

HOWEVER, COMMERCIAL VEHICLE PRODUCTS – EUROPE, A DIVISION OF DANA HOLDING CORPORATION, MAKES NO EXPRESSED OR IMPLIED WARRANTY OR REPRESENTATION BASED ON THE ENCLOSED INFORMATION.

Last Modification	Date	Approved by	Date	Issue	Eng. Change
A.U.	01/09/11	A.U.E.	01/09/11	Α	NC11536



### NDIFS80P K26857 - K26879 - K26891 Part List & Tightening Torques

	Part Number			<b>5</b>		
Item	K26857	K26879	K26891	Description	Qty <sup>0</sup>	
1		F5064/55	'	Flanged bolt	28	
2	F4974/28			Wheel hub	2	
3	F4974/88			Brake Disc	2	
4	F4567/77 F5169/77		F5169/77	Hub Bearing – Nut	2	
5	F4567/30 F51		F5170/30	Hub Bearing – Collet w asher	2	
6A	SL279/3 SL2		SL279/4	Hub Bearing – Unitized	2	
6B	F508	4/100	-	Hub Bearing – ABS Ring		
7A	SM486/52K	SM486	6/58K	Air Disc Brake (ADB) assy - LH	1	
7B	SM486/521K	SM486	6/57K	Air Disc Brake (ADB) assy - RH	1	
8		833175		Brake fixing – Bolt	12	
9		1001414		Grease nipple (90°) <sup>2</sup>	4	
10	971370			Kingpin – Cap <sup>2</sup>		
11	971010			Kingpin – Foam insert <sup>2</sup>		
12	806334			Kingpin – Bushing <sup>2, 3</sup>	4	
13	820518			Kingpin – Seal <sup>2</sup>	4	
14	F5084/14			Kingpin <sup>2</sup>		
15A	F4974/8 F5170/8		F5170/8	Bottom steering lever – LH	1	
15B	F4974/7		F5170/7	Bottom steering lever – RH	1	
16	ML602	0/100X	833257	Bottom steering lever – Bolt	2	
17	ML6020/65X 833258		833258	Bottom steering lever – Bolt	2	
18A	817493			Kingpin – Adjusting shim (0.13mm) <sup>2</sup>		
18B	817494			Kingpin – Adjusting shim (0.25mm) <sup>2</sup>	AR1	
19A	F5084/1 F		F5170/1	Pivot arm - LH	1	
19B	F5084/1A F51		F5170/1A	Pivot arm - RH	1	
20A	F504	3/208	F5170/208	Steering lever 5TH link - LH	1	
20B	F504	F5043/207 F5170/207		Steering lever 5TH link - RH	1	
21		ML6020/60X		Steering lever 5TH link - Bolt		
22		ML6020/80X		Steering lever 5TH link - Bolt		
23	160HP104-1			Draw key <sup>2</sup>	4	
24	1460HN100			Draw key – Washer <sup>2</sup>	8	
25	220HN103			Draw key - Nut 2	4	
26	220HC104			Thrust bearing <sup>2</sup>	2	
27A	A 807781			Stop Bolt – Back Lock	2	
27B	816370			Stop Bolt – Front Lock	2	
28	SL224/8			Stop Bolt – Nut	4	
29	F50	4/2 F5170/2 Knuckle <sup>3</sup>		2		

#### NOTES:

Quantities listed are for complete axle unit

<sup>1</sup> As Required -

<sup>2</sup> Available as a Service Kit: 12280/5 & 12280/6

<sup>3</sup> Available as a Sub-Assembly: SF5084/2A (K26857 & K26879); SF5170/2 (K26891)

### ADDITIONAL INFORMATION (AI):

 AI1
 Service Manual NDS
 613513

 AI2
 Lubrication Manual
 613511

 AI3
 Service Manual Disc Brake SN6.../SN7.../SK7.../NA7...
 613512

Item	Part Number	Description	Туре	Torque (N·m)	Torque (ft·lbs)
1	F5064/55	Flanged bolt	M14 x 1,5	236 - 260	174 - 192
4	F4567/77	Hub Bearing – Nut	1 x 3/4" - 8 UN	780 - 849	575 - 626
4	F5169/77	Hub Bearing – Nut	M42 x 2	700 - 770	516 - 568
8	833175	Brake fixing – Bolt	M20 x 1,5	475 - 533	350 - 393
10	971370	Kingpin – Cap	2,375 - 16 UN	88 - 108	65 - 80
16	ML6020/100X	Bottom steering lever – Bolt	M20 x 2,5	705 - 780	520 - 575
	833257	Bottom steering lever – Bolt	M22 x 1,5	870 - 960	642 - 708
17	ML6020/65X	Bottom steering lever – Bolt	M20 x 2,5	705 - 780	520 - 575
	833258	Bottom steering lever – Bolt	M22 x 1,5	870 - 960	642 - 708
21	ML6020/60X	Steering lever 5TH link - Bolt	M20 x 2,5	705 - 780	520 - 575
22	ML6020/80X	Steering lever 5TH link - Bolt	M20 x 2,5	705 - 780	520 - 575
25	220HN103	Draw key - Nut	,375 - 16 UNC	33 - 49	24 - 36
28	SL224/8	Stop Bolt – Nut	5/8" - 18 UNF	122 - 163	90 - 120

