

CIRCUITS LIST

CircuitID	Description	CircuitID	Description	CircuitID	Description
0	PowerBatteries	0TR.White	Trailerinterface	A2A.11	
0	PowerBatteries	00VA	EqualizerGnd	A3.1	Transmission
0A	12VOutlets	0W	GNDStud	A3.2	Transmission
00A	Keylessentriysystem	12Ecu	12vEngineEcu	A3.3	Transmission
0A1		12ISH	Pwrl_Shift	A3.5	Transmission
00A1	Multiplexpower	12VA	Maindistributionpower	A3.6	Transmission
00A2	eMirrors_VS	12VD	PowerBatteries	A3.7	Transmission
0AltEXTR	ChassisGnd	12VI8A	PwrtoModuleA50	A4B.8	Transmission
0AltL	ChassisGnd	24VA	Maindistributionpower	A5.B	Transmission
0AltR	ChassisGnd	24VD	PowerBatteries	A9CX1.2	Cluster
0AltUL	ChassisGnd	24VD2	Ignitionandenginestart	A9CX1.4	ESP
0B	EngineChassisGnd	24VD3	Maindistributionpower	A9CX1.5	ESP
0C	Ignitionandenginestart	24VI	24VltoRearVec	A9CX1.6	Cluster
0COND	FullHVACpassengers	26	DriverWindoPw	A9CX2.1	ESP
0ECU	EngineECUVolvo	76	24VIPreHeater	A9CX2.2	ESP
0EVAP1		136A	TransmissionPwr	A9CX2.3	ESP
0F	ChassisGnd	146A	PwrtoModuleA50	A9CX2.4	ESP
00F	GNDElectronic	290A	GndFanClutch	A9CX2.6	ESP
00F1	Multiplexpower	900	J1587network	A9CX2.7	ESP
00F2	Multiplexpower	901	J1587network	A9CX2.9	ESP
00F3		_00	PowerBatteries	A9CX2.10	ESP
00F4	FJB	A1.11	Transmission	A9CX2.12	ESP
00F5	Groundelec	A1.12	Transmission	A9CX2.13	ESP
0FDS	Driver_Seat	A1.15	Transmission	A9CX2.16	ESP
0FE		A1.16	Transmission	A9CX2.17	ESP
0FF		A1.18	Transmission	A9CX3.3	ESP
0FH	Keylessentriysystem	A1.19	Transmission	A9CX3.5	ESP
00FH	Keylessentriysystem	A1.24	Transmission	A9CX3.7	ESP
0FH1		A1.25	Transmission	A9CX3.9	ESP
00FH1	HVACdefroster	A1.31	Transmission	A9CX3.10	ESP
00FH2	Multiplexpower	A1.33	Transmission	A9CX4.1	ESP
00FR	GNDElectronic	A1.36	Transmission	A9CX4.4	ESP
0R	PowerdistributionRJB	A1.37	Transmission	A9CX4.7	ESP
00R	CanIsoJ2284network	A1.51	Transmission	A9CX4.8	ESP
00R1	Masterrelay	A1.52	Transmission	A9CX4.10	ESP
00R2	Multiplexpower	A1.54	Transmission	A9CX4.11	ESP
00R3	Multiplexpower	A1.55	Transmission	A14.A12	Cluster
00R4	Multiplexpower	A1.58	Transmission	A14.B1	Cluster
00R5	VannerCtr	A1.71	Transmission	A14.B18	Cluster
00R6	Multiplexpower	A1.74	Transmission	A14.B20	Cluster
0RAD	EngineChassisGnd	A1.76	Transmission	A14.B21	Cluster
0RAD2	Fansdriveelectric	A1.77	Transmission	A27.30	Powersteering
0TR	Trailerinterface	A2A.9		A27.87A	Powersteering

CIRCUITS LIST

CircuitID	Description	CircuitID	Description	CircuitID	Description
A31J4.1	Keylessentrysystem	A41J2.15	Keylessentrysystem	A45J1.13	Curbblights
A31J4.2	Keylessentrysystem	A41RJ1.6	Keylessentrysystem	A45J1.18	Emergency&aislelights
A31J4.3	Keylessentrysystem	A41RJ1.18	Keylessentrysystem	A45J2.1	HVACdefroster
A31J4.4	Keylessentrysystem	A41RJ2.14	FJB	A45J2.4	HVACdefroster
A31J4.5	Keylessentrysystem	A42J1.3	FJB	A45J2.7	Driver&entracewindow
A31J4.6	Keylessentrysystem	A42J1.4	FJB	A45J2.13	Driver&entracewindow
A31J4.7	Keylessentrysystem	A42J1.7	FJB	A45RJ1.17	Fog,cornering,dockinglights
A31J4.8	Keylessentrysystem	A42J1.10	Kneeling,tag,lowbuoy	A45RJ1.18	
A31J5.1	Keylessentrysystem	A42J1.13	Kneeling,tag,lowbuoy	A46J1.1	Horn
A31J5.3	Keylessentrysystem	A42J1.16	FJB	A46J1.4	Frflash,markers,clearance&headlights
A34.A5	Fansdriveelectric	A42J1.18	FJB	A46J1.7	Cornering&foglights
A34.B5	Fansdriveelectric	A42J2.15	FJB	A46J1.10	Frflash,markers,clearance&headlights
A34.C5	Fansdriveelectric	A43J1.1	Lugg.doorslocks	A46J1.13	Frflash,markers,clearance&headlights
A34.D5	Fansdriveelectric	A43J1.3	Lugg.doorslocks	A46J1.20	Frflashers,markers,clearance,headlights
A34.E5	Fansdriveelectric	A43J1.7	TPMS	A46J2.1	Fog,cornering,dockinglights
A34.F5	Fansdriveelectric	A43J2.1	Lugg.doorslocks	A46J2.4	Frheadlights
A34.G5	Fansdriveelectric	A43J2.4	Lugg.doorslocks	A46J2.7	Frheadlights
A34.H5	Fansdriveelectric	A43J2.13	Keylessentrysystem	A46RJ1.17	Frflash,markers,clearance&headlights
A34J.E	Fansdriveelectric	A43RJ1.17	ACB	A46RJ1.18	Frflash,markers,clearance&headlights
A34J.F	Fansdriveelectric	A44J1.3		A47J1.1	HVACdefroster
A34R.A3	Fansdriveelectric	A44J1.4	12VPowerdistributionFJB	A47J1.3	HVACdefroster
A34R.B3	Fansdriveelectric	A44J1.7	Wipersandwasher	A47J1.4	HVACdefroster
A34R.C3	Fansdriveelectric	A44J1.10	Wipersandwasher	A47J1.7	Wipersandwasher
A34R.D3	Fansdriveelectric	A44J1.16	Horn	A47J1.16	SmallA/C
A34R.E3	Fansdriveelectric	A44J1.19	Luggageslights	A47J1.19	
A34R.F3	Fansdriveelectric	A44J1.7	EMirror	A47J2.1	HVACdefroster
A34R.G3	Fansdriveelectric	A44J2.1	Sunvisor	A47J2.4	HVACdefroster
A34R.H3	Fansdriveelectric	A44J2.4	Sunvisor	A47J2.7	
A36AJA.7		A44J2.7	Driverlight	A47J2.10	
A36AJA.8		A44J2.7.A	Driverlight	A47J2.13	
A36AJA.9		A44J2.10	Sunvisor	A47J2.15	SmallA/C
A36AJA.10		A44J2.13	Sunvisor	A47RJ1.6	HVACdefroster
A36JA.15	Ignitionandenginestart	A44J2:3		A47RJ1.17	HVACdefroster
A36JA.17	EmergencyCutoutRlySignal	A44RJ1.17	Frflash,markers,clearance&headlights	A47RJ1.18	Wipersandwasher
A36JB.2	Ignition	A44RJ2.2	Driverlights	A47RJ2.2	Keylessentrysystem
A40.3	Trailerinterface	A44RJ2.3		A47RJ2.3	SmallA/C
A40.3.Blue	Trailerinterface	A45J1.1	HVACdefroster	A48J1.1	Fog,cornering,dockinglights
A41J1.1	Keylessentrysystem	A45J1.3	HVACdefroster	A48J1.3	Fog,cornering,dockinglights
A41J1.4	Keylessentrysystem	A45J1.4	Powersteering	A48J1.4	Cornering&foglights
A41J1.7	Keylessentrysystem	A45J1.7	12VPowerdistributionFJB	A48J1.7	Frflash,markers,clearance&headlights
A41J1.16	EngineECUVolvo	A45J1.16	Mirrors	A48J1.10	Frflash,markers,clearance&headlights
A41J1.19	EngineECUVolvo	A45J1.18	Emergency&aislelights	A48J2.1	Frheadlights
A41J2.2	Keylessentrysystem	A45J1:10	Curbblights	A48J2.4	Frheadlights

CIRCUITS LIST

CircuitID	Description	CircuitID	Description	CircuitID	Description
A48J2.5	Frflashers,markers,clearance,headlights	A51J2.7	Rrflashers,markers,Tail&stoplights	A56J1.10	Cluster
A48J2.7	Driver&entracewindow	A51J2.10	Rrflashers,markers,Tail&stoplights	A56J1.13	Multiplexpower
A48J2.10	Driver&entracewindow	A51RJ1.17	Rrflashers,markers,Tail&stoplights	A56J1.16	EngineECUVolvo
A48J2.13	Frflash,markers,clearance&headlights	A51RJ1.18	Fog,cornering,dockinglights	A56J1.19	eMirrors_VS
A48RJ1.17	Fog,cornering,dockinglights	A52J1.1	Fansdriveelectric	A56J2.15	Frflash,markers,clearance&headlights
A48RJ1.18	Frflash,markers,clearance&headlights	A52J1.3	Fansdriveelectric	A57J1.1	WCL
A48RJ2.2	Frflash,markers,clearance&headlights	A52J1.7	EngineandRJBlights	A57J1.3	WCL
A49J1.1	Fansdriveelectric	A52J1.10	Ignitionandenginestart	A57J1.19	
A49J1.3	Fansdriveelectric	A52J1.13	RJBfan	A57RJ1.18	
A49J1.10	FullHVACpassengers	A52J2.1	Alternators	A58J1.1	Slideoutfrontleft
A49J1.17	SmallA/C	A52J2.4	Alternators	A58J1.4	Slideoutfrontleft
A49J1.18	SmallA/C	A52J2.13	Ignitionandenginestart	A58J1.7	Slideoutfrontleft
A49J2.1	Alternators	A52RJ1.17	RJB_Gnd	A58J1.10	Slideoutfrontleft
A49J2.4	SmallA/C	A52RJ1.18	EngineandRJBlights	A58J1.16	Slideoutfrontleft
A49J2.13	Brake,enginebrake&retarder	A53J1.10	Curbights	A58J1.19	Slideoutfrontleft
A49J2.15	SmallA/C	A53RJ1.18		A58J2.1	Slideoutfrontleft
A49RJ1.6	SmallA/C	A54J1.1	FullHVACpassengers	A58J2.4	Slideoutfrontleft
A49RJ1.18	FullHVACpassengers	A54J1.3	FullHVACpassengers	A58J2.11	Slideoutfrontleft
A49RJ2.2	Fansdriveelectric	A54J1.7	FullHVACpassengers	A58J2.15	Slideoutfrontleft
A49RJ2.3	SmallA/C	A54J1.10	FullHVACpassengers	A58RJ1.17	Slideoutfrontleft
A50J1.4	Airdryerandheater	A54J1.16	SmallA/C	A58RJ2.2	Slideoutfrontleft
A50J1.7	Backupwarnings	A54J1.19	FullHVACpassengers	A58RJ2.14	Slideoutfrontleft
A50J1.10	SmallA/C	A54J2.4	FullHVACpassengers	A59J1.1	Slideoutrearleft
A50J1.13	Rrflashers,markers,Tail&stoplights	A54J2.7	HVACPassengers	A59J1.4	Slideoutrearleft
A50J1.18	SmallA/C	A54J2.10	FullHVACpassengers	A59J1.7	Slideoutrearleft
A50J1.19	Rrflashers,markers,Tail&stoplights	A54J2.15	FullHVACpassengers	A59J1.10	Slideoutrearleft
A50J2.1	Rrflashers,markers,Tail&stoplights	A54RJ1.6	FullHVACpassengers	A59J1.16	Slideoutrearleft
A50J2.7	Rrflashers,markers,Tail&stoplights	A54RJ1.17	FullHVACpassengers	A59J1.19	Slideoutrearleft
A50J2.10	Backupwarnings	A54RJ1.18	FullHVACpassengers	A59J2.15	Slideoutrearleft
A50RJ1.17	Rrflashers,markers,Tail&stoplights	A54RJ2.2	FullHVACpassengers	A59RJ1.17	Slideoutrearleft
A50RJ1.18	Rrflashers,markers,Tail&stoplights	A54RJ2.3	FullHVACpassengers	A59RJ2.2	Slideoutrearleft
A50RJ2.2	Backupwarnings	A54RJ2.14	FullHVACpassengers	A59RJ2.14	Slideoutrearleft
A50RJ2.3	Airdryerandheater	A55J1.1	Driverlights	A77.A	Equalizer
A51J1.1	Fog,cornering,dockinglights	A55J1.4	Cluster	A77.H	Equalizer
A51J1.3	Fog,cornering,dockinglights	A55J1.7	Reverse_Signal	A78.3	Equalizer
A51J1.4	Rrflashers,markers,Tail&stoplights	A55J1.13		A78.4	Equalizer
A51J1.7	Rrflashers,markers,Tail&stoplights	A55J2.1	DriverLights	A79.3	Equalizer
A51J1.10	Rrflashers,markers,Tail&stoplights	A55J2.15	Keylessentrysystm	A80.3	Equalizer
A51J1.13	Rrflashers,markers,Tail&stoplights	A55RJ1.6		A80.4	Equalizer
A51J1.16	Transmission	A56J1.1	EngineECUVolvo	A81CN3A.3	EngineECUVolvo
A51J1.19	WCL	A56J1.3	Cluster	A81CN3A.4	Ignitionandenginestart
A51J2.1	Rrflashers,markers,Tail&stoplights	A56J1.4	Cluster	A81CN3A.5	EngineECUVolvo
A51J2.4	Transmission	A56J1.7	Cluster	A81CN3A.9	EngineECUVolvo

CIRCUITS LIST

CircuitID	Description	CircuitID	Description	CircuitID	Description
A81CN3B.26	EngineECUVolvo	AltUR	Maindistributionpower	CB206	Fansdriveelectric
A81CN3B.27		ANT_A_CANH		CB207	Fansdriveelectric
A81CN3B.28	EngineECUVolvo	ANT_A_CANL		CB208	Fansdriveelectric
A81CN3B.35	EngineECUVolvo	ANT_A_GND		CB301	Trailerinterface
A81CN3B.36		ANT_A_PWR		CB301.Black	Trailerinterface
A81JB.6	Powersteering	ANT_B_CANH		CC16	FJB
A81JB.15	Ignitionandenginestart	ANT_B_CANL		CC17	FJB
A103.1	Steeringmultifunctions	ANT_B_GND		Clnt1	FJB
A103.3	Steeringmultifunctions	ANT_B_PWR		Clnt2	FJB
A103.4	Steeringmultifunctions	ANT_C_CANH		Clnt3	FJB
A103.5	Horn	ANT_C_CANL		Clnt4	FJB
A108.5	Cmd_Ground	ANT_C_GND		Clnt5	FJB
A130.3		ANT_C_PWR		Clnt6	FJB
A130.4	Firesuppression	B85.2	UreaSystem	Clnt7	FJB
A130.6		B97.2	UreaSystem	Clnt8	FJB
A130.8	Firesuppression	B98.2	UreaSystem	D1	Ignitionandenginestart
A130.11		B99.2		D3.2	Trailerinterface
A131A.C	Firesuppression	B115A.3	DeltaPSignals	D6	
A131B.A	Firesuppression	BLU		D12	Horn
A131B.C	Firesuppression	BRN/RHFlasher		D13	Horn
A137A.4	UreaSystem	BussBar	12VtoCB10	D51	Tagandlevellow
A137A.7	UreaSystem	CAN_Hi	eMirrors_VS	D75	Slideoutfrontleft
A137A.8	UreaSystem	CAN_Low	eMirrors_VS	D82.A	Driverlight
A137A.24	UreaSystem	CanH2	Spare	D88.A	Luggageslights
A137A.28	UreaSystem	CanL2	Spare	D89.A	Luggageslights
A137A.40	UreaSystem	CB1	Maindistributionpower	DATAKH	Keylessentrysystem
A137A.44	UreaSystem	CB2	Maindistributionpower	DATAKL	Keylessentrysystem
A137A.49	UreaSystem	CB3	Maindistributionpower	DCIN+	
A137A.50	UreaSystem	CB5	Maindistributionpower	DL0H	
A137A.51	UreaSystem	CB6	Maindistributionpower	DL0HA	
A137A.54	UreaSystem	CB7	Maindistributionpower	DL0HB	
A137A.56	UreaSystem	CB8	Maindistributionpower	DL0L	
A137A.59	UreaSystem	CB9	UreaSystem	DL0LA	
A137A.62	UreaSystem	CB10	Maindistributionpower	DL0LB	
A138.3	UreaSystem	CB48	Frfash,markers,clearance&headlights	DL1H	J1939network
A138.12	UreaSystem	CB117	Trailer	DL1L	J1939network
ACC		CB119	Trailerinteface	DL2H	
AE56J2.13	Driver&entracewindow	CB128	PowerdistributionRJB	DL2L	
Alt_LL	Alternators	CB201	Fansdriveelectric	DL3H	DBUSnetwork
Alt_UL	Alternators	CB202	Fansdriveelectric	DL3L	DBUSnetwork
Alt_UR	Alternators	CB203	Fansdriveelectric	DL7H	EngineECUVolvo
AltLL	Maindistributionpower	CB204	Fansdriveelectric	DL7L	EngineECUVolvo
AltUL	Alternators	CB205	Fansdriveelectric	DL11H	

CIRCUITS LIST

CircuitID	Description	CircuitID	Description	CircuitID	Description
DL11L		F55		L207.1	WCL
DL100H	J1939network	F57		L207.3	WCL
DL100L	J1939network	F58/F57	Driver_Seat	L207.GND	WCL
DSO1.1	Slideoutfrontleft	F73	EngineECUVolvo	L350A.B2	EngineECUVolvo
DSO2.1	Slideoutrearleft	F90	PowertoEcm	Mo11.3	SmallA/C
EI.7	Cluster	F91	EngineECUVolvo	Mo40.2	Windowsajar
EI.18	EngineECUVolvo	F95		Mo65.3	Fansdriveelectric
EMS.EB29	Ignitionandenginestart	F96		Mo67.3	Fansdriveelectric
F10	Cluster	F99	PowerdistributionRJB	Mo68.3	Fansdriveelectric
F11	Horn	F101	Maindistributionpower	Mo69.3	Fansdriveelectric
F12	Keylessentrsystem	F106	Multiplexpower	Mo70.3	Fansdriveelectric
F13	12VPowerdistributionFJB	F107	Multiplexpower	Mo71.3	Fansdriveelectric
F14	Multiplexpower	F108	CanIsoJ2284network	Mo72.3	Fansdriveelectric
F15	Keylessentrsystem	F109	EngineandRJBlights	Mo73.3	Fansdriveelectric
F16	12VPowerdistributionFJB	F110	Transmission	N1	Multiplexnetwork
F18	Multiplexpower	F117		N2	Multiplexnetwork
F19	Multiplexpower	F118	Trailer	N3	Multiplexnetwork
F20	Multiplexpower	F119		N4	Multiplexnetwork
F21	Multiplexpower	F121	PowerdistributionRJB	N5	Multiplexnetwork
F22		F122	24VltoMux	N6	Multiplexnetwork
F23	ESP	F126	FullHVACpassengers	N7	Multiplexnetwork
F24	12VPowerdistributionFJB	F130	Windowsajar	N8	Multiplexnetwork
F25	12VOutlets	F131	PowerdistributionRJB	N9	Multiplexnetwork
F27	Driverseat	F132	Multiplexpower	N10	Multiplexnetwork
F29	12VPowerdistributionFJB	F133	Multiplexpower	N11	Multiplexnetwork
F30	CanIsoJ2284network	F134	Multiplexpower	N12	Multiplexnetwork
F33		F135	Multiplexpower	N13	Multiplexnetwork
F35		F136	Multiplexpower	N14	Multiplexnetwork
F36	Ignitionandenginestart	F139	Alternators	N15	Multiplexnetwork
F37	Keylessentrsystem	F141	FullHVACpassengers	N16	Multiplexnetwork
F39	24VPowerdistributionFJB	F142	FullHVACpassengers	N17	Multiplexnetwork
F40	Firesuppression	F143	FullHVACpassengers	N18	Multiplexnetwork
F41	Multiplexpower	F144	FullHVACpassengers	N19	Multiplexnetwork
F42	Pwrl_Shift	F147	PowerdistributionRJB	N20	Multiplexnetwork
F43	Pwrl_Shift	F149	UreaSystem	N21	Multiplexnetwork
F44	Multiplexpower	F167	Luggage_Lights	N22	Multiplexnetwork
F45	Multiplexpower	F199	Fansdriveelectric	N23	Multiplexnetwork
F46	Multiplexpower	gnd_1	Cantrack	N24	Multiplexnetwork
F47		Gnd_2	Cantrack	N27	Multiplexnetwork
F50	HVACdefroster	GRN/SPEED		N28	Multiplexnetwork
F51	Multiplexpower	Jmp_Sw24.6	DriversLights	N30	Multiplexnetwork
F52		Jmp_Sw24.6.	DriversLights	N31	Multiplexnetwork
F53	Tagandlevellow	jumper	Lugg.doorslocks	N32	Multiplexnetwork

CIRCUITS LIST

CircuitID	Description	CircuitID	Description	CircuitID	Description
N33	Multiplexnetwork	R_Starter	Ignitionandenginestart	Se40.2	ESP
N56-1	Multiplexnetwork	RSO1_1	Slideoutfrontleft	Se45.2	Cluster
N56-2	Multiplexnetwork	RSO1_2	Slideoutfrontleft	Se46.B	Trailerparkbrake
N57_1	WCL	RSO2_1	Slideoutrearleft	Se49	FullHVACpassengers
N57_2	WCL	RSO2_2	Slideoutrearleft	Se51.2	Cluster
ORA/LHFlasher		Rx	Cantrack	Se51.Jmp	Seat_Belt_Jumper
Pot1		Se2		Se53.C	Cluster
Pot1	Multiplexpower	Se2A		Se54.C	Cluster
R6.30	Keylessentrysystm	Se11.Sig	Cluster	Se55.C	Cluster
R6A.30	Keylessentrysystm	Se11.Wrn	Cluster	Se56.A	
R12	FullHVACpassengers	Se13.B	EngineECUVolvo	Se57.C	
R21.87		Se14A.B	EngineECUVolvo	Se62.B	WCL
R21.B		Se14B.C	EngineECUVolvo	Se63.1	ESP
R22.87	Ignitionandenginestart	Se15.NO	Keylessentrysystm	Se63.2	ESP
R23.30		Se16	Keylessentrysystm	Se64.1	ESP
R23A.87	EngineECUVolvo	Se17.NC	Keylessentrysystm	Se64.2	ESP
R25.87	24VI	Se17.NO	Keylessentrysystm	Se67.C	ESP
R27.87A	Wipersandwasher	Se18.B		Se69.C	ESP
R29	EngineECUVolvo	Se19_P.D	Brake,enginebrake&retarder	Se89.A	
R30.87	12VPowerdistributionFJB	Se19_S.D		Se94	WCL
R31.87	12VPowerdistributionFJB	Se20.B	Cluster	Se94.A	WCL
R34.30	Ignitionandenginestart	Se21.2	HVACdefroster	Se100.4	WCL
R35.30		Se23	SmallA/C	SES02.4	Slideoutfrontleft
R36.87	Horn	Se23.C	FullHVACpassengers	SES03.2	Slideoutfrontleft
R37.30	Horn	Se23A	SmallA/C	SES05.4	Slideoutrearleft
R38.87	12VOutlets	Se24.2	FullHVACpassengers	SES06.2	Slideoutrearleft
R47.87	WCL	Se24.3	FullHVACpassengers	Shield_149	
R51.87	Trailerinterface	Se25.2	FullHVACpassengers	Shield_149A	
R51.87.Yellow	Trailerinterface	Se30.A	EngineandRJBlights	So9.B	FullHVACpassengers
R52.87	Trailerinteface	Se32.A	Transmission	So36	SmallA/C
R52.87.Green	Trailerinterface	Se32.B	Transmission	spare17	Spare
R53.30	Trailerinterface	Se33.A	Transmission	spare18	Spare
R53.30.Red	Trailerinterface	Se34.A	Transmission	spare19	Spare
R54.87		Se34.B	Transmission	spare20	Spare
R55.30	Trailerinterface	Se35.A	Transmission	spare21	Spare
R55.30.Brown	Trailerinterface	Se35.B	Transmission	spare22	Spare
R167.30	Luggageslights	Se37.1	ESP	spare23	Spare
R167.86		Se37.2	ESP	spare24	Spare
R622.85	Frflashers,markers,clearance,headlights	Se38.1	ESP	spare25	Spare
R622.87	eMirrors_VS	Se38.2	ESP	spare28	Spare
R623.85	Frflashers,markers,clearance,headlights	Se39.1	ESP	spare29	Spare
R623.87	eMirrors_VS	Se39.2	ESP	spare30	Spare
R624.87	Cust_Adapt_Interface	Se40.1	ESP	spare31	Spare

CIRCUITS LIST

CircuitID	Description	CircuitID	Description	CircuitID	Description
spare32	Spare	Sw24.3	DriverandEntrancelights	Sw103A.3	Backupwarnings
spare33	Spare	Sw24.4	Driverlights	Sw103A.6	Backupwarnings
spare34	Spare	Sw24.6	Driverlights	Sw104.1	Keylessentrysyste
spare35	Spare	Sw24.8	DriverLights	Sw104.3	Keylessentrysyste
spare39	Spare	Sw34.2B	Driver&entracewindow	Sw104.5B	Keylessentrysyste
spare40	Spare	SW34A.3	Driver&entracewindow	Sw107.2	Tagandlevellow
spare41	Spare	SW34A.4	Driver&entracewindow	Sw107.4	Tagandlevellow
spare42	Spare	Sw35.3	EngineECUVolvo	Sw107.6	Tagandlevellow
spare43	Spare	Sw35.8	EngineECUVolvo	Sw107.8	Tagandlevellow
spare44	Spare	Sw38.2B	Driver&entracewindow	Sw107.10	Tagandlevellow
spare64	Spare	Sw40.B	Trailerparkbrake	Sw108.1	Tagandlevellow
spare65	Spare	Sw41.A1	Mirrors	Sw108.3	Tagandlevellow
spare72	Spare	Sw41.A3	Mirrors	Sw109	Lugg.doorslocks
spare73	Spare	Sw41.B1	Mirrors	Sw110	Lugg.doorslocks
STO-LOCselenoid	WCL	Sw41.B2	Mirrors	Sw111	Lugg.doorslocks
Sw1.5	Frflash,markers,clearance&headlights	Sw41.B4	Mirrors	Sw112	Lugg.doorslocks
Sw1C258.2	Frflash,markers,clearance&headlights	Sw42.2	WCL	Sw113	Lugg.doorslocks
Sw1C258.3	Frflash,markers,clearance&headlights	Sw42.3	WCL	Sw114	Lugg.doorslocks
Sw1C258.4	Frflash,markers,clearance&headlights	Sw42.4	WCL	Sw115	Lugg.doorslocks
Sw1C258.6	Frflash,markers,clearance&headlights	Sw42.5	WCL	Sw116	Lugg.doorslocks
Sw1C258.7	Frflash,markers,clearance&headlights	Sw42.6	WCL	Sw117	Lugg.doorslocks
Sw1C258.8	Frflash,markers,clearance&headlights	Sw42.7	WCL	Sw122.1	HVACdefroster
Sw1C259.1	Frflash,markers,clearance&headlights	Sw44	Luggageslights	Sw122.3	HVACdefroster
Sw1C259.2	Frflash,markers,clearance&headlights	Sw46A	Engine&RJBcmpt.lights	Sw122.5B	
Sw1C259.4	Frflash,markers,clearance&headlights	Sw58.3	Ignitionandenginestart	Sw152.B	Firesuppression
Sw2.3	Frflash,markers,clearance&headlights	Sw58.5		SW156.6	
Sw2.6	Frflash,markers,clearance&headlights	Sw58.7	Ignitionandenginestart	Sw156.6	Mirrors
Sw3.3	Fog,cornering,dockinglights	Sw59.3	Ignitionandenginestart	Sw156.8	Mirrors
Sw3.8	Fog,cornering,dockinglights	Sw63A.3	Horn	Sw157.2B	Sunvisor
Sw4.3		Sw63A.4	Horn	Sw158.2B	Sunvisor
Sw4.8	Frflash,markers,clearance&headlights	Sw64	Tagandlevellow	Sw161.5B	
Sw6.4	Wipersandwasher	Sw82.5	Masterrelay	Sw165.1	DriverandEntrancelights
Sw14.3	EngineECUVolvo	Sw83.Acc		Sw165.3	DriverandEntrancelights
Sw14.8	EngineECUVolvo	Sw83.Ign		Sw165.4	Driverlights
Sw16.3	Brake,enginebrake&retarder	Sw83.St		Sw165.6	Driverlights
Sw16.8	Brake,enginebrake&retarder	Sw85.A1	Mirrors	Sw167.6	
Sw17.6	EngineECUVolvo	Sw85.A3	Mirrors	Sw221.3	eMirrors_VS
Sw18A.2B	Lugg.doorslocks	Sw85.B1	Mirrors	SwSo1.4	Slideoutfrontleft
Sw18A.4	Keylessentrysyste	Sw85.B2	Mirrors	SwSo1.5	Slideoutfrontleft
Sw18A.6	Keylessentrysyste	Sw85.B4	Mirrors	SwSo2.4	Slideoutrearleft
Sw20.3	WCL	Sw99.3	Fog,cornering,dockinglights	SwSo2.5	Slideoutrearleft
Sw20.8	WCL	Sw102.3	Fog,cornering,dockinglights	TWU.3	WCL
Sw24.1	DriverandEntrancelights	Sw102.8	Fog,cornering,dockinglights	Tx	Cantrack

CIRCUITS LIST

[illegible]