

MULTIPLEX INPUT LIST

Module.Pin#	Signal name	Hvac AC Clutch Solenoid	Page	Connected devices
A36.JA:11	I_AccKeySw	Accessories Key switch		
A36.JA:12	I_HazardSw	Hazard Switch		
A36.JA:14	I_FireSensorA36	Fire Sensor On A36		
AE.	I_A41_NormalMode			
AE.	I_A43_NormalMode			
AE.	I_A44_NormalMode			
AE.	I_A55_NormalMode			
AE.	I_A56NormalMode			
AE41.J1:17	I_ParkBrSe	Paking Brake Sensor	12.1	
AE41.J1:21	I_BrakePedSec		12.1	
AE41.J1:5	I_StartEna2		3.2	
AE41.J2:11	I_FrSrvCptOpenSe			
AE41.J2:2	I_EntDorOpSe	Entrance Door Open Sensor	29.1	
AE41.J2:3	I_EntDorLockSw	VIP Entrance Door Lock Switch	29.1	
AE41.J2:4	I_LuggDrOpenSe	Luggages doors open sensor	25.1	
AE41.J2:5	I_KeylessPanic	Keyless panic button signal	29.1	
AE41.J2:6	I_KeylessIntru	Keyless intrusion signal	29.1	
AE41.J2:7	I_KeylessLuggUnl	Keyless luggages doors unlock signal	29.1	
AE41.J2:8	I_KeylessLockAll	Keyless lock all doors signal	29.1	
AE41.J2:9	I_KeylessDrUnl	Keyless door unlock signal	29.1	
AE42.J1:20	I_TgAxlSw	Tag Axle Switch	32.1	
AE42.J2:11	I_LevelLowSw	Level low switch	32.1	
AE43.J1:20	I_LuggDoorSw	Luggage Door Switch	33.1	
AE43.J2:5	I_KlessDrULatch			
AE43.J2:6	I_LuggDrLkSe		33.2	
AE44.J1:20	I_IgnKeySw	Ignition Key switch	3.2	
AE44.J1:21	I_FrEngStaSw	Front Engine Start Switch	3.2	
AE44.J2:5	I_SunVisorDrv	sun visor drv sw	41.1	
AE44.J2:6	I_SunVisorPass	sun visor pass sw	41.1	
AE44.J2:8	I_FireExt2ndAlm		38.1	
AE44.J2:9	I_FireExt1stAl		38.1	
AE46.J1:20	I_LHFishSw	Left Hand Flasher Switch	26.1	
AE46.J1:24	I_BatMonMod46			
AE47.J1:20	I_LowWiperCam	Low wiper Cam	34.1	
AE47.J1:21	I_DefrostHighSw	Passenger defrost speed increase switch	18.1	Sw122:3
AE47.J1:24	I_BatMonMod47			
AE47.J2:11	I_DrvTempSe	Driver Temperature sensor	18.1	
AE47.J2:6	I_DefrostLowSw	Passenger defrost speed decrease switch	18.1	Sw122:1
AE47.J2:9	I_SAcSuperHeatSe		18.3	
AE48.J1:24	I_BatMonMod48			
AE48.J2:5	I_RHFishSw	Right Hand Flasher Switch	26.1	
AE49.J1:20	I_AltSeUL		1.1	
AE49.J1:24	I_BatMonMod49			

MULTIPLEX INPUT LIST

Module.Pin#	Signal name	Hvac AC Clutch Solenoid	Page	Connected devices
AE49.J2:8	I_WdoOpenSe	Passenger Window Open Sensor	27.1	
AE49.J2:9	I_RJBLtSw	Rear Junction Light Switch		
AE50.J1:20	I_RetdrSig	Retarder Signal	15.1	A1:24
AE50.J1:24	I_BatMonMod50			
AE51.J1:20	I_LHFfshSwRrSig	LH FlasherSwitch Rear Signal	26.2	
AE51.J1:21	I_BrakePedPri		12.1	
AE51.J1:24	I_BatMonMod51			
AE51.J2:5	I_RHFfshSwRrSig	RH FlasherSwitch Rear Signal	26.2	
AE52.J1:20	I_StartEna1		3.2	
AE52.J1:24	I_BatMonMod52			
AE52.J2:5	I_EngStaRrSw	Engine Start Rear Switch	3.2	
AE52.J2:6	I_EngDoorSe	Engine Door Sensor	25.1	
AE52.J2:8	I_AltSeLL		1.1	
AE52.J2:9	I_AltSeUR		1.1	
AE54.J1:20	I_AcDorOpSe	Condensor Door Open Switch		
AE54.J1:24	I_BatMonMod54			
AE54.J2:11	I_SuperHeatSe		18.2	Se24:3
AE54.J2:8	I_AcPresHiSSe	Ac Pressure High Side Sensor	18.2	
AE54.J2:9	I_AcPresLoSSe	Ac Pressure Low Side Sensor	18.2	Se24:2
AE55.J1:21	I_DimmerSw	Dash BackLighting	19.1	Sw161:5B
AE55.J2:1	I_DrvLtSw	Driver Light Switch	19.1	D83.A:1
AE55.J2:10	I_LwWipIntSw	Lower Wiper Intermitant Switch	34.1	Sw1.C258:7
AE55.J2:11	I_LwWshSw	Lower Wiper Washer Switch	34.1	Sw1.C258:6
AE55.J2:4	I_RevAlrmSw	Reverse alarm switch	26.3	
AE55.J2:6	I_RetarderSel	Retarder Selected	12.1	Sw16:3
AE55.J2:7	I_WclSw	Wheel Chair Lift Dash Switch	36.1	Sw20:3
AE55.J2:8	I_BackUpCamSw	Back up camera switch		
AE56.J1:17	I_HdLtPos1Sw	Head Light Switch Position Markers	26.1	
AE56.J1:2	I_HeadLmpWshSw		34.1	Sw6:4
AE56.J1:20	I_HiBeamCallSw	Hi/Low Beam Switch	26.1	Sw1.C259:4
AE56.J1:21	I_HdLtHiLowBmSw	Head Lights High and Low Beam Switch	26.1	Sw1.C258:8
AE56.J1:5	I_HdLtPos2Sw		26.1	Sw2:6
AE56.J2:10	I_DockingLtSw	Docking Lights Switch	26.5	Sw99:3
AE56.J2:12	I_LowDockLtsSw	Low docking lights switch	26.5	Sw102:3
AE56.J2:13	I_EntDorWdo		30.1	Sw34:2B
AE56.J2:3	I_LHFfshSwLHom		26.1	
AE56.J2:4	I_RHFfshSwLHom		26.1	
AE56.J2:5	I_FogLightSw	Fog Lights Switch	26.5	Sw3:3
AE56.J2:6	I_CorneringLtSw	Cornering Light Switch	26.5	Sw99:1
AE56.J2:7	I_HornSw	Horn Switch	9.1	
AE56.J2:9	I_WdowDrvSw		30.1	
AE57.J1:17	I_WCLLoDorSe	Wheel Chair Lift Lower Door Sensor	36.1	Sw46A.A:1
AE57.J1:2	I_WCLDoorLtch	WCL Door firts latch detection door open	36.1	

MULTIPLEX INPUT LIST

[illegible]