



**POWER DISTRIBUTION**

LOCATED IN CENTRAL DASH

LOCATED ON THE TOP OF THE DRIVER POST

LOCATED ON THE VIDEO/AUDIO PANEL

TERMINAL BLOCKS

MONITORS

ADDITIONAL 24 V. OPTION

ADDITIONAL 12 V. OPTION