

## RELAYS

| No  | Location   | Part no | Function               | Page |
|-----|------------|---------|------------------------|------|
| R1  | RJB        | 562364  | MasterRelay            | 3.1  |
| R2  | RJB        | 563332  | Transmission ZF        | 15.2 |
| R3  | RJB        | 563348  | 12vIgn&AccRelay        | 3.1  |
| R4  | FJB        | 563332  | Pre-heater cut-off     | 38.1 |
| R5  | RJB        | 563332  | ChargerRelay           | 17.1 |
| R6  | FuseBoxRJB | 563332  | DirectLightsRelay      | 24.1 |
| R8  | FuseBoxRJB | 563269  | ServiceBrakeRelay      | 12.1 |
| R9  | Evap.Cmpt. | 563348  | CondensorRelay2stSpeed | 18.2 |
| R10 | Evap.Cmpt. | 563348  | CondensorRelay1stSpeed | 18.2 |
| R11 | RJB VECR   | 563332  | ZFIgn                  | 5.1  |
| R12 | Evap.Cmpt. | 563348  | EvaporatorRelay        | 18.2 |
| R13 | FuseBoxRJB | 563332  | Ind.LightRelay         | 23.1 |
| R14 | RJB        | 561991  | ReadingLampRelay       | 22.1 |
| R15 | FuseBoxRJB | 563332  | EmergencyLamps         | 20.1 |
| R16 | DashBoard  | 563332  | AudibleFlasherRelay    | 26.1 |
| R17 | RJB        | 561991  | 12vRrWUpRelay          | 3.3  |
| R18 | FJB        | 561991  | 24vFrWUpRelay          | 3.3  |
| R19 | FJB        | 561991  | 12vFrWUpRelay          | 3.3  |
| R20 | Evap.Cmpt. | 563332  | WaterPumpRelay         | 17.1 |
| R21 | RJB        | 563269  | EmergencyCutoutRelay   | 3.2  |
| R22 | FuseBoxFJB | 563269  | EngineBrakeRelay       | 12.1 |
| R23 | RHConsole  | 563332  | LowerWiperRelay        | 34.1 |
| R24 | FJB        | 563332  | UpperWiperRelay        | 34.1 |
| R25 | RJBVECR    | 563332  | Ecmlgn                 | 5.1  |
| R26 | Evap.Cmpt. | 563332  | Pre-HeatRelay          | 18.2 |