


Ground Distribution



Rev:12

Page:2.1

No:D061030

WIRING DIAGRAM

PREVOST®