

# MULTIPLEX ERROR MESSAGES LIST

FMI 3 = Shorted High ; FMI 4 = Shorted Low ; FMI 5 = Open Circuit ; FMI 6 = Current above Normal

Cluster message	SID/PSID	FMI	Module.Pin#	Page	Cluster message	SID/PSID	FMI	Module.Pin#	Page
A/C Clutch SO9	PSID #4	3, 4, 5, 6	A52.J1:20	18,2	Flash RH SW1	PSID #133	3, 4	A48.J1:12	26,1
A/C Pres HiSd SE23	PSID #28	3, 4	A52.J1:13	18,2	Flasher LH Sw1	PSID #130	3, 4	A45.J1:9	26,1
A/C Pres LoSd SE24	PSID #29	3, 4	A52.J1:14	18,2	Flsh Audibl Rly R16	PSID #37	3, 4, 5, 6	A45.J1:8	26,1
Aux AC fan Mo51	SID #39	3, 4, 6	A46.J1:1	18,3	Fog's Lights LH L95	PSID #134	3, 4, 6	A45.J1:4	26,3
Aux Refr sol So38	SID #46	3, 4, 6	A46.J1:8	18,3	Fog's lights RH L96	PSID #136	3, 4, 6	A48.J1:8	26,3
Backup Light & Alm	PSID #167	3, 4, 6	A50.J1:20	26,3	Foot trap Mo4	PSID #14	3, 4, 6	A45.J1:2	18,1
Blinker SW1	PSID #139	3, 4	A43.J1:20	26,1	FR Clearance lights	PSID #137	3, 4, 6	A44.J1:8	26,1
Brk Lts Sens SE19	PSID #119	3, 4	A36.JB:13	12,1	Fr Flsh-Mkr LH L62	PSID #128	3, 4, 6	A45.J1:3	26,1
Center Flash LH L70	PSID #124	3, 4, 6	A50.J1:5	26,2	Fr Side Flsh RH L64	PSID #10	3, 4, 6	A48.J1:20	26,1
Center Flash RH L68	PSID #125	3, 4, 6	A50.J1:7	26,2	Fr Start SW83	PSID #58	3, 4	A36.JB:22	3,2
Center Mkr L67-L70	PSID #27	3, 4, 6	A50.J1:8	26,2	Front Flash RH L61	PSID #126	3, 4, 6	A48.J1:6	26,1
Cond Rly spd1 R10	PSID #41	3, 4, 5, 6	A54.J1:5	18,2	FrontMkr Lts LH L62	PSID #148	3, 4, 6	A45.J1:21	26,1
Cond Rly spd2 R9	PSID #42	3, 4, 5, 6	A54.J1:1	18,2	FrontMkr Lts RH L61	PSID #149	3, 4, 6	A48.J1:7	26,1
Condensor Door Sw7	PSID #7	3, 4	A49.J1:3	25,1	FrStart Enable SW58	PSID #56	3, 4	A53.J1:9	3,2
Cornering Dash Sw30	PSID #200	3, 4	A55.J1:7	26,3	Hazard Switch Sw4	PSID #138	3, 4	A36.JB:4	26,1
Cyclope Lt L81	PSID #116	3, 4, 6	A51.J1:7	26,2	Hd Light Call SW1	PSID #140	3, 4	A43.J1:3	26,1
Defr water Pmp Mo50	SID #41	3, 4	A47.J1:20	18,3	HdLamp Wsh Pmp Mo54	SID #48	3, 4, 6	A46.J1:21	34,1
Diff Lock sol So35	SID #36	3, 4, 6	A52.J1:4	37,1	Head Lights Pos1SW2	PSID #143	3, 4	A43.J1:4	26,1
Docking Dash Sw31	PSID #3	3, 4	A55.J1:8	26,3	Head Lt Sw Pos2 Sw2	PSID #11	3, 4	A45.J1:12	26,1
Driver Def Fan L198	PSID #180	3, 4, 5, 6	A47.J1:1	18,1	Hi Low Beam Sw1	PSID #6	3, 4	A43.J1:8	26,1
Driver heat Sol SO8	PSID #16	3, 4, 5, 6	A46.J1:6	18,1	High Beam LH L60	PSID #141	3, 4, 5, 6	A45.J1:6	26,1
Driver Light L16	PSID #104	3, 4, 5, 6	A47.J1:6	19,1	High Beam RH L59	PSID #145	3, 4, 5, 6	A48.J1:3	26,1
Driver Light SW24	PSID #105	3, 4	A41.J1:2	19,1	LH Corner Lts L97	PSID #120	3, 4, 5, 6	A45.J1:5	26,3
Driver Rfg Sol SO7	PSID #13	3, 4, 5, 6	A46.J1:5	18,1	LH Docking LightL93	PSID #122	3, 4, 5, 6	A51.J1:4	26,3
Driver Sensor SE21	PSID #12	3, 4, 5	A55.J1:1	18,1	Low Beam LH L60	PSID #142	3, 4, 6	A45.J1:7	26,1
Drv air Trap MO3	PSID #5	3, 4, 6	A44.J1:2	18,1	Low Beam RH L59	PSID #146	3, 4, 6	A48.J1:4	26,1
Drv Rec Cylind L203	PSID #30	3, 4, 5, 6	A47.J1:2	18,1	Low Wip Spd1 Mo22	PSID #184	3, 4, 5, 6	A47.J1:3	34,1
Elec Horn L185 L186	PSID #83	3, 4, 6	A43.J1:13	9,1	Lower Stop Lamps	PSID #153	3, 4, 6	A50.J1:6	26,2
Elec.Horn SW61 SW62	PSID #82	4	A41.J1:3	9,1	Lower Washer pmp	PSID #181	4, 6	A46.J1:3	34,1
Emergency Relay R21	PSID #44	3, 4, 5, 6	A36.JA:24	3,2	Lower Washer SW1	PSID #188	3, 4	A46.J1:9	34,1
Eng Brk Active Sig	PSID #45	3, 4	A42.J1:18		Lower Wip Int SW1	PSID #183	3, 4	A42.J1:8	34,1
Eng Cmpt Bulb L173	PSID #106	3, 4, 5, 6	A52.J1:5	25,1	Lugg doors lock R30	SID #44	3, 4, 5, 6	A36.JA:7	33,1
Eng Cmpt Sw	PSID #107	3, 4	A52.J1:11	25,1	Lugg doors unl R32	SID #45	3, 4, 5, 6	A36.JA:6	33,1
Eng Ether SW23	PSID #50	3, 4	A42.J1:5	13,1	OutDoor Sens SE20	PSID #161	3, 4, 5	A54.J1:14	18,1
Eng Fan Dash SW22	PSID #55	3, 4	A36.JB:14		Park brak Sens Se18	PSID #162	3, 4	A36.JB:9	12,1
Eng Fan Spd1 Req	PSID #51	3, 4	A52.J1:9	13,1	Pass def fan Mo25	SID #38	3, 4, 5, 6	A47.J1:7	18,1
Eng Fan Spd2 Req	PSID #52	3, 4	A52.J1:10	13,1	Pass Heat Sol SO13	PSID #24	3, 4, 6	A54.J1:8	18,2
Eng. Ether Sol SO1	PSID #49	3, 4, 6	A52.J1:6	13,1	Pass Rfg Sol SO11	PSID #23	3, 4, 5, 6	A54.J1:3	18,2
Engine Fan Spd1 MO2	PSID #53	3, 4, 5, 6	A52.J1:1	13,1	Pass. Wtr pump MO12	PSID #17	4, 6	A54.J1:4	18,2
Engine Fan Spd2 MO2	PSID #54	3, 4, 5, 6	A52.J1:2	13,1	Rear CutOut Sw82	PSID #18	3, 4	A36.JB:21	3,2
Evap Motor Rly R12	PSID #77	3, 4, 5, 6	A54.J1:7	18,2	RearFlsh LH L71 L75	PSID #131	3, 4, 6	A51.J1:21	26,2
Evap Spd Ctrl MO9	PSID #78	4, 6	A54.J1:2	18,2	RearFlsh RH L73 L76	PSID #132	3, 4, 6	A51.J1:3	26,2
Fire Sensor	PSID #79	3, 4	A41.J1:10	9,1	Retarder signal	PSID #164	3, 4	A50.J1:12	15,1

