

DIODES NUMBER CODE

No	Location	Part #	Function	Page
D1	FJB	561740	AccessoriesDiode	3.2
D2	FJB	561740	DiodeDriverLiq.Sol.	18.1
D3	UpperFrontCap	561740	SuppressorDiodeUpperWiper	34.1
D4	RHConsole	561740	SuppressorDiodeLowerWiper2ndSpd	34.1
D5	RHConsole	561740	SuppressorDiodeLowerWiper1stSpd	34.1
D6	RJB	561740	SuppressorDiodeMasterrelay	3.1
D11	Evap.Cmpt.	561740	DiodePass.Liq.Sol	18.2
D12	FJB	561740	EngineBrakediode	12.1
D15	RJB	561740	WakeUpDiode	3.2
D22	RJBVECR	561740	ServiceBrakeDiode	12.1
D25	Evap.Cmpt.	561740	SuppressorDiodeEvaporatorFan	18.2
D28	RJB	561740	SuppressorDiodeUnloaderLH	18.2
D29	RJB	561740	SuppressorDiodeUnloaderRH	18.2
D30	Evap.Cmpt.	561740	SuppressorDiodeWaterPump	18.2
D31	RJB	561740	SuppressorDiodeA/CClutch	18.2
D36	RJB	561740	SuppressorDiodeRadiatorFanClutch2ndSpd	13.1
D37	RJB	561740	SuppressorDiodeRadiatorFanClutch1stSpd	13.1
D38	FrontCeiling	563375	SuppressorZenerDiodeSunVisorRH	30.1
D39	FrontCeiling	563375	SuppressorZenerDiodeSunVisorRH	30.1
D40	UpperFrontCap	563375	SuppressorZenerDiodeSunVisorLH	30.1
D41	UpperFrontCap	563375	SuppressorZenerDiodeSunVisorLH	30.1
D42	LHConsole	563374	SuppressorZenerDiodeDriverWdw	30.1
D43	LHConsole	563374	SuppressorZenerDiodeDriverWdw	30.1
D44	FJB	561740	IgnitionDiode	3.2
D46	FJB	563557	ServiceBrakeDiode	12.1
D47	RJBVECR	563557	SpareDiode	5.1
D48	RJBVECR	563557	SpareDiode	5.1
D50	ServiceCmpt.	561740	LevelLowDiode	32.1
D51	ServiceCmpt.	561740	LevelLowDiode	32.1
D56	Dash	561740	Entrancedoorswitch	29.1
D62	FJB	561740	MasterRelay	3.2
D66	ServiceCmpt.	561740	SuppressorDiodeWaterPump	18.3
D71	LHConsole	563374	Entrancedoorlock	29.1
D72	LHConsole	563374	Entrancedoorlock	29.1
D73	Dash	561740	EntranceDoorHingeSwitch	29.1
DS01	Luggagescmpt	563375	SlideOutMotor	20.1
DS02	Luggagescmpt	563375	SlideOutMotor	20.1
DS03	Luggagescmpt	563375	SlideOutMotor	20.1
DS04	Luggagescmpt	563375	SlideOutMotor	20.1