

DIODES LIST

No	Location	Part #	Function	Page				
D1	FJB	561740	AccessoriesDiode	3.2				
D2	FJB	561740	DiodeDriverLiq. Sol.	18.1				
D3	UpperFrontCap	561740	SuppressorDiodeUpperWiper	34.1				
D4	RHConsole	561740	SuppressorDiodeLowerWiper2ndSpd	34.1				
D5	RHConsole	561740	SuppressorDiodeLowerWiper1stSpd	34.1				
D6	RJB	561740	SuppressorDiodeMasterrelay	3.1				
D11	Evap.Cmpt.	561740	DiodePass. Liq. Sol	18.2				
D12		561740	*opt*	12.1				
D15	RJB	561740	WakeUpDiode	3.2				
D25	Evap.Cmpt.	561740	SuppressorDiodeEvaporatorFan	18.2				
D28	RJB	561740	SuppressorDiodeUnloaderLH	18.2				
D29	RJB	561740	SuppressorDiodeUnloaderRH	18.2				
D30	Evap.Cmpt.	561740	SuppressorDiodeWaterPump	18.2				
D31	RJB	561740	SuppressorDiodeA/Cclutch	18.2				
D36	RJB	561740	SuppressorDiodeRadiatorFanClutch2ndSpd	13.1				
D37	RJB	561740	SuppressorDiodeRadiatorFanClutch1stSpd	13.1				
D44	FJB	561740	IgnitionDiode	3.2				
D50	ServiceCmpt.	561740	LevelLowDiode	32.1				
D51	ServiceCmpt.	561740	LevelLowDiode	32.1				
D56	Dash	561740	Entrancedoorswitch	29.1				
D62	FJB	561740	MasterRelay	3.2				
D66	ServiceCmpt.	561740	SuppressorDiodeWaterPump	18.3				
D71	LHConsole	563374	Entrancedoorlock	29.1				
D72	LHConsole	563374	Entrancedoorlock	29.1				
D73	Dash	561740	EntranceDoorHingeSwitch	29.1				
D75	Slide-OutPanel	561740	ParkBrakeDiode	20.1				
DSo1		*opt*	ZenerMotSldOut1	20.1				
DSo2		*opt*	ZenerMotSldOut1	20.1				
DSo3		*opt*	ZenerMotSldOut2	20.1				
DSo4		*opt*	ZenerMotSldOut2	20.1				
DSo5	Luggagescmpt	563375	ZenerMotSldOut3	20.2				
DSo6	Luggagescmpt	563375	ZenerMotSldOut3	20.2				