WIRING DIAGRAM INDEX

| Information Pages | | I E | | M | | ĪT | |
|-------------------------------|------------|------------------------------|-----------|--|-----------|--------------------------|------|
| Multiplexed Devices Index | B1 - B8 | ELD / ITS Gateway | 42.4 | Main Distribution Ignition & Batt. | 3.1 | Tail and Licence Lights | 26.2 |
| Arrangement - Harness | C1-C2 | Emergency and Aisle lights | 12.1 | Main Distribution Wake-Up | 3.3 | | |
| Circuit Number Listing | E | Engine brake and Retarder | 14.2 | Marker Lights | 26.1,26.2 | Transmission Allison | 15.1 |
| Circuit Breaker code | F | Engine ECU And Heater Outlet | 25.1 | Mirror Ramco | 31.1 | Transmission I Shift | 15.3 |
| Connectors code | G | Engine Lighting | 3.2 | Multiplexing Power | 7.1 | Trailer Package | 26.4 |
| Diode Number Code | Н | Engine Start | 14.1 | Multiplexing Network | 6.1, 6.2 | Tire Pressure Monitoring | 39.1 |
| Resistors Number Code | J | Engine VECU, Override | 29.1 | | | • | |
| Fuses Code | L | Entrance Door | 16.1 | | | | |
| Relay Code | K | ESP | | N | | U | |
| | | | | No Smoking Sign | 11.1 | Under Floor Lighting | 25.1 |
| | | F | 14.1 | | | Urea | 14.4 |
| Functions | | Fast Idle | 9.1 | | | | |
| | | Fire Alarm | 38.1 | | | | |
| A | | Fire Extinguisher | 26.1,26.2 | Р | | V | |
| ACB | 41.1 | Flashers | 26.3 | Parcel Rack Fan | 18.2 | Video Distribution | 35.3 |
| Air Dryer | 37.2 | Fog lights | 10.1 | Park Brake Sensor | 12.1 | Volvo Link | 37.1 |
| | | Fuel Gauge | 13.1 | Park Brake Trailer Sensor | 12.1 | | |
| В | | Fuel Filter Preheater | | Parking Brake Release Switch | 32.1 | W | |
| Back-up Camera | 28.1 | | | Power Distribution FJB | 4.1 | Watch your step | 29.1 |
| Back-up lights and alarm | 26.3 | G | 2.1 | Power Distribution RJB | 5.1 | Wheelchair Lift Ricon | 36.1 |
| Battery and Equalizer | 1.1 | Grounds | 45.1 | Power Outlet 12VDC | 30.1 | Window Ajar | 27.1 |
| Battery Charger | 17.1 | Galley | | Pre-Heater | 17.1 | Wiper & Washer | 34.1 |
| Brake Pedal Sensor | 12.1 | | | Prime Pump | 13.1 | | |
| | | Н | 26.1 | Pneumatic Cut-Out Acc. | 9.1 | | |
| С | | Hazard Switch | 26.1 | | | | |
| Charging System | 3.2 | Head Lights Switch | 9.1 | R | | | |
| Cigar lighter | 30.1 | Horn | 22.1 | Radiator Fan Clutch | 13.1 | | |
| Clearance lights rear & front | 26.1,26.2 | Hostess Chime | 18.1 | Reading Lamp | 22.1 | | |
| Cluster | 10.1 | Hvac Driver's Area | 18.2 | Regulator 5V & Audio IN & HDMI IN 35.8 | | | |
| Cornering Lights | 26.3 | Hvac Passenger | | | | | |
| Cruise control | 14.1 | | | | | | |
| | | I | 23.1 | S | | | |
| | | Indirect Led Lighting | 40.1 | Sound System | 35.5-35.6 | | |
| D | | Inverters and Outlets | | Spare Wires | 8.1 | | |
| Dash Lights | 19.1 | | | Stop lights | 26.2 | | |
| Destination Sign | 28.2 | K | | Sun Visor | 41.1 | | |
| Direct Led Lighting | 24.1 | Kneeling & Tag | 32.1,32.2 | Steering Control ZF | 37.1 | | |
| Docking Lights | 26.3 | | | Steering Multi-functions | 41.1 | | |
| Driver's Light and Backlight | 19.1 | L | | Speaker Arrangement | 35.2 | | |
| Driver's Window & Seat | 30.1, 30.3 | Lavatory | 11.1 | Seat Audio | 35.7 | | |
| Digital Clock | 28.1 | Low Buoy | 32.1 | | | | |
| | | Luggage Door Lock/Unlock | 33.1 | | | | |
| | | Luggage Compt. Lighting | 25.1 | | | | |

| PREVOST | WIRING DIAGRAM | No: | D061340 Page A | REMSION 23 |
|---------|----------------|-----|----------------|------------|