

WIRING DIAGRAM PAGES LIST

Information pages		D		I		R	
Multiplex output list	B1	Dash Lights	19.1	Indirect & Hat Rack Lighting	23.1	Radiator Fan Clutch	14.1
Multiplex input list	B2	Destination Sign	28.1	IVN (Cleaver Device)	35.8	Reading Lamp	22.1
Multiplex error messages list	B3	Direct Lighting	24.1	Inverter (s) & 120V outlets	40.1	Retarder	12.1 - 15.1
Arrangement - Harness	C1.1- C1.4	Docking Lights (Optional)	26.5				
Circuit Number Listing	E	Driver's Light & Backlight	19.1	K		S	
Circuit Breaker code	F	Driver's Window	30.1	Kneeling system	32.1	Speaker Arrangement	35.2
Connectors code	G	Driver's Seat	30.3			Spare Wires	8.1
Diode Number Code	H			L		Stop Lights	26.2
Resistors Number Code	J			Luggage Door Lock/Unlock	33.1 - 33.2	Steering Control ZF	37.2
Fuses Code	L	E				Steering Wheel Control	41.1
Relay Code	K	Engine ECU Volvo	14.1	M		Sun Visor	41.1
Symbol List	M	Engine Block Heater	14.1	MobileView	35.7		
		Engine Start	3.2	Main Distribution Ignition & Batt.	3.1		
A		Entrance Door & Lights	29.1	Main Distribution Wake-Up	3.3		
ACM - Urea	14.2	ESP	16.1	Marker Lights	26.1 - 26.2	T	
Air Dryer	37.1			Mirror w/ Adjustment	31.1	Tag Automatic Unload system	32.1
Air Exhaust Fan	11.1			Multiplexing Power	7.1	Tail & Licence Lights	26.2
Air Filter Sensor	39.1	F		Multiplexing Network	6.1 - 6.2	Tachometer Rear	39.1
A/C 120V Outlets	40.1	Fan Rear Junction Box	1.1			TLSE > See Fire Supp. Sys.	38.1
		Farebox	28.1	N		Trailer Package	26.4
B		Fast Idle	14.1	Next Stop Indicator	37.1	Trailer Park Brake	12.2
Back-up lights & Alarm	26.3	Fire Alarm	38.1			Transmission Allison Gen 5	15.1
Batteries & Equalizer	1.1	Fire Suppression System	38.1				
Battery Charger	17.1	Flashers	26.1 - 26.2	O		U	
Brake and Brk Interlock	12.1	Fog Lights	26.5	Oil Separator - WET Tank	37.1	Under Floor Lighting	25.1 - 25.2
Brake Wear Sensor	13.1	Fuel Gauge	10.1			Upper Defrost	18.4
		Fuel water Filter	13.1			Urea System	14.2
C		G		P		V	
Charging System	3.2	Ground Distribution	2.1	Parcel Rack A/C system	18.3	Volvo Link (TGW)	37.1
Cigar Lighter	30.2			Park Brake Sensor	12.1		
Clearance Lights Rear & Front	26.1 - 26.2	H		Park Brake Trailer Sensor	12.2	W	
Cluster	10.1	Hazard	26.1	Pneumatic Cut-Out Acc.	9.1	Watch Your step	29.1
Compressor Cooling Fan	14.1	Head Lights	26.1	Power Distribution FJB	4.1	Water Pump Relay	17.1
Cornering Lights (Optional)	26.5	Horn (Electric)	9.1	Power Distribution RJB	5.1	Wheelchair Lift Ricon	36.1
Coolant Level Led	39.1	Hostess Chime	22.2	Power Outlet	30.2	Window Ajar	27.1
Coolant Preheater Spheros	17.1	Hvac Defroster	18.1			Wiper & Washer	34.1
Cruise Control	14.1	Hvac Passengers	18.2				
Clever Devices	35.8 , 35.9						