

CONNECTORS CODE

NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET	NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET
				HOUSING	HOUSING					HOUSING	HOUSING
AA1	BEHIND DASH - SONALERT	BOSCH	5		561183	C 57					
AA2	BEHIND DASH - SONALERT	BOSCH	5		561183	C 58	RR JCT BOX AC PANEL	DEUTSCH	24	562280	562283
C X1	FR LH UPPER WHELL CPT-ABS	AMP	18		562792	C 59	RR JCT BOX AC PANEL	AMP CPC	14	561584	561583
C X2	FR LH UPPER WHELL CPT-ABS	AMP	6		562793	C 60	RR JCT BOX COMPT.-LT	AMP MNL	2	561248	561247
C X3	FR LH UPPER WHELL CPT-ABS	AMP	9		562794	C 61	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247
C X4	FR LH UPPER WHELL CPT-ABS	AMP	15		562795	C 62	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247
CS	RR JCT BOX ECU WORLD TR.	PED	32		562817	C 63	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247
CT	RR JCT BOX ECU WORLD TR.	PED	32		562824	C 64	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247
C V	RR JCT BOX ECU WORLD TR.	PED	32		562823	C 65	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247
CV 12	RR JCT BOX-WORLD TRANSM. & EATON CLUSTER	AMP CPC	9	561636	561637	C 66	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247
C Y		JAE	30		562765	C 67	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247
C 1	FR JCT BOX COMPARTMENT	AMP CPC	14	561585	561584	C 68	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247
C 2	FR JCT BOX COMPARTMENT	AMP CPC	16	561639	561640	C 69	RR AXLE ACC-INSIDE PVC END	PED WP	6	561568	561578
C 3	FR JCT BOX COMPARTMENT	AMP CPC	24	561641	561643	C 70	LH CONSOLE	AMP CPC	16	561642	561643
C 4	FR JCT BOX COMPARTMENT	AMP CPC	37	561644	561646	C 71	FR JCT BOX COMPARTMENT	AMP CPC	37	561645	561646
C 5	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	37	561644	561646	C 72	FR JCT BOX COMPARTMENT	AMP CPC	24	561642	561643
C 6	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	16	561639	561640	C 73	DASH CENTER PANEL	AMP CPC	16	561639	561640
C 7						C 74	FR JCT BOX COMPARTMENT	AMP CPC	37	561645	561646
C 8	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	24	561641	561643	C 75					
C 9	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	24	561641	561643	C 76	LUGGAGE COMPT.-AIR RET.SENS.	AMP MNL	2	561248	561247
C 10						C 77	LUGGAGE COMPT.-AIR RET.SENS.	AMP MNL	2	561248	561247
C 11	FR SERVICE COMPARTMENT	AMP CPC	37	561644	561646	C 78					
C 12	FR SERVICE COMPARTMENT	AMP CPC	16	561639	561640	C 79					
C 13	LH CONSOLE-CTR MIRROR	AMP MNL	6	561552	561515	C 80	LUGGAGE COMPT.-AIR RET.SENS.	AMP MNL	2	561248	561247
C 14	UNDER DASH-LH MIRROR	AMP MNL	9	561661	561662	C 81	PASSENGER COMPT.-AISLE LTS	AMP MNL	2	560900	560898
C 15	RR JCT BOX	AMP CPC	24	561641	561643	C 82	ENTRANCE DOOR	MOLEX	6	562070	562069
C 16	LH CONSOLE SW-CRUISE ON OFF	EATON	10	-----	562763	C 83	ENTRANCE DOOR-PROIMITY SW	MOLEX	4	561477	561476
C 17	LH CONSOLE SW-CRUISE RESUME	EATON	10	-----	562763	C 84	ENTRANCE DOOR-PRESSURE SW	PED WP	2	561566	561690
C 18	LH CONSOLE SW-CRUISE SET	EATON	10	-----	562763	C 85	UNDER INSTRUMENT PANEL LH	AMP MTA-100	-----	562248	-----
C 19	LH CONSOLE DECEL SW	EATON	10	-----	562763	C 86					
C 20	RR JCT BOX	AMP CPC	37	561644	561646	C 87	RR END ROOF	AMP CPC	9	561636	561637
C 21	RR JCT BOX	AMP CPC	24	561641	561643	C 88					
C 22	RR JCT BOX - EATON TRANSM.	AMP MNL	6	561552	561515	C 89	RR END ROOF-B/U NONITOR	AMP CPC	4	561582	561581
C 23	DDEC ENGINE-ECM J1939	PED MP	6	-----	561962	C 90	RR JCT BOX	AMP CPC	15	561987	561986
C 24	DDEC ENGINE	PED WP	1	561605	561577	C 91	RR JCT BOX	AMP CPC	37	561714	561713
C 25	RR JCT BOX - EATON TRANSM. J1939	DEUTCH	3	562877	562884	C 92	FR LH UPPER WHELL CPT-ABS	AMP CPC	9	561635	561637
C 26	HYD & MAN TRANSM.-NEUT. & B/U	PED WP	4	561610	561611	C 93	FR LH UPPER WHELL CPT-ABS		35	-----	641094
C 27	HYD & MAN TRANSM.-SPEED SENS.	PED WP	2	561566	561690	C 94					
C 28	EATON TRANSMISSION	DEUTCH	3	562877	562884	C 95	CONDENSOR CPT - LIQ. SOL. VALVE	PED WP	2	561566	561690
C 29	EATON TRANSMISSION	PED MP	6	562878	-----	C 96	FR AXLE ACCESSORIES	AMP CPC	14	561585	561585
C 30	RR JCT BOX - ECU EATON TRANSM.	PED MP	32	-----	562866	C 97	RR AXLE ACC-INSIDE PVC END	PED WP	6	561568	561578
C 31	RR JCT BOX - ECU EATON TRANSM.	PED MP	24	-----	562865	C 98	FR SERVICE COMPT-EL.FT.PEDAL	PED WP	3	561782	561781
C 32	DDEC ENGINE-ECM	PED	30	-----	561600	C 99	FR SERVICE COMPT LTS	AMP MNL	2	561248	561247
C 33	RR JCT BOX - EATON TRANSM.	DEUTCH	9	562531	-----	C 100	LH CONSOLE - 120 VOLTS SWITCH	EATON	8	-----	562763
C 34	RH. CONSOLE - EATON TRANSM. SHIFTER	PED MP	3	-----	562871	C 101	FR SERVICE COMPT-ELEC. HORNS	PED WP	2	561566	561690
C 35	RR JCT BOX	AMP CPC	24	561642	561643	C 102	FR SERV & SIDE CPT-FLASH. LH	GROTE	2	-----	562155
C 36	RH. CONSOLE - EATON TRANSM. SHIFTER	PED MP	24	-----	562874	C 103	FR SERV & SIDE CPT-MARKERS	GROTE	2	-----	562155
C 37	RR SECTION-LH HAT RACK	MOLEX	6	562558	562557	C 104	FR SERV & SIDE CPT-FLASH. RH	GROTE	2	-----	562155
C 38	RR SECTION-RH HAT RACK	MOLEX	6	562558	562557	C 105	FR SERVICE COMPT-LIQ.S.VALVE	PED WP	2	561566	561690
C 39	LH CONSOLE - EATON TRANSM. DISPLAY	AMP MNL	4	561551	561668	C 106	FR SERVICE COMPT-WATER VALVE	PED WP	2	561566	561690
C 40	RR JCT BOX - EATON TRANSM. J1939	DEUTCH	3	562877	562884	C 107	EVAPORATOR COMPT-DAMPER	PED WP	2	561566	561690
C 41	LAVATORY ROOF FLUORESCENT	AMP MNL	2	560900	560898	C 108	FR SERVICE COMPT-KNEEL.SYS	PED WP	2	561566	561690
C 42	LAVATORY BACK WALL-WTR TANK	AMP MNL	2	560900	560898	C 109	FR SERVICE COMPT-KNEEL.SYS	PED WP	2	561566	561690
C 43	LAVATORY BACK WALL-ACCES.	AMP MNL	9	561661	561662	C 110	FR SERVICE COMPT-KNEEL.SYS	PED WP	2	561566	561690
C 44	EATON TRANSM. J1939	DEUTCH	3	562877	562884	C 111	EVAPORATOR COMPT-DAMPER	DEUTSCH	2	562486	562485
C 45	FR JCT BOX COMPARTMENT	AMP CPC	24	561642	561643	C 112	EVAPORATOR COMPT-SPEED MOT CTRL	DEUTSCH	5	-----	562566
C 46	EATON TRANSM. J1939	DEUTCH	3	562877	562884	C 113	BATT. & RR J.B.CPT.MARKER LT	GROTE	2	-----	562155
C 47	FR SERVICE COMPARTMENT	AMP CPC	16	561694	561695	C 114	RR J. BOX CPT DOOR DIR LT LH	GROTE	2	-----	562155
C 48	FR. SERVICE CMPT.PRESS SW PARK BREAK	DEUTCH	4	562479	562477	C 115	ENGINE COMPT-AIR DRYER	PED WP	2	561566	561690
C 49	BATTERIE COMPT.-LT	AMP MNL	2	561248	561247	C 116	ENGINE COMPT. LTS	PED WP	1	561605	561577
C 50	FR SERVICE COMPT.-LOW BUOY	PED WP	1	561605	561577	C 117					
C 51						C 118	ENGINE COMPT-LAVATORY FAN	PED WP	2	561566	561690
C 52	RR JCT BOX	AMP CPC	22	561709	561710	C 119	ENGINE CPT RR DOOR RH LO LAMP	PED WP	6	561606	561607
C 53						C 120	ENGINE CPT RR DOOR LH LO LAMP	PED WP	6	561606	561607
C 54						C 121	BATTERIE CPT. DOOR DIR LT RH	GROTE	2	-----	562155
C 55	RH SWITCH PANEL	AMP CPC	9	561636	561637	C 122	ENGINE CPT-UNLOAD TAG SYSTEM	PED WP	2	561566	561690
C 56						C 123	TAG AXLE-UNLOAD TAG RH VALVE	PED WP	2	561566	561690

CONNECTORS CODE

NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET	NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET
				HOUSING	HOUSING					HOUSING	HOUSING
C 124	ENGINE CPT-ETHER SW	PED WP	2	561566	561690	C 189	ENGINE CPT RR DOOR B/U LT	PED WP	2	561566	561690
C 125	ENGINE CPT-BU ALARM	PED WP	2	561566	561690	C 190	ENGINE CPT RR DOOR TAIL LT	PED WP	2	561566	561690
C 126	ENGINE CPT-FLUSHING PUMP	PED WP	2	561566	561690	C 191	ENGINE CPT RR DOOR RH STOP LT	PED WP	2	561566	561690
C 127	ENGINE CPT-FUEL FILTER	PED WP	2	561566	561690	C 192	ENGINE CPT RR DOOR RH DIR. LT	PED WP	2	561566	561690
C 128	ENGINE CPT-A/C COMPR.CLUTCH	ITT SS	2	561813	561812	C 193					
C 129	ENGINE CPT-PRE-HEAT WATER	AMP FF	6	561672	561186	C 194	ENGINE CPT RR DOOR LH DIR. LT	PED WP	2	561566	561690
C 130	ENGINE CPT-UNLOADER	ITT SS	2	561813	561812	C 195	ENGINE CPT RR DOOR LH STOP LT	PED WP	2	561566	561690
C 131	ENGINE CPT-UNLOADER	ITT SS	2	561813	561812	C 196	ENGINE CPT RR DOOR CYCLOP LT	PED WP	2	561566	561690
C 132	ENGINE CPT-A/C LO PRESS SW	PED WP	2	561566	561690	C 199	ENGINE CPT RR DOOR LICENCE LT	DOM AUTO	2	930210	-----
C 133	ENGINE CPT-A/C HI PRESS SW	PED WP	2	561566	561690	C 200	RH HAT RACK-FLUORESCENT	AMP MNL	2	561248	561247
C 134	FR JCT BOX-LUGGAGE DIODE CON.	AMP MNL	15	561987	561986	C 201	RH HAT RACK-FLUORESCENT	AMP MNL	2	561248	561247
C 135	FR JCT BOX-LUGGAGE DIODE CON.	AMP MNL	15	561987	561986	C 202	RH HAT RACK-INDIRECT LIGHTING	MOLEX	2	-----	562758
C 136	RR JCT BOX - A/C PANEL DIODE CONN.	AMP MNL	15	561987	561986	C 203	RH HAT RACK-INDIRECT LIGHTING	MOLEX	6	-----	562759
C 137	RR JCT BOX-TRANSMITTER	AMP MNL	2	560900	560898	C 204	RH HAT RACK-GENERAL LT	AMP MNL	2	560900	560898
C 138	RR JCT BOX-CONTROL MODULE	AMP HDP	15	-----	562012	C 205	FR SECT.-RH HAT RACK SPEAKER	AMP MNL	9	561661	561662
C 139	RR JCT BOX-LOGIC MODULE	AMP HDP	15	562011	-----	C 206	RH HAT RACK-READING LT	AMP FF	4	-----	562756
C 140	HVAC DASH MODULE THERMOMETER	MOLEX	4		562782	C 207	LH HAT RACK-READING LT	AMP FF	4	-----	562756
C 141	INSTRUMENT PANEL LH UNLOAD TAG	AMP	2	561248	561247	C 208	LH HAT RACK-BALLAST	MOLEX	2	-----	562758
C 142	LAVATORY DOOR WALL	AMP MNL	2	561248	561247	C 209	LH HAT RACK HOTESS CHIME	AMP MNL	3	561667	561550
C 143	LAVATORY DOOR WALL	AMP MNL	3	560908	562006	C 210	FR SECT.-LH HAT RACK SPEAKER	AMP MNL	9	561661	561662
C 144	UNDER LH SEAT-AISLE LTS	AMP MNL	4	560851	560852	C 211	FR ROOF-STORE LH	AMP MNL	2	560900	560898
C 145	RR JCT BOX CPT-RR SIDE LTS	AMP MNL	9	561670	561669	C 212	FR ROOF-STORE RH	AMP MNL	2	560900	560898
C 146	ENGINE CPT-MODULATOR VALVE	AMPHENOL	2	-----	560412	C 213					
C 147	BATT & RR J.B.CPT-DOCK.LTS	PED WP	2	561566	561690	C 214	ENGINE CPT J1922				
C 148						C 215	TAG AXLE - A.T.C. SYSTEM				
C 149	CONDENSER CPT-FAN MOTOR	ORDNANCE	3	562555	562001	C 216	TAG AXLE - A.T.C. SYSTEM				
C 150						C 217	RH DASH PANEL-FRONT CAMERA SW	EATON	8	-----	562763
C 151	EVAPORATOR CPT-THERMOSTAT	ITT SS	2	561813	562159	C 218	RH DASH PANEL-FRONT CAMERA SW	AMP MNL	2	560900	560898
C 152	CONDENSER CPT-FUEL GAUGE	PED WP	4	561610	561611	C 219					
C 153	EVAPORATOR CPT-AIR AMB. SENS	AMP MNL	2	561248	561247	C 220	RR.JCT.BOX-FUEL PRIME PUMP	TC	1	561070	561073
C 154	EVAPORATOR CPT-FRESH AIR SENS	ITT SS	2	561813	561812	C 221	BATTERY CMPT. FIRE DETECTOR	DEUTSCH	2	562486	562485
C 155	EVAPORATOR CPT-WATER VALVE	PED WP	4	561610	561611	C 222	ENGINE CMPT. FIRE DETCTOR	DEUTSCH	2	562486	562485
C 156	EVAPOR. CPT-BYPASS WATER VAL.	PED WP	2	561566	561690	C 223	ENGINE CMPT. FIRE DETCTOR	DEUTSCH	2	562486	562485
C 157	EVAPORATOR CPT-WATER PUMP	PED WP	2	561566	561690	C 224					
C 158	CONDENSER CPT-A/C LO TEMP.	PED WP	2	561566	561690	C 225					
C 159	CONDENSER CPT-A/C HI TEMP.	PED WP	2	561566	561690	C 226					
C 160	FR AXLE-ABS RH SENSOR	WABCO	2	641132	-----	C 227					
C 161	FR AXLE-ABS RH VALVE	WABCO	3	-----	641098	C 228					
C 162	FR AXLE-ABS LH VALVE	WABCO	3	-----	641098	C 229					
C 163	FR AXLE-ABS LH SENSOR	WABCO	2	641132	-----	C 230	ENG.CPT.-FUEL PRIME PUMP FEED	DEUTSCH	2	562486	562485
C 164	RR AXLE-ABS LH SENSOR	WABCO	2	641132	-----	C 231	ENG.CPT.-FUEL PRIME PUMP SW.	PED WP	2	561566	561690
C 165	RR AXLE-ABS LH VALVE	WABCO	3	-----	641098	C 232	ENG.CPT.-FUEL PRIME PUMP	PED WP	2	561566	561690
C 166	RR AXLE-ABS RH VALVE	WABCO	3	-----	641098	C 233	FR. SERVICE COMPT.	VDO	8	-----	562043
C 167	RR AXLE-ABS RH SENSOR	DEUTSCH	2	641132	-----	C 234	FR. SERVICE COMPT.	VDO	8	-----	562044
C 168	RR AXLE-ABS OPT ATC	PED WP	2	561566	561690	C 235	FR. SERVICE COMPT.	VDO	8	-----	562041
C 169	RR JCT BOX-SPEED SW	AMP HDP	15	-----	562012	C 236	LUGGAGE COMPARTEMENT	AMP MNL	4	560851	560852
C 170	FR JCT BOX-FLASHER UNIT	TC	2	-----	561940	C 237	UNDER DASH LH-JACOB CLUTCH SW	ITT SS	3	561111	561080
C 171	LH CONSOLE	AMP CPC	24	561642	561643	C 238	RR JCT BOX-DIODE CONNECTOR	AMP MNL	9	561670	561669
C 172	ENGINE COMPT-WATER TANK HEAT.	PED WP	2	561566	561690	C 239	FR SERVICE CPT-HI BUOY VALVE	PED WP	2	561566	561690
C 173	LAV.POTABLE-WATER TANK HEAT.	AMP MNL	2	560900	560898	C 240	FR SERVICE CPT-KNEEL PROX SW	PED WP	2	561566	561690
C 174	UNDER DASH RH-HTR MODULE	AMP MNL	9	561670	561669	C 241					
C 175	UNDER DASH RH-HTR MODULE	AMP MNL	9	561670	561669	C 242	FR SERVICE CPT-MARK & DIR LT	ITT SS	3	561111	561080
C 176	UNDER DASH RH-WIPER PULSE	AMP FF	6	-----	561186	C 243	FR SERVICE CPT-HEADLAMPS	TC	3	-----	561071
C 177	UNDER DASH RH-WIPER MOTOR	AMP FF	6	-----	561186	C 244	FR SERVICE CPT-LH FOG LAMP	ITT SS	2	561813	561812
C 178	UNDER DASH RH-LH FAN	TC	2	561030	560997	C 245	FR SERVICE CPT-RH FOG LAMP	ITT SS	2	561813	561812
C 179	UNDER DASH RH-RH FAN	TC	2	561030	560997	C 246	FR SERVICE CPT-MARK & DIR LT	ITT SS	3	561111	561080
C 180	RR JCT BOX-DIODE CONNECTOR	AMP MNL	15	561987	561986	C 247					
C 181	RR JCT BOX-DIODE CONNECTOR	AMP MNL	15	561987	561986	C 248	FR JCT BOX-WIPER PULSE GEN	AMP FF	6	-----	561108
C 182						C 249					
C 183	FR SERVICE CPT-KNEELING PAN.	PED WP	4	561610	561611	C 250					
C 184	FR SERVICE CPT-KNEELING SW	ITT SS	3	561111	561080	C 251	LH DASH PANEL-FAST IDLE SW	EATON	8	-----	562763
C 185						C 252					
C 186	RR JCT BOX CPT.-SPEED SIGN.TR	PED WP	2	561566	561690	C 253	LH DASH PANEL-ETHER SW	EATON	8	-----	562763
C 186M	RR JCT BOX CPT.-SPD SIGN. M.TR	PED WP	2	561566	561690	C 254	INST. PANEL RH-ENTR.DOOR SW.	TORRIX	5	-----	562110
C 186W	RR JCT BOX CPT.-SPD SIGN. WT	PED WP	2	561566	561690	C 255	LH DASH PANEL-JACOB & RETARDER SW	EATON	8	-----	562763
C 187	FR JCT BOX-RPM RESISTOR CON.	AMP MNL	6	561552	561515	C 256					
C 188						C 257					

CONNECTORS CODE

NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET	NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET
				HOUSING	HOUSING					HOUSING	HOUSING
C 258	LH SW PANEL-MULTI FUNC. SW	AMP FF	8	561188	-----	C 325	LH DASH PANEL-KNEELING SW	EATON	8	-----	562763
C 259	LH SW PANEL-MULTI FUNC. SW	AMP FF	6	-----	561108	C 326	ENGINE CMPT.	PED	4	-----	561610
C 260	FR SERVICE CPT-LUG DOOR LCK	PED WP	6	561606	561607	C 327	ENGINE CONTROL	DEUTSCH	6	562583	562581
C 261	UNDER DASH RH-DOOR MODULE	AMP MNL	9	561670	561669	C 328	GALLEY-LAMP	AMP MNL	2	561248	561247
C 262	UNDER DASH RH-DOOR MODULE	AMP MNL	4	561551	561668	C 329	ENGINE TACHO SIGNAL	PED WP	3	561781	561789
C 263	UNDER DASH RH-DOOR MODULE	AMP MNL	3	561667	561550	C 330					
C 264	UNDER DASH RH-DOOR MODULE	AMP MNL	3	561667	561550	C 331	GALLEY MICROWAVE SW	EATON	8	-----	562763
C 265	UNDER DASH RH-DOOR MODULE	AMP HDP-20	15	562011	562012	C 332					
C 266						C 333	GALLEY RH CONTAINER SW	EATON	8	-----	562763
C 267	UNDER DASH RH	AMP CPC	24	561642	561643	C 334	GALLEY LH CONTAINER SW	EATON	8	-----	562763
C 268	UNDER DASH LH-MIRROR	AMP MNL	6	561552	561515	C 335					
C 269	UNDER DASH RH-MIRROR	AMP MNL	6	561552	561515	C 336					
C 270	LH MIRROR POST	MOLEX	6	562070	562069	C 337	INSTR PANEL LH-UP WIPER SW	EATON	8	-----	562763
C 271	RH MIRROR POST	MOLEX	6	562070	562069	C 338	INSTR PANEL LH-UP DEFROST SW	EATON	8	-----	562763
C 272	LH MIRROR	SPARTAN	6	-----	990158	C 339	INSTR PANEL LH-UP WASHER SW	EATON	8	-----	562763
C 273	RH MIRROR	SPARTAN	6	-----	990158	C 340	FR JCT. BOX FIRE PIEZO ALARM	AMP MNL	2	560900	560898
C 274	RR. JCT. BOX - SIGNAL ALT. MODULE					C 341	INSTR PANEL LH-HEAT MIRROR SW	EATON	8	-----	562763
C 275	UNDER DASH RH-DOOR MODULE	AMP MNL	9	561670	561669	C 342	ENGINE RR START SW	DEUTSCH	2	562586	562585
C 276	UNDER DASH RH-LOCK SOL.VALVE	AMP MNL	2	561248	561247	C 343	INSTR PANEL LH-HEADLAMP SW	EATON	8	-----	562763
C 277						C 344	INSTR PANEL LH-HAZARD LT SW	EATON	8	-----	562763
C 278						C 345	INSTR PANEL LH-FOG LT SW	EATON	8	-----	562763
C 279	UNDER DASH CYLINDER READ SW.	AMP MNL	2	561248	561247	C 346					
C 280	LH CONSOLE-UNLOAD TAG SW.	NGR	10	-----	562763	C 347	INSTR PANEL LH-DASH LT SW	AMP MNL	2	560900	560898
C 281						C 348	INSTR PANEL CENT-RACOR MODULE	MOLEX	6	562070	562067
C 282						C 349					
C 283						C 350	RH CONSOLE-THERMOMETER	AMP MNL	3	561667	561550
C 284						C 351	LH HAT RACK-FLUOR 110V	MOLEX	4	561477	561476
C 285						C 352	RH CONSOLE-DRV TEMP SENSOR	BURNDY	4	-----	561104
C 286	RH SW PANEL-A/C & HEAT	EATON	8	-----	562763	C 353	INSTR PANEL RH-DRV FAN RHEOST	AMP MNL	6	561552	561515
C 287	ENGINE COMPT-LTS SW	PED WP	2	561566	561690	C 354	INSTR PANEL RH-DRV TEMP CTR	AMP MNL	6	561552	561515
C 288	RH SW PANEL-FRESH AIR	EATON	8	-----	562763	C 355	INSTR PANEL RH-FR TEMP CTR	AMP MNL	3	561667	561550
C 289						C 356					
C 290						C 357	INSTR PANEL RH-WATER TEMP GA	AMP MNL	3	561667	561550
C 291						C 358	INSTR PANEL RH-FUEL LEVEL GA	AMP MNL	3	561667	561550
C 292						C 359					
C 293						C 360					
C 294						C 361	FR ROOF-WIPER MOTOR	AMP FF	6	-----	561186
C 295						C 362	FR ROOF-LAVATORY OCCUPIED LT	AMP MNL	2	561248	561247
C 296						C 363	FR ROOF-WATCH YOUR STEP LT	AMP MNL	2	561248	561247
C 297	INSTRUMENT PANEL RH -LTS	AMP MNL	2	560900	560898	C 364	FR ROOF-DESTINATION SIGN	AMP MNL	3	561667	561550
C 298						C 365	FR ROOF-UP WINDSHIELD DEFROST	AMP MNL	3	561667	561550
C 299	RH DASH PANEL SW-GALLEY	EATON	8	-----	562763	C 366	RH DASH PANEL-GRN & RED LEDS	AMP MNL	3	560908	562006
C 300						C 367	ENGINE COMPT-DIF OIL T SENSOR	PED WP	2	561566	561690
C 301						C 368	FR ROOF-DEST. SIGN BALLAST	AMP MNL	3	561667	561550
C 302						C 369	FR ROOF-DEST. SIGN OPER. SW	TORRIX	5	-----	562110
C 303						C 370	FR ROOF-DEST. SIGN FLUOR.	AMP MNL	2	560900	560898
C 304						C 371	FR ROOF-DEST. SIGN FLUOR.	AMP MNL	2	560900	560898
C 305						C 372	FR ROOF-DEST. SIGN SPEED SW	MOLEX	4	561477	561476
C 306						C 373	FR ROOF-NO SMOKING LT	AMP MNL	2	561248	561247
C 307						C 374	LH SWITCH PANEL	AMP MNL	6	561552	561515
C 308	LH CONSOLE SW-RHEOSTAT	TC	2	561030	560997	C 375					
C 309	DDEC ENGINE-ECM POWER CON.	PED MP	5	-----	562345	C 376					
C 310	LH DASH PANEL -LUG. DOOR LCK SW	EATON	8	-----	562763	C 377	LH DASH PANEL-STOP ENG.OVERRIDE SW	EATON	8	-----	562763
C 311	RH DASH PANEL -HOS & PAS CHIME SW	EATON	8	-----	562763	C 378					
C 312	RH DASH PANEL -READING LTS SW	EATON	8	-----	562763	C 379					
C 313	RH DASH PANEL -GEN & FLUOR LTS SW	EATON	8	-----	562763	C 380	LH CONSOLE-DDR CONNECTOR	DEUTSCH	6	562360	-----
C 314	LH DASH PANEL-FR DEST. SIGN SW	EATON	8	-----	562763	C 381					
C 315	LH DASH PANEL-LH STORE SW	EATON	8	-----	562763	C 382					
C 316	LH CONSOLE SPARE SWITCH	EATON	8	-----	562763	C 383					
C 317	LH DASH PANEL-RH STORE SW	EATON	8	-----	562763	C 384					
C 318	LH CONSOLE SW-DRV WINDOW LIFT	EATON	8	-----	562763	C 385					
C 319						C 386	LH DASH PANEL-WCL POWER SYSTEM SW	EATON	8	-----	562763
C 320	RH DASH PANEL-DRIVER'S LTS SW	EATON	8	-----	562763	C 387	RR JCT BOX (WCL)	AMP MNL	9	561661	561662
C 321	READING LTS TEST					C 388	RR JCT BOX (WCL)	AMP MNL	12	561735	561734
C 322	LH CONSOLE DRV WIND LIFT MOT	PED PO	2	-----	561848	C 389	WCL REAR DOOR	MOLEX	4	561477	561476
C 323	LH CONSOLE CRUISE CTR SW PAN. AMP	CPC	9	561636	561637	C 390	LAVATORY WALL-WCL REMOTE CTR	EATON	8	-----	562763
C 324						C 391	LAVATORY WALL-WCL LAMP	EATON	8	-----	562763

CONNECTORS CODE

NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET	NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET
				HOUSING	HOUSING					HOUSING	HOUSING
C 392	LAVATORY WALL-WCL SW. LT.	EATON	2	-----	561835	C 459	WORLD TRANSM.-ENGINE SP.SENS.	PED MP	2	-----	562426
C 393	LAVATORY WALL-WCL REMOTE SYS.	AMP CPC	4	561686	561687	C 460	WORLD TRANSM.-SPEED SENSOR	ITT	2	-----	562541
C 394	UNDER INSTR. PANEL- B/U MONITOR	AMP MNL	4	560851	560852	C 461	WORLD TRANSM.-RETARDER TEMP.	PED MP	2	561566	561680
C 395	DRIVER'S COMPT. - B/U MONITOR	AMP	5	-----	-----	C 462	WORLD TRANSM.-RETARD SOL."K"	PED MP	2	-----	562426
C 396	FR SECT. LH HAT RACK-SPEAKER	MOLEX	4	562507	562503	C 463	WORLD TRANSM.-SENSOR CONN.	DEUTSCH	16	562570	562571
C 397	ENGINE COMPT. CRADLE ACC.	DEUTSCH	40	562281	562284	C 464	RR JCT BOX-DDR CONNECTOR	DEUTSCH	6	-----	562360
C 398						C 465	LH CONSOLE-SHIFTER SELECTOR	PED	20	-----	562825
C 399	ENGINE COMPT. - PRE-EXITATION ALT.	PED WP	2	561566	561690	C 466	FR SERVICE CPT.-RESIS. MOD.	PED WP	3	-----	562428
C 400	ENGINE COMPT. BLOCK HEATER	PED MP	3	561781	561782	C 467	FR SERVICE CPT.-RESIS. MOD.	PED WP	3	-----	562428
C 401						C 468			8		
C 402	RR DRIVE AXLE-AIR DRYER	PED MP	2	-----	562251	C 469					
C 403	GALLEY FRIGO NORCOLD	AMP MNL	2	561248	561247	C 470	FR LH UPPER WHELL CPT-SILENT 1000	AMP MNL	2	561248	561247
C 404	GALLEY LAMP	AMP MNL	2	561248	561247	C 471	FR LH UPPER WHELL CPT-SILENT 1000	AMP MNL	2	561248	561247
C 405						C 472	FR LH UPPER WHELL CPT-SILENT 1000	PED WP	2	561566	561690
C 406	FR JCT BOX COMPT.-ABS	AMP MNL	2	560900	560898	C 473	FR LH UPPER WHELL CPT-SILENT 1000	AMP MNL	3	561667	561550
C 407	ENGINE COMPT. -SIGNAL	PED WP	6	561606	561607	C 474	DRIVER CPT.-TEMP. SENSOR	AMP MNL	2	561247	561248
C 408	ENGINE COMPT. -SIGNAL	PED WP	6	561606	561607	C 475	RR JCT BOX-SPEED SIGN CONNECTOR	AMP MNL	2	561248	561247
C 409	ENGINE CPT -LOW COOL. LEVEL	PED MP	2	-----	562350	C 475M	RR JCT BOX-SPEED SIGN MANUAL TR.	MOLEX	6	562070	562069
C 410	FR JCT BOX-DIODE CONNECTOR	AMP MNL	15	561987	561986	C 475W	RR JCT BOX-SPEED SIGN WORLD TR.	MOLEX	6	562070	562069
C 411	FR JCT BOX-DIODE CONNECTOR	AMP MNL	15	561987	561986	C 476					
C 412	LH DASH PANEL-MASTER SWITCH SW	EATON	8	-----	562763	C 477					
C 413	ENG CPT-A/C HI UNLOAD PRS SW	PED WP	2	561566	561690	C 478	ELECTRONIC DESTINATION SIGN	AMP CPC	9	561636	561637
C 414	RR JCT BOX	AMP MNL	9	561670	561669	C 479	HVAC MODULE				
C 415	ENGINE CRADLE-FAN SIGNAL	PED WP	3	561781	561782	C 480	UNDER DASH LH-DR. FAN SPEED CTR. MOD	PED	4	561889	561890
C 416	ENGINE CRADLE-FAN SIGNAL	PED P-C	3	562398	-----	C 481	UNDER DASH LH-DR. FAN SPEED CTR. MOD	PED	3	561781	561782
C 417	FRONT JCT BOX-DIODES	AMP MNL	15	561987	561986	C 482					
C 418	LH DASH PANEL-HTR WINDSH.SW	EATON	8	-----	562763	C 483	FR SERVICE CPT. (NOT USED)	PED PC	2	-----	562237
C 419	FR JCT BOX-RETARDER OR JACOB	AMP MNL	3	561667	561550	C 484	UNDER DASH LH.-FOOT DAMPER MOTOR	PED PC	2	-----	562076
C 420	ENGINE COMPT. WEBASTO WATER HTR	TC	2	561597	-----	C 485	UNDER DASH LH.-DASH & DEFR. DAM.MOT.	AMP MNL	3	561667	561550
C 421	ENGINE COMPT. WEBASTO WATER HTR	TC	1	561073	-----	C 486					
C 422	ENGINE COMPT. WEBASTO WATER HTR	TC	2	561597	-----	C 487					
C 423	PRO-HEAT	PC	2			C 488					
C 424	UNDER INSTRUMENT PANEL CENTER	AMP MNL	3	561667	561550	C 489					
C 425	FR JCT BOX-DIODES	AMP MNL	15	561987	561986	C 490					
C 426	ENGINE COMPT. CLUTCH CTR FAN	PED WP	3	561781	561782	C 491					
C 427	PRO-HEAT	PED-WP	2	561566	561680	C 492					
C 428	PRO-HEAT	PED WP	6	561606	561607	C 493					
C 429	FR JCT BOX COMPT.	AMP MNL	6	561552	561515	C 494					
C 430	LH CONSOLE-TIMER	AMP FF	8	561188	562363	C 495					
C 431	LH CONSOLE-PRE HEAT.	TAB AMP	1	561540	561539	C 496					
C 432	ENGINE CPT.-PROX. SW. DOOR AJAR	PED-WP	2	561566	561680	C 497					
C 433	FR SERVICE CPT. KNEEL. PRESS. SW	PED WP	2	561566	561690	C 498					
C 434	FRONT JCT. BOX-DIODES	AMP MNL	15	561987	561986	C 499					
C 435	FR SERVICE CPT.(RH) KNEEL. PIEZO	AMP MNL	2	560900	560898	C 500	FR LH UPPER WHELL CPT -PRODRIVER	MOLEX	6	562070	562069
C 436	RH HAT RACK-WCL CENTER ROOF ACC	AMP CPC	16	561639	561640	C 501	FR LH UPPER WHELL CPT -PRODRIVER	PED MP	7	562433	-----
C 437	RH HAT RACK-WCL FR & RR SECT.	AMP CPC	24	561642	561643	C 502	LH DASH PANEL-PRE HEATER SW.	EATON	8	-----	562763
C 438						C 503	LH CONSOLE-PRE HEATER SW.	EATON	2	-----	561837
C 439						C 504	LH CONSOLE WEBASTO TIMER	AMP	8	-----	562852
C 440						C 505	LH CONSOLE ESPAR TIMER	AMP	9	-----	562681
C 441						C 506	FR JCT BOX CPT. DIGITAL CLOCK	AMP	4	561685	561687
C 442						C 507	FR SECT. LH HAT-RACK DIG. CLOCK	MOLEX	4	561477	561476
C 443						C 508	RR JCT BOX-FAN CLUTCH RETARDER	AMP MNL	6	561552	561515
C 444						C 509	FR LH UPPER WHELL CPT -DATA LOGGER	PED MP	16	-----	562530
C 445						C 510	FR LH UPPER WHELL CPT -DATA LOGGER	DEUTSCH	9	562531	-----
C 446						C 511	FR LH UPPER WHELL CPT -DATA LOGGER	PED MP	4	562532	-----
C 447						C 512	FR LH UPPER WHELL CPT -DATA LOGGER	PED MP	10	562533	-----
C 448						C 513	FR LH UPPER WHELL CPT -DATA LOGGER	AMP MNL	3	561667	561550
C 449						C 514	FR LH UPPER WHELL CPT -DATA LOGGER	PED MP	6	562433	562417
C 450	SOUND SYS. JCT. PANEL	MOLEX	4	562507	562503	C 515	FR JCT BOX CPT.-INTERCOM	MOLEX	4	561477	561476
C 451	WIRELESS MICRO-FIRST CPT BAG	MOLEX	2	562550	562549	C 516	FR JCT BOX CPT.-INTERCOM	MOLEX	6	562070	562069
C 452	UNDER DASH INSTR. PANEL	MOLEX	2	562550	562549	C 517	LAVATORY WALL-INTERCOM	MOLEX	6	562070	562069
C 453	SOUND SYS. JCT.PANEL-VCP	PED WP	2	561566	561680	C 519	UNDER DASH RH-SEDAN DOOR	HUMPHREY	2	-----	562580
C 454	SOUND SYS.JCT.PAN.-FILT. VCP	PED WP	2	561566	561680	C 520	UNDER DASH RH-SEDAN DOOR	HUMPHREY	2	-----	641385
C 455	WIRELESS MICRO-LH HAT-RACK	CINCH	2	562554	562551	C 521	UNDER DASH RH-SEDAN DOOR	HUMPHREY	2	-----	641385
C 456	WORLD TRANSM.-RETARDER ACCUM.	PED MP	2	-----	562427	C 522	FR JCT BOX-DAYTIME LTS MODULE	BOSCH	5	-----	561183
C 457	WORLD TRANSM.-MAIN CONNECTOR	DEUTSCH	31	562572	562536	C 523	FR JCT BOX-FUSE BLOCK	PED	8	562647	562646
C 458	WORLD TRANSM.-TURBINE SP.SENS	PED MP	2	-----	562426	C 524	FR JCT BOX-FUSE BLOCK	PED	8	562647	562646

CONNECTORS CODE

NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET	NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET
				HOUSING	HOUSING					HOUSING	HOUSING
C 525	FR JCT BOX-FUSE BLOCK	PED	8	562647	562646	C 592	L.H.CONSOLE - MIRROR R.H.	EURAMTEC	8	-----	562799
C 526	FR JCT BOX-FUSE BLOCK	PED	8	562647	562646	C 593	BATTERY CMPT. - CHARGER	PED WP	3	561781	561782
C 527	FR JCT BOX-FUSE BLOCK	PED	8	562647	562646	C 594	FRONT ROOF - DRIVERS LIGHT	LEEKRAFT		-----	562803
C 528	FR JCT BOX-FUSE BLOCK	PED	8	562647	562646	C 595	DASH CENTER MODULE - OPEN DOOR	MOLEX	4	561477	561476
C 529	FR JCT BOX-12V OUTLET	AMP MNL	2	561247	561248	C 596	DASH CENTER MODULE - CLOSE DOOR	MOLEX	4	561477	561476
C 530	RR JCT BOX-FUSE BLOCK	PED	8	562647	562646	C 597	L.H. DASH PANEL - DISPLAY SET SW.	MOLEX	5		562812
C 531	RR JCT BOX-FUSE BLOCK	PED	8	562647	562646	C 598	L.H. DASH PANEL - DISPLAY SET SW.	MOLEX	5		562812
C 532	RR JCT BOX-FUSE BLOCK	PED	8	562647	562646	C 599					
C 533	RR JCT BOX-FUSE BLOCK	PED	8	562647	562646	C 600	ENGINE CPT.-A/C LOW PRESS SW. UNLOAD	PED	2	562348	562471
C 534	RR JCT BOX-FUSE BLOCK	PED	8	562647	562646	C 601	L.H. ROOF - WINDOW AJAR	AMP MNL	2	561248	561247
C 535	RR JCT BOX-FIRE MODULE DETECT.	AMP MNL	3	561667	561550	C 602	L.H. ROOF - WINDOW AJAR	MOLEX	4	561477	561476
C 536	UNDER DASH RH-DRIVER'S HTR TEMP. CTR	AMP MNL	6	561552	561515	C 603	R.H. ROOF - WINDOW AJAR	AMP MNL	2	561248	561247
C 537	BATT. CPT.-A/C PRESS. SIGN. RLY	AMP MNL	2	561248	561247	C 604					
C 538	FR SERVICE CPT.-OUTSIDE TEMP. SENSOR	AMP MNL	2	561248	561247	C 605	HAT RACK - MOTOR FAN	PED	2	560997	561030
C 539	HVAC DASH MODULE OUTPUT CON	MOLEX	24		562780	C 606	HAT RACK - MOTOR FAN	PED	2	560997	561030
C 540	HVAC DASH MODULE INPUT CON	MOLEX	22		562781	C 607	FRONT SERVICE CMPT. RPM SIGNAL	PED WP	2	561566	561690
C 541	SOUND SYS. JCT PANEL-AUDIO SEAT SYS.	PED WP	2	561566	561690	C 608	FRONT SERVICE CMPT. SPEED SIGNAL	PED WP	2	561566	561690
C 542	LH HAT RACK-AUDIO SEAT SYSTEM	AMP MNL	3	561667	561550	C 609	LAVATORY - NIGHT LIGHT				
C 543	RR JCT BOX-PARK. BRAKE STOP LTS RESIS.	PED WP	2	561566	561690	C 610	RR JCT BOX	AMP MNL	6	561552	561515
C 544	SOUND SYS JCT PANEL-AUDIO SEAT SYS.	PED WP	3	561781	562428	C 611	HAT RACK READING LTS RICON	MOLEX	6	562558	562557
C 545	LH HAT RACK-AUDIO SEAT SYSTEM	AMP MNL	3	561667	561550	C 612	HAT -RACK FLUOR. INSTATION LTS RICON	MOLEX	4	562507	562503
C 546						C 613	HAT -RACK INDIRECT LTS RICON	AMP MNL	3	561667	561550
C 547	RH DASH PANEL-ACCESSORIES	AMP CPC	37	561645	561646	C 614	HAT -RACK INDIRECT LTS RICON	AMP MNL	3	561667	561550
C 548	LH DASH PANEL-T.T. LT. TEST SW.	EATON	8	-----	562763	C 615					
C 549	LH DASH PANEL-FAN CLUTCH OVERR. SW	EATON	8	-----	562763	C 616					
C 550	LAST LUGG. CPT. -WCL RICON	AMP CPC	16	561694	561695	L X	CLUSTER	JAE	22		562766
C 551	LAST LUGG. CPT. -WCL RICON	AMP CPC	16	561694	561695	L Y	CLUSTER	JAE	30		562767
C 552	LAST LUGG. CPT. -WCL RICON	AMP CPC	9	561636	561637	R X	CLUSTER	JAE	22		562764
C 553	UNDER DASH R.H. - CONTROL. HEAD	MOLEX	16	-----	562559						
C 554	UNDER DASH R.H. - CONTROL. HEAD	MOLEX	16	-----	562559						
C 555	UNDER DASH R.H. - CONTROL. HEAD	MOLEX	16	-----	562559						
C 556	UNDER DASH R.H. - RADIO ACC.	MOLEX	2	562550	562549						
C 557	UNDER DASH R.H. - RADIO ACC.	MOLEX	9	562556	562555						
C 558	UNDER DASH R.H. - RADIO ACC.	MOLEX	4	562507	562503						
C 559	SOUND SYS. JCT. PANEL - FILTER AMPLI	PED WP	2	561566	561690						
C 560	SOUND SYS. JCT. PANEL - POWER AMPLI	MOLEX	4	562507	562503						
C 561	L.H. HAT RACK - WIRELESS MICRO	MOLEX	4	562507	562503						
C 562	L.H. HAT RACK - VCP	MOLEX	9	562556	562555						
C 563	L.H. MODESTY PANEL - DRIVERS SPK.	MOLEX	4	562507	562503						
C 564	L.H. MODESTY PANEL - MICRO	MOLEX	4	562507	562503						
C 565	R.H. MODESTY PANEL - MICRO	MOLEX	4	562507	562503						
C 566	L.H. CONSOLE - BOOM MICRO	MOLEX	4	562507	562503						
C 567	L.H. CONSOLE - DRIVERS MICRO	MOLEX	4	562507	562503						
C 568	SOUND SYS. JCT. PANEL - PASS. SPK	CINCH	4	562553	562552						
C 569	SOUND SYS. JCT. PANEL - POWER AMPLI.	MOLEX	9	562556	562555						
C 570	UNDER DASH PANEL TTLT	MOLEX	6		562464						
C 571	UNDER DASH PANEL TTLT	MOLEX	20		562778						
C 572	UNDER DASH PANEL TTLT	MOLEX	18		562779						
C 573	UNDER DASH PANEL TTLT	MOLEX	8		562465						
C 574	HAT -RACK FLUOR. INDIRECT LIGHTING	MOLEX	6	-----	562759						
C 575	HAT -RACK FLUOR. INSTATION LIGHT	MOLEX	4	562507	562503						
C 576	HAT -RACK FLUOR. INDIRECT LIGHTING	AMP MNL	3	561667	561550						
C 577	HAT -RACK FLUOR. INDIRECT LIGHTING	AMP MNL	3	561667	561550						
C 578	HAT -RACK FLUOR. INSTATION LIGHT	MOLEX	4	562507	562503						
C 579											
C 580	RH DASH PANEL-HAT RACK FAN SW	EATON	8	-----	562763						
C 581											
C 582	FRONT SERVICE CMPT. - WINDOWS AJAR	PED WP	2	561566	561690						
C 583	L.H. DASH PANEL - MASTER KEY	DEUTSCH	2	562486	562485						
C 584	FRONT SERVICE CMPT. - AIR HORH	HUMPHREY	3	-----	641385						
C 585											
C 586											
C 587											
C 588	FRONT SERVICE CPT. CENTER SOUND SYS.	AMP. CPC	37	561645	561646						
C 589	UNDER DASH - L.H. MIRROR	AMP MNL	9	561670	561669						
C 590	UNDER DASH - R.H. MIRROR	AMP MNL	9	561670	561669						
C 591	L.H.CONSOLE - MIRROR L.H.	EURAMTEC	8	-----	562799						