

# CONNECTORS CODE

NO	LOCATION	TYPE	CAVITY	#PIN HOUSING	#SOCKET HOUSING	NO	LOCATION	TYPE	CAVITY	#PIN HOUSING	#SOCKET HOUSING
C X1	FR LH UPPER WHELL CPT-ABS	AMP	15		563200	C 59	RR JCT BOX - A/C PANEL	AMP CPC	14	561585	561583
C X2	FR LH UPPER WHELL CPT-ABS	AMP	18		563201	C 60	RR JCT BOX COMPT.-LT	AMP MNL	2	561248	561247
C TCI	DDEC ENGINE – TURBO TEMP	FCI	2		563404	C 61	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247
C RXTX	HVAC MODULE COMMUNICATION	MOLEX	3	563206	562783	C 62	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247
C S	RR JCT BOX ECU WORLD TR.	PED	32		562817	C 63	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247
C T	RR JCT BOX ECU WORLD TR.	PED	32		562824	C 64	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247
C V	RR JCT BOX ECU WORLD TR.	PED	32		562823	C 65	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247
C Y	CLUSTER	JAE	30		562765	C 66	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247
C 1	FR JCT BOX COMPARTMENT	AMP CPC	14	561585	561584	C 67	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247
C 2	FR JCT BOX COMPARTMENT	AMP CPC	16	561639	561640	C 68	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247
C 3	FR JCT BOX COMPARTMENT	AMP CPC	24	561641	561643	C 69	RR AXLE ACC-INSIDE PVC END	PED WP	6	561568	561578
C 4	FR JCT BOX COMPARTMENT	AMP CPC	37	561644	561646	C 70	LH CONSOLE	AMP CPC	24	561642	561643
C 5	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	37	561644	561646	C 71	FR JCT BOX COMPARTMENT	AMP CPC	37	561645	561646
C 6	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	16	561639	561640	C 72	FR JCT BOX COMPARTMENT	AMP CPC	24	561642	561643
C 8	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	24	561641	561643	C 74	FR JCT BOX COMPARTMENT	AMP CPC	37	561645	561646
C 9	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	37	561644	561646	C 75	LUGG. COMPT. - DOOR LOCK	AMP MNL	2	561551	561668
C 10						C 76	LUGGAGE COMPT.-AIR RET.SENS.	AMP MNL	2	561248	561247
C 11	FR SERVICE COMPARTMENT	AMP CPC	37	561644	561646	C 77	LUGGAGE COMPT.-DOOR LOCK		4	561551	561668
C 12	FR SERVICE COMPARTMENT	AMP CPC	16	561639	561640	C 78	LUGGAGE COMPT.-LTS - COND. CPT	AMP MNL	2	561248	561247
C 13	LH CONSOLE-CTR MIRROR	AMP MNL	6	561552	561515	C 79	LUGGAGE COMPT.-LTS - EVAP. CPT.	AMP MNL	2	561248	561247
C 14	UNDER DASH-LH MIRROR	AMP MNL	9	561661	561662	C 80	LUGGAGE COMPT.-AIR RET.SENS.	AMP MNL	2	561248	561247
C 15						C 80A	EVAPORATOR COMPT.-AIR RET.SENS.	AMP MNL	2	561248	561247
C 16	LH CONSOLE SW-CRUISE ON OFF	EATON	10	-----	562763	C 81	LUGGAGE COMPT.-DOOR LOCK	AMP MNL	2	561551	561668
C 17	LH CONSOLE SW-CRUISE RESUME	EATON	10	-----	562763	C 82	LUGGAGE COMPT.-DOOR LOCK	AMP MNL	2	561551	561668
C 18	LH CONSOLE SW-CRUISE SET	EATON	10	-----	562763	C 83	LUGGAGE COMPT.-DOOR LOCK	AMP MNL	2	561551	561668
C 19	LH CONSOLE DECEL SW	EATON	10	-----	562763	C 84	LUGGAGE COMPT.-DOOR LOCK	AMP MNL	2	561551	561668
C 20	RR JCT BOX	DEUTSCH	70	562282	562285	C 85	LUGGAGE COMPT.-DOOR LOCK	AMP MNL	2	561551	561668
C 21	RR JCT BOX	DEUTSCH	24	562281	562284	C 86	LUGGAGE COMPT.-DOOR LOCK	AMP MNL	2	561551	561668
C 22						C 87	RR END ROOF	AMP CPC	9	561636	561637
C 23						C 88	FR. SERV. COMPT.-PRESS SW. PARK BRAKE	PED WP	2	561566	561690
C 24						C 89	RR END ROOF-B/U NONITOR	AMP CPC	4	561582	561581
C 25						C 90	RR JCT BOX	AMP CPC	15	561987	561986
C 26						C 91	RR JCT BOX	AMP CPC	37	561714	561713
C 27						C 92	FR LH UPPER WHELL CPT-ABS	AMP CPC	9	561635	561637
C 28						C 93					
C 29						C 94					
C 30						C 95	CONDENSOR CPT. LIQ SOL VALVE	PED WP	2	561566	561690
C 31						C 96	FR AXLE ACCESSORIES	AMP CPC	14	561585	561585
C 32	DDEC ENGINE-ECM	AMP	68	-----	563403	C 97	RR AXLE ACC-INSIDE PVC END	PED WP	6	561568	561578
C 33						C 98	FR SERVICE COMPT-EL.FT.PEDAL	PED WP	3	561782	561781
C 34						C 99	FR SERVICE COMPT LTS	AMP MNL	2	561248	561247
C 35	RR JCT BOX	DEUTSCH	40	562281	562284	C 100					
C 36						C 101	FR SERVICE COMPT-ELEC. HORNS	PED WP	2	561566	561690
C 37						C 102	SIDE (LH/FR & CENTER) DIR. LTS	GROTE	2	-----	562155
C 38						C 103	SIDE (LH/FR & CENTER) MARKER LTS	GROTE	2	-----	562155
C 39						C 104	SIDE (RH/FR & CENTER) DIR. LTS	GROTE	2	-----	562155
C 40						C 105	FR SERVICE COMPT-LIQ.S.VALVE	PED WP	2	561566	561690
C 41						C 106	FR SERVICE COMPT-WATER VALVE	PED WP	2	561566	561690
C 42						C 107					
C 43						C 108					
C 44						C 109					
C 45	FR. JCT BOX COMPARTMENT	AMP CPC	24	561642	561643	C 110					
C 46						C 111	EVAPORATOR COMPT-DAMPER	DEUTSCH	2	562486	562485
C 47	FR SERVICE COMPARTMENT	AMP CPC	16	561694	561695	C 112	EVAPORATOR COMPT-SPEED MOT CTRL	DEUTSCH	5	-----	562566
C 48	FR. SERV. COMPT.-PRESS SW. PARK BRAKE	PED WP	2	561566	561690	C 113	SIDE (LH/RR) MARKER LTS	GROTE	2	-----	562155
C 49	BATTERIE COMPT.-LT	AMP MNL	2	561248	561247	C 114	SIDE (LH/RR) DIR LTS	GROTE	2	-----	562155
C 50						C 115					
C 51						C 116	ENGINE COMPT. LTS	GROTE	2	-----	563268
C 52	RR JCT BOX	AMP CPC	24	561642	561643	C 117	SIDE (RH/RR) MARKER LTS	GROTE	2	-----	562155
C 53						C 118					
C 54						C 119	ENGINE CPT RR DOOR RH LO LAMP	PED WP	6	561606	561607
C 55	RH SWITCH PANEL	AMP CPC	9	561636	561637	C 120	ENGINE CPT RR DOOR LH LO LAMP	PED WP	6	561606	561607
C 56						C 121	SIDE (RH/RR) DIR. LTS	GROTE	2	-----	562155
C 57						C 122	ENGINE CPT-CAMERA DOOR VALVE	PED WP	2	561566	561690
C 58	LUGGAGE COMPT. - A/C PANEL	AMP CPC	9	561636	561637	C 123					

# CONNECTORS CODE

NO	LOCATION	TYPE	CAVITY	#PIN HOUSING	#SOCKET HOUSING	NO	LOCATION	TYPE	CAVITY	#PIN HOUSING	#SOCKET HOUSING
C 124	ENGINE CPT-ETHER SW	PED WP	2	561566	561690	C 187	FR JCT BOX-RPM RESISTOR CON.	AMP MNL	6	561552	561515
C 125	ENGINE CPT-B/U ALARM	PED WP	2	561566	561690	C 188	LUGG. CPT. - MANUAL REMOTE SLIDE-OUT	AMP CPC	7	561772	561773
C 126						C 189	ENGINE CPT RR DOOR B/U LT	PED WP	2	561566	561690
C 127	ENGINE CPT-FUEL FILTER	PED WP	2	561566	561690	C 190	ENGINE CPT RR DOOR TAIL/STOP LT	AMP SUPER S	3		562601
C 128	ENGINE CPT-A/C COMPR.CLUTCH	ITT SS	2	561813	561812	C 191	ENGINE CPT RR DOOR TAIL/STOP LT	AMP SUPER S	3		562601
C 129	ENGINE CPT-PRE-HEAT WATER	AMP FF	6	561672	561186	C 192	ENGINE CPT RR DOOR RH DIR. LT	PED WP	2	561566	561690
C 130	ENGINE CPT-UNLOADER	ITT SS	2	561813	561812	C 193					
C 131	ENGINE CPT-UNLOADER	ITT SS	2	561813	561812	C 194					
C 132	ENGINE CPT-A/C LO PRESS SW	PED WP	2	561566	561690	C 195					
C 133	ENGINE CPT-A/C HI PRESS SW	PED WP	2	561566	561690	C 196					
C 134	FR JCT BOX-LUGGAGE DIODE CON.	AMP MNL	15	561987	561986	C 197					
C 135	FR JCT BOX-LUGGAGE DIODE CON.	AMP MNL	15	561987	561986	C 198	ENGINE CPT RR DOOR LICENCE LT	PED WP	2	562348	562471
C 136	RR JCT BOX-A/C PANEL DIODE CON.	AMP MNL	15	561987	561986	C 199					
C 137	RR JCT BOX-TRANSMITTER	AMP MNL	2	560900	560898	C 200					
C 138	RR JCT BOX-CONTROL MODULE	AMP HDP	15	-----	562012	C 201	AUX. UNIT CONTROL	PED WP	4	561610	561611
C 139	RR JCT BOX-LOGIC MODULE	AMP HDP	15	562011	-----	C 202	AUX. UNIT CONTROL	PED WP	3	561781	561782
C 140	HVAC DASH MODULE THERMOMETER	MOLEX	4	562782	-----	C 203	AUX. UNIT CONTROL	PED WP	2	561566	561690
C 141	INSTRUMENT PANEL LH UNLOAD TAG	AMP	2	561248	561247	C 204	AUX. LIQUID SOL.VALVE	PED WP	2	561566	561690
C 142						C 205					
C 143						C 206					
C 144						C 207					
C 145	RR JCT BOX CPT-RR SIDE LTS	AMP MNL	9	561670	561669	C 208					
C 146	ENGINE CPT-MODULATOR VALVE	AMPHENOL	2	-----	560412	C 209					
C 147	BATT & RR J.B.CPT-DOCK.LTS	PED WP	2	561566	561690	C 210					
C 148						C 211	FR ROOF-STORE LH	AMP MNL	2	560900	560898
C 149	CONDENSER CPT-FAN MOTOR	ORDNANCE	3	562555	562001	C 212	FR ROOF-STORE RH	AMP MNL	2	560900	560898
C 150	ENGINE CPT. - FUEL FILTER	PED WP	1	561605	561577	C 213					
C 151	EVAPORATOR CPT-THERMOSTAT	ITT	2	561813	562159	C 214					
C 152	CONDENSER CPT-FUEL GAUGE	PED WP	4	561610	561611	C 215					
C 153	EVAPORATOR CPT-AIR AMB. SENS	AMP MNL	2	561248	561247	C 216					
C 154	EVAPORATOR CPT-FRESH AIR SENS	ITT SS	2	561813	561812	C 217					
C 155	EVAPORATOR CPT-WATER VALVE	PNEUMAC	4	563204	-----	C 218					
C 156	EVAPOR. CPT-BYPASS WATER VAL.	PED WP	2	561566	561690	C 219					
C 157	FRONT SER. CPT-WATER PUMP	PED WP	2	561566	561690	C 220	RR.JCT.BOX-FUEL PRIME PUMP	TC	1	561070	561073
C 158	ENGINE CPT-A/C LO TEMP.	PED WP	2	561566	561690	C 221	BATTERY CMPT. FIRE DETECTOR	DEUTSCH	2	562486	562485
C 159	ENGINE CPT-A/C HI TEMP.	PED WP	2	561566	561690	C 222	ENGINE CMPT. FIRE DETECTOR	DEUTSCH	2	562486	562485
C 160	FR AXLE-ABS RH SENSOR	WABCO	2	641132	-----	C 223	ENGINE CMPT. FIRE DETECTOR	DEUTSCH	2	562486	562485
C 161	FR AXLE-ABS RH VALVE	WABCO	3	-----	641098	C 224					
C 162	FR AXLE-ABS LH VALVE	WABCO	3	-----	641098	C 225					
C 163	FR AXLE-ABS LH SENSOR	WABCO	2	641132	-----	C 226					
C 164	RR AXLE-ABS LH SENSOR	DEUTSCH	2	562486	562485	C 227					
C 165	RR AXLE-ABS LH VALVE	WABCO	3	-----	641098	C 228	ENG.CPT.-A/C COMPRESSOR	PED WP	2	561566	561690
C 166	RR AXLE-ABS RH VALVE	WABCO	3	-----	641098	C 229					
C 167	RR AXLE-ABS RH SENSOR	DEUTSCH	2	562486	562485	C 230	ENG.CPT.-FUEL PRIME PUMP FEED	DEUTSCH	2	562486	562485
C 168	RR AXLE-ABS OPT ATC	PED WP	2	561566	561690	C 231	ENG.CPT.-FUEL PRIME PUMP SW.	PED WP	2	561566	561690
C 169	RR JCT BOX-SPEED SW	AMP HDP	15	-----	562012	C 232	ENG.CPT.-FUEL PRIME PUMP	PED WP	2	561566	561690
C 170	FR JCT BOX-FLASHER UNIT	TC	2	-----	561940	C 233					
C 171	LH CONSOLE	AMP CPC	24	561642	561643	C 234					
C 172	FR SERV. COMPT.- LEVEL LOW	AMP CPC	9	561635	561637	C 235					
C 173	LAV.POTABLE-WATER TANK HEAT.	AMP MNL	2	560900	560898	C 236					
C 174	UNDER DASH RH-HTR MODULE	AMP MNL	9	561670	561669	C 237					
C 175	UNDER DASH RH-HTR MODULE	AMP MNL	9	561670	561669	C 238	UNDER DASH LH PASS REC DAMPER SW	EATON	8		562763
C 176	UNDER DASH RH-WIPER PULSE	AMP FF	6	-----	561186	C 239	RR I.D. LTS	PED WP	2	561566	561690
C 177	UNDER DASH RH-WIPER MOTOR	AMP FF	6	-----	561186	C 240	LUGG. CPT.-CO-PILOT SEAT HEATER	AMP MNL	2	560900	560898
C 178	UNDER DASH RH-LH FAN	TC	2	561030	560997	C 241	HEADLAMPS HI BEAM	HELLA	2		562623
C 179	UNDER DASH RH-RH FAN	TC	2	561030	560997	C 242	HEADLAMPS LO BEAM	HELLA	2		562623
C 181	RR JCT BOX-DIODE CONNECTOR	AMP MNL	15	561987	561986	C 242	HEADLAMPS LO BEAM (XENON OPTION)	PED MP	2		563366
C 180	RR JCT BOX-DIODE CONNECTOR	AMP MNL	15	561987	561986	C 243	FR SERVICE CPT-HEADLAMPS MAIN	DEUTSCH	6	565131	562789
C 182						C 244	FR SERVICE CPT-LH FOG LAMP	DEUTSCH	2	561813	561812
C 183						C 245	FR SERVICE CPT-RH FOG LAMP	DEUTSCH	2	561813	561812
C 184						C 246	FR SERVICE CPT-MARK & DIR LT	CONXALL	5	563091	563090
C 185						C 247	DIRECTIONAL & HAZARD FR LTS	AMP SS	3		562601
C 186						C 248	FR JCT BOX-WIPER PULSE GEN	AMP FF	6	-----	561108
C 186M	RR JCT BOX CPT.-SPD SIGN. M.TR	PED WP	2	561566	561690	C 249					
C 186W	RR JCT BOX CPT.-SPD SIGN. WT	PED WP	2	561566	561690	C 250					

# CONNECTORS CODE

NO	LOCATION	TYPE	CAVITY	#PIN HOUSING	#SOCKET HOUSING	NO	LOCATION	TYPE	CAVITY	#PIN HOUSING	#SOCKET HOUSING
C 251	LH SW PANEL-FAST IDLE	EATON	10	-----	562763	C 315	LH CONSOLE SW-LH STORE	EATON	10	-----	562763
C 252						C 316					
C 253	LH SW PANEL-ETHER	EATON	10	-----	562763	C 317	LH CONSOLE SW-RH STORE	EATON	10	-----	562763
C 254	INST. PANEL RH-ENTR.DOOR SW.	TORRIX	5	-----	562110	C 318	LH CONSOLE SW-DRV WINDOW LIFT	EATON	10	-----	562763
C 255	LH SW PANEL-JACOB	EATON	10	-----	562763	C 319					
C 256						C 320	RH SW PANEL-DRIVER'S LTS	EATON	10	-----	562763
C 257						C 321					
C 258	LH SW PANEL-MULTI FUNC. SW	AMP FF	8	561188	-----	C 322	LH CONSOLE DRV WIND LIFT MOT	PED PO	2	-----	561848
C 259	LH SW PANEL-MULTI FUNC. SW	AMP FF	6	-----	561108	C 323	LH CONSOLE CRUISE CTR SW PAN.	AMP CPC	9	561636	561637
C 260						C 324					
C 261						C 325	LH CONSOLE SW-KNEELING	EATON	8	-----	562763
C 262	UNDER DASH RH-KEYLESS MODULE	AMP MUL	22	-----	562675	C 326	LH CONSOLE SW-SPARE	EATON	8	-----	562763
C 263	UNDER DASH RH- KEYLESS MODULE	AMP MUL	26	-----	562676	C 327	ENGINE CONTROL	DEUTSCH	6	562583	562581
C 264	ENTRANCE DOOR-KEYPAD	AMP CPC	9	561536	561637	C 328					
C 265	RH SW PANEL -DRIVER'S DOOR SW.	EATON	10	-----	562763	C 329	ENGINE TACHO SIGNAL	PED WP	3	561781	561789
C 266	ENTRANCE DOOR-KEYLESS	AMP CPC	14	561585		C 330					
C 267	UNDER DASH RH	AMP CPC	24	561642	561643	C 331					
C 268						C 332					
C 269	UNDER DASH FLAT MIRROR	CONXALL	5	563091	563090	C 333					
C 270	LH MIRROR POST	MOLEX	6	562070	562069	C 334					
C 271	RH MIRROR POST	MOLEX	6	562070	562069	C 335					
C 272	LH MIRROR	SPARTAN	6	-----	990158	C 336					
C 273	RH MIRROR	SPARTAN	6	-----	990158	C 337	INSTR PANEL LH-UP WIPER SW	EATON	8	-----	562763
C 274	RR JCT BOX - ALT SIGNAL MODULE	AMP MNL	12	561735	561734	C 338	INSTR PANEL LH-UP DEFROST SW	EATON	8	-----	562763
C 275						C 339	INSTR PANEL LH-UP WASHER SW	EATON	8	-----	562763
C 276	UNDER DASH RH -3 WAY LTS	EATON	10	-----	562763	C 340	FR JCT. BOX FIRE PIEZO ALARM	AMP MNL	2	560900	560898
C 277	LH CONSOLE -DOCK. & CORN. SW.	EATON	10	-----	562763	C 341	INSTR PANEL LH-HEAT MIRROR SW	EATON	8	-----	562763
C 278	LH CONSOLE -BACK-UP CANCEL SW.	EATON	10	-----	562763	C 342	ENGINE RR START SW	DEUTSCH	2	562586	562585
C 279	FR SERVICE CPT- STEERING ZF	DEUTSCH	2	562485		C 343	INSTR PANEL LH-HEADLAMP SW	EATON	8	-----	562763
C 280	UNDER DASH RH -3 WAY LTS	EATON	10	-----	562763	C 344	INSTR PANEL LH-HAZARD LT SW	EATON	8	-----	562763
C 281	LH CONSOLE -LEVEL LOW	AMP MNL	4	560851	560852	C 345	INSTR PANEL LH-FOG LT SW	EATON	8	-----	562763
C 282	RH SW PANEL -MONITOR OPER. SW.	EATON	10	-----	562763	C 346	INSTR PANEL LH-SWITCH LTS	EATON	2	-----	561837
C 282	FR SERVICE CPT- STEERING GEAR BOX ZF	VOLVO	2	562928		C 347	INSTR PANEL LH-DASH LT SW	AMP MNL	2	560900	560898
C 283	LH CONSOLE -LOW DOCKING SW.	EATON	10	-----	562763	C 348	INSTR PANEL CENT-RACOR MODULE	MOLEX	6	562070	562067
C 284						C 349					
C 285	ENTRANCE DOOR -SOL. DOOR	PED PO	2	-----	562076	C 350	RH CONSOLE-THERMOMETER	AMP MNL	3	561667	561550
C 286	RH SW PANEL-A/C & HEAT	EATON	10	-----	562763	C 351					
C 287	ENGINE COMPT-LTS SW	PED WP	2	561566	561690	C 352	RH CONSOLE-DRV TEMP SENSOR	BURNDY	4	-----	561104
C 288	RH SW PANEL-FRESH AIR	EATON	10	-----	562763	C 353	INSTR PANEL RH-DRV FAN RHEOST	AMP MNL	6	561552	561515
C 289						C 354	INSTR PANEL RH-DRV TEMP CTR	AMP MNL	6	561552	561515
C 290	LUGGAGE COMPT -DOOR LOCK	AMP MNL	4	561551	561668	C 355	INSTR PANEL RH-FR TEMP CTR	AMP MNL	3	561667	561550
C 291	LUGGAGE COMPT -DOOR LOCK	AMP MNL	4	561551	561668	C 356					
C 292	FR SERVICE CMPT-LEVEL LOW		2		641385	C 357	INSTR PANEL RH-WATER TEMP GA	AMP MNL	3	561667	561550
C 293	FR SERVICE CMPT-LEVEL LOW		2		641385	C 358	INSTR PANEL RH-FUEL LEVEL GA	AMP MNL	3	561667	561550
C 294	FR SERVICE CMPT-LEVEL LOW		2		641385	C 359					
C 295	FR SERVICE CMPT-LEVEL LOW		2		641385	C 360	INSTR PANEL RH-B/U MONITOR	AMP MNL	2	561248	561247
C 296	FR SERVICE CMPT-LEVEL LOW		2		641385	C 361	FR ROOF-WIPER MOTOR	AMP FF	6	-----	561186
C 297	INSTRUMENT PANEL RH -LTS	AMP MNL	2	560900	560898	C 362					
C 298						C 363					
C 299						C 364					
C 300	FR SERVICE CPT- LOW BEAM RESISTORS	PED WP	2	561566	561690	C 365					
C 301						C 366	RH DASH PANEL-GRN & RED LEDS	AMP MNL	3	560908	562006
C 302						C 367					
C 303						C 368					
C 304						C 369					
C 305						C 370					
C 306						C 371					
C 307						C 372	FR ROOF-DEST. SIGN SPEED SW	MOLEX	4	561477	561476
C 308	LH CONSOLE SW-RHEOSTAT	TC	2	561030	560997	C 373	FR ROOF-NO SMOKING LT	AMP MNL	2	561248	561247
C 309						C 374	LH SWITCH PANEL	AMP MNL	6	561552	561515
C 310	LH CONSOLE SW-LUG. DOOR LOCK	EATON	10	-----	562763	C 375					
C 311						C 376	LH SWITCH PANEL	AMP CPC	37	561714	562005
C 312						C 377	LH SW PANEL-STOP ENG.OVERRIDE	EATON	10	-----	562763
C 313						C 378					
C 314						C 379					

# CONNECTORS CODE

NO	LOCATION	TYPE	CAVITY	#PIN HOUSING	#SOCKET HOUSING	NO	LOCATION	TYPE	CAVITY	#PIN HOUSING	#SOCKET HOUSING
C 380	LH CONSOLE-DDR CONNECTOR	DEUTSCH	6	562360	-----	C 445					
C 381	INST. PANEL CENTER-ANTI-THEFT LED	AMP MNL	2	561248	561247	C 446					
C 382						C 447					
C 383						C 448					
C 384						C 449					
C 385	EVAP CPT - FULL AIR WATER PUMP	PED WP	2	561566	561690	C 450					
C 386						C 451					
C 387						C 452					
C 388						C 453					
C 389						C 454					
C 390						C 455					
C 391						C 456	WORLD TRANSM.-RETARDER ACCUM.	PED MP	2	-----	562427
C 392						C 457	WORLD TRANSM.-MAIN CONNECTOR	DEUTSCH	31	562572	562536
C 393						C 458	WORLD TRANSM.-TURBINE SP.SENS	PED MP	2	-----	562426
C 394						C 459	WORLD TRANSM.-ENGINE SP.SENS.	PED MP	2	-----	562426
C 395						C 460	WORLD TRANSM.-SPEED SENSOR	ITT	2	-----	562541
C 396						C 461	WORLD TRANSM.-RETARDER TEMP.	PED MP	2	561566	561590
C 397	ENGINE COMPT. CRADLE ACC.	DEUTSCH	40	562281	562284	C 462	WORLD TRANSM.-RETARD SOL."K"	PED MP	2	-----	562426
C 398	ENGINE COMPT. - EXITING SIGNAL ALTERN.	PED WP	2	561566	561690	C 463	WORLD TRANSM.-SENSOR CONN.	DEUTSCH	16	562570	562571
C 399	ENGINE COMPT. - EXITING SIGNAL ALTERN.	PED WP	2	561566	561690	C 464	RR JCT BOX-DDL CONN W.T.	DEUTSCH	6	-----	562360
C 400	ENGINE COMPT. BLOCK HEATER	PED MP	3	561781	561782	C 465	LH CONSOLE-SHIFTER SELECTOR	PED	20	-----	562825
C 401						C 466	FR SERVICE CPT.-RESIS. MOD.	PED WP	3	-----	562428
C 402						C 467	FR SERVICE CPT.-RESIS. MOD.	PED WP	3	-----	562428
C 403						C 468					
C 404						C 469					
C 405						C 470	FR LH UPPER WHELL CPT-SILENT 1000	AMP MNL	2	561248	561247
C 406	FR JCT BOX COMPT.-ABS	AMP MNL	2	560900	560898	C 471	FR LH UPPER WHELL CPT-SILENT 1000	AMP MNL	2	561248	561247
C 407						C 472	FR LH UPPER WHELL CPT-SILENT 1000	PED WP	2	561566	561690
C 408						C 473	FR LH UPPER WHELL CPT-SILENT 1000	AMP MNL	3	561667	561550
C 409	ENGINE CPT -LOW COOL. LEVEL	PED MP	2	-----	562350	C 474	DRIVER'S.-TEMP. SENSOR	AMP MNL	2	561247	561248
C 410	FR JCT BOX-DIODE CONNECTOR	AMP MNL	15	561987	561986	C 475	RR JCT BOX-SPEED SIGN CONNECTOR	AMP MNL	2	561248	561247
C 411	FR JCT BOX-DIODE CONNECTOR	AMP MNL	15	561987	561986	C 475M	RR JCT BOX-SPEED SIGN MANUAL TR.	MOLEX	6	562070	562069
C 412	LH SW PANEL-MASTER SWITCH	EATON	10	-----	562763	C 475W	RR JCT BOX-SPEED SIGN WORLD TR.	MOLEX	6	562070	562069
C 413	ENG CPT-A/C HI UNLOAD PRS SW	PED WP	2	561566	561690	C 476					
C 414						C 477					
C 415	RR JCT BOX - ENGINE SIGNAL	DEUTSCH	24	562280	562783	C 478					
C 416						C 479	HVAC MODULE	MOLEX	3	-----	562783
C 417	FRONT JCT BOX-DIODES	AMP MNL	15	561987	561986	C 480	UNDER DASH RH-DR'S FAN SPEED CTR MOD	PED	4	561889	561890
C 418	INSTR. PANEL LH-HTR WINDSH.SW	EATON	10	-----	562763	C 481	UNDER DASH RH-DR'S FAN SPEED CTR MOD	PED	3	561781	561782
C 419	FR JCT BOX-RETARDER OR JACOB	AMP MNL	3	561667	561550	C 482					
C 420	ENGINE COMPT. WEBASTO WATER HTR	TC	2	561597	-----	C 483	FR SERVICE CPT. -SEAT ELECTRICAL SEAT	PED PC	2	-----	562237
C 421	ENGINE COMPT. WEBASTO WATER HTR	TC	1	561073	-----	C 484	UNDER DASH LH-FOOT DAMPER MOTOR	PED PC	2	-----	562076
C 422	ENGINE COMPT. WEBASTO WATER HTR	TC	2	561597	-----	C 485	UNDER DASH LH-DASH & DEFROST DAMP.M.	AMP MNL	3	561667	561550
C 423						C 486					
C 424	UNDER INSTRUMENT PANEL CENTER	AMP MNL	3	561667	561550	C 487					
C 425	FR JCT BOX-DIODES	AMP MNL	15	561987	561986	C 488					
C 426	ENGINE COMPT. CLUTCH CTR FAN	PED WP	3	561781	561782	C 489					
C 427						C 490					
C 428						C 491					
C 429	FR JCT BOX COMPT.	AMP MNL	6	561552	561515	C 492					
C 430	LH CONSOLE-TIMER	AMP FF	8	561188	562363	C 493					
C 431	LH CONSOLE-PRE HEAT.	TAB AMP	1	561540	561539	C 494					
C 432	ENGINE CPT.-PROX. SW. DOOR AJAR	DEUTSCH	4	562479	562477	C 495					
C 433	FR SERVICE CPT. KNEEL. PRESS. SW	PED WP	2	561566	561690	C 496					
C 434	FRONT JCT. BOX-DIODES	AMP MNL	15	561987	561986	C 497					
C 435	FR SERVICE CPT.(RH) KNEEL. PIEZO	AMP MNL	2	560900	560898	C 498					
C 436	RH HAT RACK-WCL CENTER ROOF ACC	AMP CPC	16	561639	561640	C 499					
C 437						C 500	FR LH UPPER WHELL CPT -PRODRIVER	MOLEX	6	562070	562069
C 438	EVAP. COMPT.-COND.RELAY	AMP MNL	2	561248	561247	C 501	FR LH UPPER WHELL CPT -PRODRIVER MOD	PED MP	7	562433	-----
C 439	EVAP. COMPT.-COND.RELAY	AMP MNL	2	561248	561247	C 502	LH CONSOLE-PRE HEATER SW.	EATON	10	-----	562763
C 440	EVAP. COMPT.-EVAP.RELAY	DEUTSCH	4	562479	562477	C 503					
C 441						C 504	LH CONSOLE WEBASTO TIMER	AMP	8	-----	562852
C 442						C 505	LH CONSOLE ESPAR TIMER	AMP	12	-----	562681
C 443						C 506	LH CONSOLE-LEVEL LOW SW.	EATON	10	-----	562763
C 444						C 508	RR JCT BOX-FAN CLUTCH RETARDER	AMP MNL	6	561552	561515

# CONNECTORS CODE

NO	LOCATION	TYPE	CAVITY	#PIN HOUSING	#SOCKET HOUSING	NO	LOCATION	TYPE	CAVITY	#PIN HOUSING	#SOCKET HOUSING
C 509	FR LH UPPER WHELL CPT -DATA LOGGER	PED MP	16	-----	562530	C 571	UNDER DASH PANEL TTLT MODULE	MOLEX	20	-----	562778
C 510	FR LH UPPER WHELL CPT -DATA LOGGER	DEUTSCH	9	562531	-----	C 572	UNDER DASH PANEL TTLT MODULE	MOLEX	18	-----	562779
C 511	FR LH UPPER WHELL CPT -DATA LOGGER	PED MP	4	562532	-----	C 573	UNDER DASH PANEL TTLT MODULE	MOLEX	8	-----	562465
C 512	FR LH UPPER WHELL CPT -DATA LOGGER	PED MP	10	562533	-----	C 574					
C 513	FR LH UPPER WHELL CPT -DATA LOGGER	AMP MNL	3	561667	561550	C 575					
C 514	FR LH UPPER WHELL CPT -DATA LOGGER	PED MP	6	562433	562417	C 576					
C 515						C 577					
C 516						C 578					
C 517						C 579					
C 518						C 580					
C 519						C 581					
C 520						C 582					
C 521						C 583	L.H. DASH PANEL - MASTER KEY	DEUTSCH	2	562486	562485
C 522	FR JCT BOX-DAYTIME LTS MODULE	BOSCH	5	-----	561183	C 584	FRONT SERVICE CMPT. - AIR HORH	HUMPHREY	3	-----	641385
C 523	FR JCT BOX-FUSE BLOCK	PED	8	562647	562646	C 585					
C 524	FR JCT BOX-FUSE BLOCK	PED	8	562647	562646	C 586					
C 525	FR JCT BOX-FUSE BLOCK	PED	8	562647	562646	C 587					
C 526	FR JCT BOX-FUSE BLOCK	PED	8	562647	562646	C 588					
C 527	FR JCT BOX-FUSE BLOCK	PED	8	562647	562646	C 589	FR SERVICE ELECT MIRROR	CONXALL	5	563089	563088
C 528						C 590	UNDER DASH ELECT MIRROR	CONXALL	8	563089	563088
C 529	FR JCT BOX-12V OUTLET	AMP MNL	2	561247	561248	C 591	L.H.CONSOLE - MIRROR L.H.	EURAMTEC	8	-----	562799
C 530	RR JCT BOX-FUSE BLOCK	PED	8	562647	562646	C 592	L.H.CONSOLE - MIRROR R.H.	EURAMTEC	8	-----	562799
C 531	RR JCT BOX-FUSE BLOCK	PED	8	562647	562646	C 593					
C 532	RR JCT BOX-FUSE BLOCK	PED	8	562647	562646	C 594	FRONT ROOF - DRIVERS LIGHT	LEEKRAFT		-----	562803
C 533						C 595					
C 534						C 596					
C 535	RR JCT BOX-FIRE MODULE DETECT.	AMP MNL	3	561667	561550	C 597	L.H. DASH PANEL - DISPLAY SET SW.	MOLEX	5	-----	562812
C 536	UNDER DASH RH-DRIVER'S HTR TEMP. CTR	AMP MNL	6	561552	561515	C 598	L.H. DASH PANEL - DISPLAY SET SW.	MOLEX	5	-----	562812
C 537	BATT. CPT.-A/C PRESS. SIGN. RLY	AMP MNL	2	561248	561247	C 599	UND.DASH-MAGN.SW.CTR.POS.DR'S AIR	AMP MNL	2	561248	561247
C 538	FR SERVICE CPT.-OUTSIDE TEMP. SENSOR	AMP MNL	2	561248	561247	C 600	ENGINE CPT.-A/C LOW PRESS SW. UNLOAD	PED	2	562348	562471
C 539	HVAC DASH MODULE OUTPUT CON	MOLEX	24		562780	C 601					
C 540	HVAC DASH MODULE INPUT CON	MOLEX	22		562781	C 602					
C 541						C 603					
C 542						C 604					
C 543						C 605					
C 544						C 606					
C 545						C 607					
C 546	LH DASH PANEL-ACCESSORIES	AMP CPC	37	561645	561646	CH 50	FRONT SERVICE COMP.- TRANS INHIBIT	PED WP	1	561605	561577
C 547	RH DASH PANEL-ACCESSORIES	AMP CPC	37	561645	561646	CH 51	FRONT SERVICE COMP.- TRANS INHIBIT	PED WP	1	561605	561577
C 548	LH DASH PANEL-T.T. LT. TEST SW.	EATON	10	-----	562763	L 608	FRONT SERVICE CMPT. SPEED SIGNAL	PED WP	2	561566	561690
C 549						LX	CLUSTER	JAE	22	-----	562766
C 550	EVAPORATOR COMPARTIMENT	ITT	2	561813	562159	RY	CLUSTER	JAE	30	-----	562767
C 551	RR JCT BOX - A/C PANEL	PED	2	561566	561690	X	CLUSTER	JAE	22	-----	562764
C 552											
C 553											
C 554											
C 555	LUGGAGES - AWNING WINDOWS	MOLEX	4	561477	561476						
C 555A	LUGGAGES-AWNING EXTENSION HARNESS	MOLEX	4	561477	561476						
C 555S1	FR SLIDE-OUT-AWNING WINDOW	MOLEX	4	561477	561476						
C 555S2	RR SLIDE-OUT-AWNING WINDOW	MOLEX	4	561477	561476						
C 556											
C 557											
C 558											
C 559											
C 560											
C 561											
C 562											
C 563											
C 564											
C 565											
C 566											
C 567											
C 568											
C 569											
C 570	UNDER DASH PANEL TTLT MODULE	MOLEX	6		562464						