

NO.	LOCATION	TYPE	(NB) CAVITY	*PIN HOUSING	*SOCKET HOUSING
C3	UNDER DASH-LH	AMP CPC	37	561645	561646
C7	FR SERVICE COMPT.-CLUTCH SW	ITT SS	3	561111	561080
C8	FR JCT PANEL VCR FEED	AMP MNL	2	561248	561247 PRIOR REV 010
C11	LH CONSOLE SW-MIRROR	AMP MNL	3	561667	561550
C12	LH CONSOLE SW-MIRROR HTR	AMP MNL	2	561248	561247
C13	LH CONSOLE SW-MIRROR	AMP MNL	6	561552	561515
C14	UNDER DASH LH-MIRROR	AMP MNL	9	561670	561669
C15	UNDER DASH RH-MIRROR	AMP MNL	9	561670	561669
C18	UNDER DASH-FIRE ALARM	AMP MNL	2	560900	560898
C19	UNDER DASH-A/C & HEAT SYST.	TC	10	561072	561110
C20	RR JCT BOX DIODES	AMP MNL	9	561670	561669
C21	LUGGAGE COMPT.-LOCK DOOR MOT.	PED	2	-----	562076
C22	ENGINE COMPT.-CYCLOP LT	PED WP	2	561566	561690
C26	UNDER INSTRUMENT.-PANEL RHEO.	TC	2	561030	560997
C29	FR SERVICE COMPT.-VIM FEED	PED WP	3	561781	561782
C32	RH CONSOLE-DRV TEMP SENSOR	BURNDY	3	-----	561104
C33	FRSERVICE COMPT. DDEC VSS	PED WP	2	561566	561690
C34	RH CONSOLE-DRV TEMP CTRL	BURNDY	6	-----	561103
C35	RECIRULATED AIR GRIL.-SENSER	BURNDY	3	-----	561104
C36	LH CONSOLE SW-CRUISE ON/OFF	SWF	8	-----	561107
C37	LH CONSOLE SW-CRUISE SET	SWF	8	-----	561107
C38	LH CONSOLE SW-CRUISE RESUME	SWF	8	-----	561107
C41	UNDER DASH-FLASHER UNIT	TC	2	-----	561940
C49	LAVATORY NIGHT LTS	AMP MNL	2	560900	560898
C50	RH CONSOLE-PAS. TEMP CTRL	BURNDY	6	-----	561103
C51	RH CONSOLE SW-A/C & HEAT	SWF	8	-----	561107
C52	ENGINE COMPT.-COMPRESSOR 05G	PED WP	2	561566	561690
C53	ENGINE COMPT.-COMPRESSOR 05G	PED WP	2	561566	561690
C54	ENGINE COMPT.-COMPRESSOR 05G	TC	1	560098	560697
C61	ENGINE COMPT.-FUEL FILTER	PED WP	2	561566	561690
C65	UNDER LH HAT RACK	MOLEX	4	561477	561476
C67	LH UNDER DASH-AMPLIF. RH SPK	BLAUPUNKT	2	561988	-----
C68	LH UNDER DASH-AMPLIF. RH SPK	BLAUPUNKT	2	561988	-----
C73	LH SW PANEL-MULTI FUNC. LEV.	AMP FF	8	561188	-----
C74	LH SW PANEL-MULTI FUNC. LEV.	AMP FF	6	-----	561108
C78	LUGGAGE COMPT.-DOOR LOCK 4 LH	AMP MNL	4	560851	560852
C79	LUGGAGE COMPT.-DOOR LOCK 4 RH	AMP MNL	4	560851	560852
C80	FR JCT PANEL-LUG. DOOR LOCK	AMP MNL	6	561552	561515
C81	LUGGAGE COMPT.-DOOR LOCK 1 LH	AMP MNL	4	560851	560852
C82	LUGGAGE COMPT.-DOOR LOCK 1 RH	AMP MNL	4	560851	560852
C83	UNDER DASH-FLASHER MODULE	TC	10	561072	561110
C84	UNDER DASH-A/C SYSTEM	TC	3	561091	561071
C85	LUGGAGE COMPT.-DOOR LOCK 3 RH	AMP MNL	4	560851	560852
C86	LUGGAGE COMPT.-DOOR LOCK 3 LH	AMP MNL	4	560851	560852
C88	RR END ROOF-CLEARANCE LTS	AMP MNL	2	560900	560898
C90	RR ROOF AUX. A/C THERMOST.	BURNDY	6	-----	561103
C91	RR ROOF AUX. A/C TMP SENSOR	BURNDY	6	-----	561104
C92	RR ROOF AUX. A/C FAN RH	TC	2	561030	560997
C93	RR ROOF AUX. A/C FAN LH	TC	2	561030	560997
C94	RR ROOF AUX. A/C FAN RES LH	AMP MNL	2	560900	560898
C95	RR ROOF AUX. A/C FAN RES RH	AMP MNL	2	560900	560898
C96	RR ROOF AUX. A/C LIQ SOL VAL	TC	2	561030	560997
C97	RR ROOF AUX. A/C SHUT SOL VAL	AMPHENOL	2	-----	560412
C98	CONDENSER CPT.	ITT SS	4	561998	561999
C101	CONDENSER CPT.-A/C PRESS. SW	PED WP	2	561566	561690
C105	UNDER DASH RH-DRV LIQ SOL VL	TC	2	561030	560997
C106	UNDER DASH RH-DRV WTR VALVE	TC	2	561030	560997
C107	UNDER DASH RH-DRV HTR RH FAN	TC	2	561030	560997
C108	UNDER DASH RH-DRV HTR LH FAN	TC	2	561030	560997

NO.	LOCATION	TYPE	(NB) CAVITY	*PIN HOUSING	*SOCKET HOUSING
C111	LH CONSOLE SW-DRIVER'LTS	SWF	8	-----	561107
C112	LH CONSOLE SW-GENERAL LTS	SWF	8	-----	561107
C114	ENGINE DDEC-SPEED SIGNAL	PED WP	2	561566	561590
C115	RR JCT BOX-ENGINE ACCES.	DEUTSCH	40	562281	562284
C116	DRIVE AXLE COMPT.-AIR DRYER	PED MP	2	-----	562251
C119	ENGINE COMPT.-LH LOWER LAMP	PED WP	6	561606	561607
C120	ENGINE COMPT.-LH LOWER LAMP	PED WP	6	561606	561607
C123	HAT RACK-BALLAST RH	AMP MNL	6	561552	561515
C124	HAT RACK-FLUORESCENT	AMP MNL	4	561551	561668
C125	HAT RACK-FLUORESCENT	AMP MNL	4	561551	561668
C126	HAT RACK-READING LTS	AMP MNL	2	560900	560898
C130	LH CONSOLE SW-READING LTS	SWF	8	-----	561107
C131	LH CONSOLE SW-LUG.DOOR LOCK	SWF	8	-----	561107
C132	LH CONSOLE SW-PAS & HOS CHIME	SWF	8	-----	561107
C133	LH CONSOLE SW-JACOB OR RET.	SWF	8	-----	561107
C134	LH CONSOLE SW-GALLEY	SWF	8	-----	561107
C135	LH SW PANEL-ETHER	SWF	8	-----	561107
C136	LH CONSOLE SW-MIRROR HTR	SWF	8	-----	561107
C137	RH SW PANEL-HEAD LAMP	SWF	8	-----	561107
C138	RH SW PANEL-SPARE	SWF	8	-----	561107
C139	RH SW PANEL-FOG LAMP	SWF	8	-----	561107
C140	FR JCT PANEL-BAT. HI/LO	AMP MNL	2	560900	560898
C141	ENGINE COMPT.-B/UP ALARM	PED WP	2	561566	561590
C142	FR SERVICE CPT-LH MARKER LTS	ITT SS	3	561111	561080
C143	RR LH HAT RACK-FEEDING	AMP MNL	9	561661	561662
C144	RR RH HAT RACK-FEEDING	AMP MNL	9	561661	561662
C145	RH HAT RACK-BALLAST	AMP MNL	4	560851	560852
C146	FR SERVICE CPT-RH MARKER LTS	ITT SS	3	561111	561080
C147	RR ROOF LH-EMERGENCY EXIT LTS	AMP MNL	2	560900	560898
C148	RR ROOF RH-EMERGENCY EXIT LTS	AMP MNL	2	560900	560898
C149	LH HAT RACK-BALLAST	AMP MNL	4	560851	560852
C150	FR RH HAT RACK-110V FLUOR	AMP MNL	2	561248	561247
C151	FR LH HAT RACK-110V FLUOR	AMP MNL	2	561248	561247
C152	LH HAT RACK-GENERAL LTS	AMP MNL	3	561667	561550
C153	RH HAT RACK-GENERAL LTS	AMP MNL	3	561667	561550
C154	RH SW PANEL-HAZARD	SWF	8	-----	561107
C155	LH SW PANEL-FAST IDLE	SWF	8	-----	561107
C156	LH SW PANEL-STP ENG. OVER.	SWF	8	-----	561107
C158	RR ROOF AUX. A/C FEEDING	AMP MNL	3	561667	561550
C160	FR SERVICE CPT-INTERFACE	AMP CPC	37	561644	561646
C161	ENGINE DDEC III-ECM	PED	30	-----	561600
C162	ENGINE DDEC III-ACCESSORIES	PED WP	4	561610	561611
C163	ENGINE CPT-COOLANT PROBE	PED MP	2	-----	562350
C164	FR SERVICE JCT BOX	AMP CPC	22	561709	561710
C165	FR SERVICE JCT BOX	AMP CPC	16	561693	561695
C166	UNDER INSTRUMENT PANEL	AMP CPC	16	561639	561640
C167	FR SERVICE CPT-EL. FOOT PEDAL	PED WP	3	561781	561782
C168	FR SERVICE CPT-DDR	DEUTSCH	6	562360	-----
C169	FR SERVICE CPT-WORLD TR. VIW	AMP CPC	16	561638	561640
C172	ENGINE COMPT-WATER TANK HEAT.	PED WP	2	561566	561690
C173	LAV.PORTABLE-WATER TANK HEAT.	AMP MNL	2	560900	560898
C175	FR SERV CPT-KNEELING FEEDING	PED WP	3	561781	561782
C177	GALLEY-REFRIGERATOR	AMP MNL	2	561248	561247

NO.	LOCATION	TYPE	(NB) CAVITY	*PIN HOUSING	*SOCKET HOUSING	NO.	LOCATION	TYPE	(NB) CAVITY	*PIN HOUSING	*SOCKET HOUSING	
C179	RH HAT RACK-110V MONITOR	MOLEX	4	561477	561476							PRIOR REV. 010
C180	FR SERV CPT-KNEEL. DIODE	AMP MNL	9	561670	561699	C243	DRIVE AXLE CPT-ABS LH VALVE	WABCO	3	-----	641098	
C181	FR SERV CPT-KNEELING MODULE	AMP MNL	12	561735	561734	C244	DRIVE AXLE CPT-ABS RH VALVE	WABCO	3	-----	641098	
C182	FR SERVICE CPT-SPEED SW	AMP HDP	15	-----	562012	C245	DRIVE AXLE CPT-ABS RH SENSOR	WABCO	2	641132	-----	PROIR S570
C184	FR SERV CPT-KNEEL. MOD. CTRL	AMP MNL	3	-----	561550	C245	DRIVE AXLE CPT-ABS RH SENSOR	DEUTSCH	2	562486	562485	EFF. W/S570
C184	FR AXLE-KNEELING PROXIMITY SW	AMP MNL	3	561667	561550	C246	DRIVE AXLE CPT-ABS SPARE	PED WP	4	561610	561611	
C185	FR SERV CPT-KNEEL. MOD. EXH.	AMP MNL	3	-----	561550	C247	FR SERVICE CPT-ABS MODULE	WABCO	35	-----	561094	
C187	FR SERV CPT-KNEEL. MOD. BRK	AMP MNL	3	-----	561550	C248	DRIVE AXLE CPT-ABS	PED WP	6	561606	561607	
C187	FR SERVICE JCT BOX-RESISTORS	AMP MNL	6	561552	561515	C249	FR SERVICE CPT-ABS/DDEC	PED WP	2	561566	561690	
C188	LH CONSOLE SW-KNEELING	SWF	8	-----	561107	C250	RH SW PANEL-B/UP CANCEL	SWF	8	-----	561107	
C190	FR SERVICE CPT.-WORLD TR VIM	PED WP	30	-----	561600	C251	RH SW PANEL-SEAT HTR	SWF	8	-----	561107	
C192	GALLEY-FEEDING	AMP CPC	3	561862	561847	C252	LH SW PANEL-SWITCH LT	SWF	2	-----	561837	
C194	GALLEY SW-CONTAINER RH	SWF	8	-----	561107	C254	FR SERVICE JCT BOX-ABS	AMP CPC	16	561693	561695	
C195	GALLEY SW-CONTAINER LH	SWF	8	-----	561107	C255	RH CONSOLE-RADIO	AMP MNL	9	561670	561669	PRIOR REV 010
C199	FR SERV. JCT BOX-SERVICE BRK	AMP MNL	3	561667	561550	C257	ENGINE COMPT-WATER HEATER	AMP FF	6	-----	561186	
C200	LH CONSOLE SW-24V FLUOR	SWF	8	-----	561107	C258	DRIVER GUARD WATER HTR TIMER	AMP FF	8	561188	562363	
C201	UNDER INSTRUMENT PANEL	AMP MNL	2	560900	560898	C259	ENGINE COMPT-WATER HEATER	TC	2	561597	-----	
C202	UNDER INSTRUMENT PANEL	AMP CPC	9	561636	561637	C260	ENGINE COMPT-WATER HEATER	TC	1	561073	-----	
C205	LH UNDER DASH-AMPLIF. LH SPK	BLAUPUNKT	2	561988	-----	C261	ENGINE COMPT-WATER HEATER	TC	2	561597	-----	
C206	RH CONSOLE-FR DEFROSTER	TC	2	561030	560997	C266	BATTERY COMPT. LTS	AMP MNL	2	561248	561247	
C207	RH CONSOLE-DRV RHEOSTAT	AMP MNL	6	561552	561515	C267	LUGGAGE COMPT. LTS - 1	AMP MNL	2	561248	561247	
C208	UNDER DASH-DRV HTR MODULE	AMP MNL	9	561670	561669	C268	LUGGAGE COMPT. LTS - 2	AMP MNL	2	561248	561247	
C209	UNDER DASH-DRV HTR MODULE	AMP MNL	9	561670	561669	C269	LUGGAGE COMPT. LTS - 3 RH	AMP MNL	2	561248	561247	
C210	LH UNDER DASH-AMPLIF. LH SPK	BLAUPUNKT	2	561988	-----	C270	LUGGAGE COMPT. LTS - 3 LH	AMP MNL	2	561248	561247	
C211	RH CONSOLE-VCR VOLUME	AMP MNL	4	561551	561668	C271	LUGGAGE COMPT. LTS - 4	AMP MNL	2	561248	561247	
C212	LH CONSOLE SW-VCR VIDEO	SWF	8	-----	561107	C272	FR SERVICE CPT LTS	AMP MNL	2	561248	561247	
C213	FR ROOF-CLEARANCE LT	AMP MNL	2	560900	560898	C274	FR JCT PANEL-DIODES	AMP MNL	15	561987	561986	
C214	UNDER DASH PANEL-TACHOGRAPH	V.D.O.	8	-----	562041	C276	FR JCT PANEL-ALARM BUZZER	BOSCH	5	-----	561183	
C215	UNDER DASH PANEL-TACHOGRAPH	V.D.O.	8	-----	562043	C281	LH CONSOLE- FR. DEST. SIGN	SWF	2	-----	561837	
C216	UNDER DASH PANEL-TACHOGRAPH	AMP MNL	4	560851	560852	C282	FR. ROOF- DEST. SIGN	AMP CPC	9	561636	561637	
C217	FR LH HAT RACK-SPEAKER	AMP MNL	4	561659	561660	C290	LUGGAGE CPT-DOOR LOCK	AMP MNL	4	560851	560852	
C218	FR RH HAT RACK-SPEAKER	AMP MNL	4	561659	561660	C291	LUGGAGE CPT-DOOR LOCK	AMP MNL	4	560851	560852	
C219	DASH RHEOSTAT-P.A. VOLUME	MOLEX	4	561477	561476	C292	LUGGAGE CPT-DOOR LOCK	AMP MNL	4	560851	560852	
C220	LH UNDER DASH-P.A. VOLUME	AMP MNL	3	561667	561550	C293	WIPER MOTOR	AMP FF	6	-----	561186	
C221	LH UNDER DASH-AMPLIFIER FEED	AMP MNL	3	561550	561667	C294	UNDER DASH-WIPER SYST. FEED	AMP MNL	6	561552	561515	
C222	LH UNDER DASH-P.A. RADIO	AMP MNL	9	561670	561669	C295	UNDER DASH-WIPER PULSE GEN.	AMP FF	6	-----	561186	PRIOR REV 010
C223	LH UNDER DASH-P.A. RADIO	AMP MNL	9	561670	561669	C296	FR SERVICE CPT-HEAD LTS	ITT SS	3	561111	561080	PRIOR REV 010
C224	LH UNDER DASH-PA & RADIO FEED	AMP MNL	6	561552	561515	C298	FR LH HAT RACK-AMPLI	MOLEX	6	-----	562464	PRIOR REV 010
C225	LH UNDER DASH-PA MICRO OUTLET	AMP MNL	3	561667	561550	C299	FR LH HAT RACK-AMPLI	MOLEX	10	-----	562465	PRIOR REV 010
C226	LH UNDER DASH-PA MICRO OUTLET	AMP MNL	3	561667	561550	C300	FR LH HAT RACK-AMPLI	MOLEX	6	-----	562464	
C227	RH CONSOLE-SPEAKER CONTROL SW	SWF	8	-----	561107	C301	FR LH HAT RACK-AMPLI	MOLEX	10	-----	562465	
C229	LH UNDER DASH-PA DRV SPEAKERS	AMP MNL	4	561551	561668	C302	UNDER DASH-FLASHER MODULE	AMP MNL	2	560900	560898	
C230	ENG.CPT.-FUEL PRIME PUMP SW.	PED WP	2	561566	561690	C309	ENGINE DDEC III-ECM POWER	PED WP	5	-----	562345	
C231	ENG.CPT.-FUEL PRIME PUMP	PED WP	2	561566	561690	C312	ENGINE DDEC III-ECM SIGNAL	PED WP	3	561781	561782	
C232	UNDER L.H. CONSOLE	MOLEX	4	561477	561476	C313	ENGINE DDEC III-OUTPUT	PED WP	4	562398	-----	
C233	MICRO OUTLET SOCKET	MOLEX	4	561477	561476	C314	FR SERVICE CPT-PRESS SW KNEEL	PED WP	2	561566	561690	
C234	UNDER INSTRUMENT PANEL-VDO	AMP MNL	4	560851	560852	C315	FR SERVICE CPT-KNEEL ALARM	PED WP	2	561566	561690	
C234	UNDER INSTRUMENT PANEL-VDO	AMP FF	8	-----	562363	C316	FR SERVICE CPT-KNEEL ALARM	AMP MNL	2	560900	560898	
C235	UNDER INSTRUMENT PANEL-VDO	AMP MNL	4	560851	560852	C326	ENGINE DDEC III- MANUAL TR.	PED WP	4	561610	561611	
C235	UNDER INSTRUMENT PANEL-VDO	AMP FF	8	-----	562363	C364	FR ROOF-DESTINATION SIGN	AMP MNL	3	561667	561550	
C236	FR SERVICE CPT CENTER-ABS	AMP CPC	14	561585	561583	C365	FR ROOF-DESTINATION SIGN	AMP MNL	2	560900	560898	
C237	FR AXLE CPT-ABS RH SENSOR	WABCO	2	641132	-----	C368	FR ROOF-DEST. SIGN BALLAST	AMP MNL	3	561667	561550	
C238	FR AXLE CPT-ABS RH VALVE	WABCO	3	-----	641098	C369	FR ROOF-DEST. SIGN OPER. SW.	TORRIX	5	-----	562110	
C239	FR AXLE CPT-ABS LH VALVE	WABCO	3	-----	641098	C370	FR ROOF-DEST. SIGN FLUOR.	AMP MNL	2	560900	560898	
C240	FR AXLE CPT-ABS LH SENSOR	WABCO	2	641132	-----	C371	FR ROOF-DEST. SIGN FLUOR.	AMP MNL	2	560900	560898	
C241	DRIVE AXLE CPT-ABS	PED WP	6	561606	561607	C372	FR ROOF-DEST. SIGN SPEED SW.	MOLEX	4	561477	561476	
C242	DRIVE AXLE CPT-ABS LH SENSOR	DEUTSCH	2	562486	562485							

NO.	LOCATION	TYPE	(NB) CAVITY	*PIN HOUSING	*SOCKET HOUSING
C382	ENGINE GENERATOR 12 VAC RLY	PED WP	1	561605	561577
C383	LH UNDER DASH-MICRO W/O WIRE	AMP MNL	2	561248	561247 PRIOR REV. 010
C384	LH UNDER DASH-MICRO W/O WIRE	AMP MNL	3	561550	561667 PRIOR REV. 010
C385	BATTERY COMPT. ACC.	AMP MNL	12	561735	561734
C386	CONDENSER CPT-BYPASS VALVE	PED WP	2	561566	561590
C387	EVAPORATOR CPT-BYPASS VALVE	PED WP	2	561566	561590
C388	LH SW PANEL-MASTER SW	SWF	8	-----	561107
C389	EVAPORATOR CPT-WATER PUMP	PED WP	2	561566	561590
C390	CONDENSER CPT.-A/C JCT BOX	DEUTSCH	24	562280	562283
C391	CONDENSER CPT.-PRESS.SW	PED WP	2	561566	561590
C392	CONDENSER CPT.- MOTOR FAN	PED WP	2	561566	561590
C393	CONDENSER CPT.- MOTOR FAN	PED WP	2	561566	561590
C394	LH OVER CONSOLE- B/U MONITOR	AMP MNL	4	560851	560852
C395	LH OVER CONSOLE- B/U MONITOR	AMP MNL	5	-----	-----
C396	CONDENSER CPT.- MOTOR FAN	PED WP	2	561566	561590
C396	HAT RACK SPEAKER	MOLEX	4	562507	562503
C397	CONDENSER CPT.- MOTOR FAN	PED WP	2	561566	561590
C421	ENGINE CPT. WEBASTO WATER HTR	AMP FF	2	562474	562473
C422	ENGINE CPT. WEBASTO WATER HTR	PED	2	562644	561597
C426	ENGINE S60 RAD. FAN CLUTCH	PED WP	3	561781	561782
C430	DRIVER GUARD WATER HTR TIMER	AMP FF	8	561188	562363
C450	SOUND SYS. JCT. PANEL	MOLEX	4	562507	562503
C451	WIRELESS MICRO-FIRST CPT BAG	MOLEX	2	562550	562549
C452	UNDER DASH INSTR. PANEL	MOLEX	2	562550	562549
C453	SOUND SYS. JCT.PANEL-VCP	PED WP	2	561566	561590
C454	SOUND SYS.JCT.PAN.-FILT. VCP	PED WP	2	561566	561590
C455	WIRELESS MICRO-LH HAT-RACK	CINCH	2	562554	562551
C456	WORLD TRANSM.-RETARDER ACCUM.	PED MP	2	-----	562427
C457	WORLD TRANSM.-MAIN CONNECTOR	DEUTSCH	31	562572	562536
C458	WORLD TRANSM.-TURBINE SP.SENS	PED MP	2	-----	562426
C459	WORLD TRANSM.-ENGINE SP.SENS.	PED MP	2	-----	562426
C460	WORLD TRANSM.-SPEED SENSOR	ITT	2	-----	562541
C461	WORLD TRANSM.-RETARDER TEMP.	PED MP	2	561566	561590
C462	WORLD TRANSM.-RETARD SOL."K"	PED MP	2	-----	562426
C463	WORLD TRANSM.-SENSOR CONN.	DEUTSCH	16	562570	562571
C464	FR SERVICE CPT.-DDL CONN W.T.	PED MP	12	-----	562574
C465	LH CONSOLE-SHIFTER SELECTOR	T & BET	10	-----	562429
C466	FR SERVICE CPT.-RESIS. MOD.	PED WP	3	-----	562428
C467	FR SERVICE CPT.-RESIS. MOD.	PED WP	3	-----	562428
C468	FR SERVICE CPT.-VIM MOD. W.T.	PED MP	18	-----	562573
C470	FR SERVICE CPT.-SILENT 1000	AMP MNL	2	561248	561247
C471	FR SERVICE CPT.-SILENT 1000	AMP MNL	2	561248	561247
C472	FR SERVICE CPT.-SILENT 1000	PED WP	2	561566	561690
C473	FR SERVICE CPT.-SILENT 1000	AMP MNL	3	561667	561550
C475	FR SERVICE CPT-SPEED SIGN CON	DEUTSCH	6	-----	562581
C475M	FR SERVICE CPT-SPEED SIGN M.T	DEUTSCH	6	562583	-----
C475W	FR SERVICE CPT-SPEED SIGN W.T	DEUTSCH	6	562583	-----
C500	FR JCT PANEL-PRODRIVER	MOLEX	6	562070	562069
C501	RH CONSOLE-PRODRIVER	PED MP	7	562433	-----
C502	DRIVER GUARD PRE-HTR SW.	SWF	8	-----	561107
C503	DRIVER GUARD PRE-HTR SW.	SWF	2	-----	561837
C504	DRIVER GUARD WEBASTO TIMER	AMP FF	8	561188	562363
C505	DRIVER GUARD ESPAR TIMER	AMP FF	3	-----	562034
C508	RR JCT BOX-FAN CLUTCH MOD	AMP MNL	6	561552	561515
C510	FR SERVICE CPT-RESIST.RUN LTS	PED MP	2	561566	561690
C544	SOUND SYS.JCT.PANEL-SEET AUD.	PED WP	3	561781	561782
CA	FR SERVICE CPT-ECU WORLD TR.	T & BET	34	-----	562419
CB	FR SERVICE CPT-ECU WORLD TR.	T & BET	34	-----	562420

NO.	LOCATION	TYPE	(NB) CAVITY	*PIN HOUSING	*SOCKET HOUSING
C541	SOUND SYS.JCT.PANEL-AUDIO SEAT SYS.	PED WP	2	561566	561690
C542	LH HAT RACK-AUDIO SEAT SYSTEM	AMP MNL	2	561667	561550
C545	LH HAT RACK-AUDIO SEAT SYSTEM	AMP MNL	2	561667	561550
WEB1	ENGINE CPT. WEBASTO WATER HTR	AMP FF	2	562474	562643
WEB2	ENGINE CPT. WEBASTO WATER HTR	AMP FF	2	562474	562643