

NO.	LOCATION	TYPE	(NB) CAVITY	*PIN HOUSING	*SOCKET HOUSING
C3	UNDER DASH-LH	AMP CPC	37	561645	561646
C7	FR SERVICE COMPT.-CLUTCH SW	ITT SS	3	561111	561080
C8	FR JCT PANEL VCR FEED	AMP MNL	2	561248	561247 PRIOR REV 010
C11	LH CONSOLE SW-MIRROR	AMP MNL	3	561667	561550
C12	LH CONSOLE SW-MIRROR HTR	AMP MNL	2	561248	561247
C13	LH CONSOLE SW-MIRROR	AMP MNL	6	561552	561515
C14	UNDER DASH LH-MIRROR	AMP MNL	9	561670	561669
C15	UNDER DASH RH-MIRROR	AMP MNL	9	561670	561669
C18	UNDER DASH-FIRE ALARM	AMP MNL	2	560900	560898
C19	UNDER DASH-A/C & HEAT SYST.	TC	10	561072	561110
C20	RR JCT BOX DIODES	AMP MNL	9	561670	561669
C21	LUGGAGE COMPT.-LOCK DOOR MOT.	PED	2	-----	562076
C22	ENGINE COMPT.-CYCLOP LT	PED WP	2	561566	561690
C26	UNDER INSTRUMENT.-PANEL RHEO.	TC	2	561030	560997
C29	FR SERVICE COMPT.-VIM FEED	PED WP	3	561781	561782
C32	RH CONSOLE-DRV TEMP SENSOR	BURNDY	3	-----	561104
C33	FRSERVICE COMPT. DDEC VSS	PED WP	2	561566	561690
C34	RH CONSOLE-DRV TEMP CTRL	BURNDY	6	-----	561103
C35	RECIRULATED AIR GRIL.-SENSER	BURNDY	3	-----	561104
C36	LH CONSOLE SW-CRUISE ON/OFF	SWF	8	-----	561107
C37	LH CONSOLE SW-CRUISE SET	SWF	8	-----	561107
C38	LH CONSOLE SW-CRUISE RESUME	SWF	8	-----	561107
C41	UNDER DASH-FLASHER UNIT	TC	2	-----	561940
C49	LAVATORY NIGHT LTS	AMP MNL	2	560900	560898
C50	RH CONSOLE-PAS. TEMP CTRL	BURNDY	6	-----	561103
C51	RH CONSOLE SW-A/C & HEAT	SWF	8	-----	561107
C52	ENGINE COMPT.-COMPRESSOR 05G	PED WP	2	561566	561690
C53	ENGINE COMPT.-COMPRESSOR 05G	PED WP	2	561566	561690
C54	ENGINE COMPT.-COMPRESSOR 05G	TC	1	560098	560697
C61	ENGINE COMPT.-FUEL FILTER	PED WP	2	561566	561690
C65	UNDER LH HAT RACK	MOLEX	4	561477	561476
C67	LH UNDER DASH-AMPLIF. RH SPK	BLAUPUNKT	2	561988	-----
C68	LH UNDER DASH-AMPLIF. RH SPK	BLAUPUNKT	2	561988	-----
C73	LH SW PANEL-MULTI FUNC. LEV.	AMP FF	8	561188	-----
C74	LH SW PANEL-MULTI FUNC. LEV.	AMP FF	6	-----	561108
C78	LUGGAGE COMPT.-DOOR LOCK 4 LH	AMP MNL	4	560851	560852
C79	LUGGAGE COMPT.-DOOR LOCK 4 RH	AMP MNL	4	560851	560852
C80	FR JCT PANEL-LUG. DOOR LOCK	AMP MNL	6	561552	561515
C81	LUGGAGE COMPT.-DOOR LOCK 1 LH	AMP MNL	4	560851	560852
C82	LUGGAGE COMPT.-DOOR LOCK 1 RH	AMP MNL	4	560851	560852
C83	UNDER DASH-FLASHER MODULE	TC	10	561072	561110
C84	UNDER DASH-A/C SYSTEM	TC	3	561091	561071
C85	LUGGAGE COMPT.-DOOR LOCK 3 RH	AMP MNL	4	560851	560852
C86	LUGGAGE COMPT.-DOOR LOCK 3 LH	AMP MNL	4	560851	560852
C88	RR END ROOF-CLEARANCE LTS	AMP MNL	2	560900	560898
C90	RR ROOF AUX. A/C THERMOST.	BURNDY	6	-----	561103
C91	RR ROOF AUX. A/C TMP SENSOR	BURNDY	6	-----	561104
C92	RR ROOF AUX. A/C FAN RH	TC	2	561030	560997
C93	RR ROOF AUX. A/C FAN LH	TC	2	561030	560997
C94	RR ROOF AUX. A/C FAN RES LH	AMP MNL	2	560900	560898
C95	RR ROOF AUX. A/C FAN RES RH	AMP MNL	2	560900	560898
C96	RR ROOF AUX. A/C LIQ SOL VAL	TC	2	561030	560997
C97	RR ROOF AUX. A/C SHUT SOL VAL	AMPHENOL	2	-----	560412
C98	CONDENSER CPT.	ITT SS	4	561998	561999
C101	CONDENSER CPT.-A/C PRESS. SW	PED WP	2	561566	561690
C105	UNDER DASH RH-DRV LIQ SOL VL	TC	2	561030	560997
C106	UNDER DASH RH-DRV WTR VALVE	TC	2	561030	560997
C107	UNDER DASH RH-DRV HTR RH FAN	TC	2	561030	560997
C108	UNDER DASH RH-DRV HTR LH FAN	TC	2	561030	560997

NO.	LOCATION	TYPE	(NB) CAVITY	*PIN HOUSING	*SOCKET HOUSING
C111	LH CONSOLE SW-DRIVER LTS	SWF	8	-----	561107
C112	LH CONSOLE SW-GENERAL LTS	SWF	8	-----	561107
C114	ENGINE DDEC-SPEED SIGNAL	PED WP	2	561566	561590
C115	RR JCT BOX-ENGINE ACCES.	DEUTSCH	40	562281	562284
C116	DRIVE AXLE COMPT.-AIR DRYER	PED MP	2	-----	562251
C119	ENGINE COMPT.-LH LOWER LAMP	PED WP	6	561606	561607
C120	ENGINE COMPT.-LH LOWER LAMP	PED WP	6	561606	561607
C123	HAT RACK-BALLAST RH	AMP MNL	6	561552	561515
C124	HAT RACK-FLUORESCENT	AMP MNL	4	561551	561668
C125	HAT RACK-FLUORESCENT	AMP MNL	4	561551	561668
C126	HAT RACK-READING LTS	AMP MNL	2	560900	560898
C130	LH CONSOLE SW-READING LTS	SWF	8	-----	561107
C131	LH CONSOLE SW-LUG.DOOR LOCK	SWF	8	-----	561107
C132	LH CONSOLE SW-PAS & HOS CHIME	SWF	8	-----	561107
C133	LH CONSOLE SW-JACOB OR RET.	SWF	8	-----	561107
C134	LH CONSOLE SW-GALLEY	SWF	8	-----	561107
C135	LH SW PANEL-ETHER	SWF	8	-----	561107
C136	LH CONSOLE SW-MIRROR HTR	SWF	8	-----	561107
C137	RH SW PANEL-HEAD LAMP	SWF	8	-----	561107
C138	RH SW PANEL-SPARE	SWF	8	-----	561107
C139	RH SW PANEL-FOG LAMP	SWF	8	-----	561107
C140	FR JCT PANEL-BAT. HI/LO	AMP MNL	2	560900	560898
C141	ENGINE COMPT.-B/UP ALARM	PED WP	2	561566	561590
C142	FR SERVICE CPT-LH MARKER LTS	ITT SS	3	561111	561080
C143	RR LH HAT RACK-FEEDING	AMP MNL	9	561661	561662
C144	RR RH HAT RACK-FEEDING	AMP MNL	9	561661	561662
C145	RH HAT RACK-BALLAST	AMP MNL	4	560851	560852
C146	FR SERVICE CPT-RH MARKER LTS	ITT SS	3	561111	561080
C147	RR ROOF LH-EMERGENCY EXIT LTS	AMP MNL	2	560900	560898
C148	RR ROOF RH-EMERGENCY EXIT LTS	AMP MNL	2	560900	560898
C149	LH HAT RACK-BALLAST	AMP MNL	4	560851	560852
C150	FR RH HAT RACK-110V FLUOR	AMP MNL	2	561248	561247
C151	FR LH HAT RACK-110V FLUOR	AMP MNL	2	561248	561247
C152	LH HAT RACK-GENERAL LTS	AMP MNL	3	561667	561550
C153	RH HAT RACK-GENERAL LTS	AMP MNL	3	561667	561550
C154	RH SW PANEL-HAZARD	SWF	8	-----	561107
C155	LH SW PANEL-FAST IDLE	SWF	8	-----	561107
C156	LH SW PANEL-STP ENG. OVER.	SWF	8	-----	561107
C158	RR ROOF AUX. A/C FEEDING	AMP MNL	3	561667	561550
C160	FR SERVICE CPT-INTERFACE	AMP CPC	37	561644	561646
C161	ENGINE DDEC III-ECM	PED	30	-----	561600
C162	ENGINE DDEC III-ACCESSORIES	PED WP	4	561610	561611
C163	ENGINE CPT-COOLANT PROBE	PED MP	2	-----	562350
C164	FR SERVICE JCT BOX	AMP CPC	22	561709	561710
C165	FR SERVICE JCT BOX	AMP CPC	16	561693	561695
C166	UNDER INSTRUMENT PANEL	AMP CPC	16	561639	561640
C167	FR SERVICE CPT-EL. FOOT PEDAL	PED WP	3	561781	561782
C168	FR SERVICE CPT-DDR	DEUTSCH	6	562360	-----
C169	FR SERVICE CPT-WORLD TR. VIW	AMP CPC	16	561638	561640
C172	ENGINE COMPT-WATER TANK HEAT.	PED WP	2	561566	561690
C173	LAV.PORTABLE-WATER TANK HEAT.	AMP MNL	2	560900	560898
C175	FR SERV CPT-KNEELING FEEDING	PED WP	3	561781	561782
C177	GALLEY-REFRIGERATOR	AMP MNL	2	561248	561247

NO.	LOCATION	TYPE	(NB) CAVITY	*PIN HOUSING	*SOCKET HOUSING	
C179	RH HAT RACK-110V MONITOR	MOLEX	4	561477	561476	PRIOR REV. 010
C180	FR SERV CPT-KNEEL. DIODE	AMP MNL	9	561670	561699	
C181	FR SERV CPT-KNEELING MODULE	AMP MNL	12	561735	561734	
C182	FR SERVICE CPT-SPEED SW	AMP HDP	15	-----	562012	
C184	FR SERV CPT-KNEEL. MOD. CTRL	AMP MNL	3	-----	561550	
C184	FR AXLE-KNEELING PROXIMITY SW	AMP MNL	3	561667	561550	
C185	FR SERV CPT-KNEEL. MOD. EXH.	AMP MNL	3	-----	561550	
C187	FR SERV CPT-KNEEL. MOD. BRK	AMP MNL	3	-----	561550	
C187	FR SERVICE JCT BOX-RESISTORS	AMP MNL	6	561552	561515	
C188	LH CONSOLE SW-KNEELING	SWF	8	-----	561107	
C190	FR SERVICE CPT.-WORLD TR VIM	PED WP	30	-----	561600	
C192	GALLEY-FEEDING	AMP CPC	3	561862	561847	
C194	GALLEY SW-CONTAINER RH	SWF	8	-----	561107	
C195	GALLEY SW-CONTAINER LH	SWF	8	-----	561107	
C196	FR SERV CPT-KNEEL.	PED	2	561566	561690	
C197	FR SERV CPT-KNEEL.	PED	2	561566	561690	
C199	FR SERV. JCT BOX-SERVICE BRK	AMP MNL	3	561667	561550	
C200	LH CONSOLE SW-24V FLUOR	SWF	8	-----	561107	
C201	UNDER INSTRUMENT PANEL	AMP MNL	2	560900	560898	PRIOR REV. 010
C202	UNDER INSTRUMENT PANEL	AMP CPC	9	561636	561637	
C205	LH UNDER DASH-AMPLIF. LH SPK	BLAUPUNKT	2	561988	-----	
C206	RH CONSOLE-FR DEFROSTER	TC	2	561030	560997	
C207	RH CONSOLE-DRV RHEOSTAT	AMP MNL	6	561552	561515	
C208	UNDER DASH-DRV HTR MODULE	AMP MNL	9	561670	561669	
C209	UNDER DASH-DRV HTR MODULE	AMP MNL	9	561670	561669	
C210	LH UNDER DASH-AMPLIF. LH SPK	BLAUPUNKT	2	561988	-----	
C211	RH CONSOLE-VCR VOLUME	AMP MNL	4	561551	561668	PRIOR REV. 010
C212	LH CONSOLE SW-VCR VIDEO	SWF	8	-----	561107	PRIOR REV. 010
C213	FR ROOF-CLEARANCE LT	AMP MNL	2	560900	560898	
C214	UNDER DASH PANEL-TACHOGRAPH	V.D.O.	8	-----	562041	
C215	UNDER DASH PANEL-TACHOGRAPH	V.D.O.	8	-----	562043	
C216	UNDER DASH PANEL-TACHOGRAPH	AMP MNL	4	560851	560852	
C217	FR LH HAT RACK-SPEAKER	AMP MNL	4	561659	561660	
C218	FR RH HAT RACK-SPEAKER	AMP MNL	4	561659	561660	
C219	DASH RHEOSTAT-P.A. VOLUME	MOLEX	4	561477	561476	PRIOR REV. 010
C220	LH UNDER DASH-P.A. VOLUME	AMP MNL	3	561667	561550	PRIOR REV. 010
C221	LH UNDER DASH-AMPLIFIER FEED	AMP MNL	3	561550	561667	PRIOR REV. 010
C222	LH UNDER DASH-P.A. RADIO	AMP MNL	9	561670	561669	PRIOR REV. 010
C223	LH UNDER DASH-P.A. RADIO	AMP MNL	9	561670	561669	PRIOR REV. 010
C224	LH UNDER DASH-PA & RADIO FEED	AMP MNL	6	561552	561515	PRIOR REV. 010
C225	LH UNDER DASH-PA MICRO OUTLET	AMP MNL	3	561667	561550	PRIOR REV. 010
C226	LH UNDER DASH-PA MICRO OUTLET	AMP MNL	3	561667	561550	PRIOR REV. 010
C227	RH CONSOLE-SPEAKER CONTROL SW	SWF	8	-----	561107	PRIOR REV. 010
C229	LH UNDER DASH-PA DRV SPEAKERS	AMP MNL	4	561551	561668	PRIOR REV. 010
C230	ENG.CPT.-FUEL PRIME PUMP SW.	PED WP	2	561566	561690	
C231	ENG.CPT.-FUEL PRIME PUMP	PED WP	2	561566	561690	
C232	UNDER L.H. CONSOLE	MOLEX	4	561477	561476	PRIOR REV. 010
C233	MICRO OUTLET SOCKET	MOLEX	4	561477	561476	PRIOR REV. 010
C234	UNDER INSTRUMENT PANEL-VDO	AMP MNL	4	560851	560852	PRIOR REV. 010
C234	UNDER INSTRUMENT PANEL-VDO	AMP FF	8	-----	562363	
C235	UNDER INSTRUMENT PANEL-VDO	AMP MNL	4	560851	560852	PRIOR REV. 010
C235	UNDER INSTRUMENT PANEL-VDO	AMP FF	8	-----	562363	
C236	FR SERVICE CPT CENTER-ABS	AMP CPC	14	561585	561583	
C237	FR AXLE CPT-ABS RH SENSOR	WABCO	2	641132	-----	
C238	FR AXLE CPT-ABS RH VALVE	WABCO	3	-----	641098	
C239	FR AXLE CPT-ABS LH VALVE	WABCO	3	-----	641098	
C240	FR AXLE CPT-ABS LH SENSOR	WABCO	2	641132	-----	
C241	LAST LUGGAGE CPT-ABS	PED WP	6	561606	561607	
C242	DRIVE AXLE CPT-ABS LH SENSOR	DEUTSCH	2	562486	562485	

NO.	LOCATION	TYPE	(NB) CAVITY	*PIN HOUSING	*SOCKET HOUSING	
C243	DRIVE AXLE CPT-ABS LH VALVE	WABCO	3	-----	641098	
C244	DRIVE AXLE CPT-ABS RH VALVE	WABCO	3	-----	641098	
C245	DRIVE AXLE CPT-ABS RH SENSOR	WABCO	2	641132	-----	PROIR S570
C245	DRIVE AXLE CPT-ABS RH SENSOR	DEUTSCH	2	562486	562485	EFF. W/S570
C246	DRIVE AXLE CPT-ABS SPARE	PED WP	4	561610	561611	
C248	LAST LUGGAGE CPT-ABS	PED WP	6	561606	561607	
C249	FR SERVICE CPT-ABS/DDEC	PED WP	2	561566	561690	
C250	RH SW PANEL-B/UP CANCEL	SWF	8	-----	561107	
C251	RH SW PANEL-SEAT HTR	SWF	8	-----	561107	
C252	LH SW PANEL-SWITCH LT	SWF	2	-----	561837	
C254	FR SERVICE JCT BOX-ABS	AMP CPC	16	561693	561695	
C255	RH CONSOLE-RADIO	AMP MNL	9	561670	561669	PRIOR REV 010
C257	ENGINE COMPT-WATER HEATER	AMP FF	6	-----	561186	
C258	DRIVER GUARD WATER HTR TIMER	AMP FF	8	561188	562363	
C259	ENGINE COMPT-WATER HEATER	TC	2	561597	-----	
C260	ENGINE COMPT-WATER HEATER	TC	1	561073	-----	
C261	ENGINE COMPT-WATER HEATER	TC	2	561597	-----	
C266	BATTERY COMPT. LTS	AMP MNL	2	561248	561247	
C267	LUGGAGE COMPT. LTS - 1	AMP MNL	2	561248	561247	
C268	LUGGAGE COMPT. LTS - 2	AMP MNL	2	561248	561247	
C269	LUGGAGE COMPT. LTS - 3 RH	AMP MNL	2	561248	561247	
C270	LUGGAGE COMPT. LTS - 3 LH	AMP MNL	2	561248	561247	
C271	LUGGAGE COMPT. LTS - 4	AMP MNL	2	561248	561247	
C272	FR SERVICE CPT LTS	AMP MNL	2	561248	561247	
C274	FR JCT PANEL-DIODES	AMP MNL	15	561987	561986	
C276	FR JCT PANEL-ALARM BUZZER	BOSCH	5	-----	561183	
C281	LH CONSOLE- FR. DEST. SIGN	SWF	2	-----	561837	
C282	FR. ROOF- DEST. SIGN	AMP CPC	9	561636	561637	
C290	LUGGAGE CPT-DOOR LOCK	AMP MNL	4	560851	560852	
C291	LUGGAGE CPT-DOOR LOCK	AMP MNL	4	560851	560852	
C292	LUGGAGE CPT-DOOR LOCK	AMP MNL	4	560851	560852	
C293	WIPER MOTOR	AMP FF	6	-----	561186	
C294	UNDER DASH-WIPER SYST. FEED	AMP MNL	6	561552	561515	
C295	UNDER DASH-WIPER PULSE GEN.	AMP FF	6	-----	561186	PRIOR REV 010
C296	FR SERVICE CPT-HEAD LTS	ITT SS	3	561111	561080	PRIOR REV 010
C298	FR LH HAT RACK-AMPLI	MOLEX	6	-----	562464	PRIOR REV 010
C299	FR LH HAT RACK-AMPLI	MOLEX	10	-----	562465	PRIOR REV 010
C300	FR LH HAT RACK-AMPLI	MOLEX	6	-----	562464	
C301	FR LH HAT RACK-AMPLI	MOLEX	10	-----	562465	
C302	UNDER DASH-FLASHER MODULE	AMP MNL	2	560900	560898	
C309	ENGINE DDEC III-ECM POWER	PED WP	5	-----	562345	
C312	ENGINE DDEC III-ECM SIGNAL	PED WP	3	561781	561782	
C313	ENGINE DDEC III-OUTPUT	PED WP	4	562398	-----	
C314	FR SERVICE CPT-PRESS SW KNEEL	PED WP	2	561566	561690	
C315	FR SERVICE CPT-KNEEL ALARM	PED WP	2	561566	561690	
C316	FR SERVICE CPT-KNEEL ALARM	AMP MNL	2	560900	560898	
C326	ENGINE DDEC III- MANUAL TR.	PED WP	4	561610	561611	
C360	ENGINE CPT.-UNLOAD TAG VALVE	PED WP	2	561566	561690	
C364	FR ROOF-DESTINATION SIGN	AMP MNL	3	561667	561550	
C365	FR ROOF-DESTINATION SIGN	AMP MNL	2	560900	560898	
C368	FR ROOF-DEST. SIGN BALLAST	AMP MNL	3	561667	561550	
C369	FR ROOF-DEST. SIGN OPER. SW.	TORRIX	5	-----	562110	
C370	FR ROOF-DEST. SIGN FLUOR.	AMP MNL	2	560900	560898	
C371	FR ROOF-DEST. SIGN FLUOR.	AMP MNL	2	560900	560898	
C372	FR ROOF-DEST. SIGN SPEED SW.	MOLEX	4	561477	561476	

NO.	LOCATION	TYPE	(NB) CAVITY	*PIN HOUSING	*SOCKET HOUSING	
C382	ENGINE GENERATOR 12 VAC RLY	PED WP	1	561605	561577	
C383	LH UNDER DASH-MICRO W/O WIRE	AMP MNL	2	561248	561247	PRIOR REV. 010
C384	LH UNDER DASH-MICRO W/O WIRE	AMP MNL	3	561550	561667	PRIOR REV. 010
C385	BATTERY COMPT. ACC.	AMP MNL	12	561735	561734	
C386	CONDENSER CPT-BYPASS VALVE	PED WP	2	561566	561590	
C387	EVAPORATOR CPT-BYPASS VALVE	PED WP	2	561566	561590	
C388	LH SW PANEL-MASTER SW	SWF	8	-----	561107	
C389	EVAPORATOR CPT-WATER PUMP	PED WP	2	561566	561590	
C390	CONDENSER CPT.-A/C JCT BOX	DEUTSCH	24	562280	562283	
C391	CONDENSER CPT.-PRESS.SW	PED WP	2	561566	561590	
C394	LH OVER CONSOLE- B/U MONITOR	AMP MNL	4	560851	560852	
C395	LH OVER CONSOLE- B/U MONITOR	AMP MNL	5	-----	-----	
C396	HAT RACK SPEAKER	MOLEX	4	562507	562503	
C421	ENGINE CPT. WEBASTO WATER HTR	AMP FF	2	562474	562473	
C422	ENGINE CPT. WEBASTO WATER HTR	PED	2	562644	561597	
C426	ENGINE S60 RAD. FAN CLUTCH	PED WP	3	561781	561782	
C430	DRIVER GUARD WATER HTR TIMER	AMP FF	8	561188	562363	
C450	SOUND SYS. JCT. PANEL	MOLEX	4	562507	562503	
C451	WIRELESS MICRO-FIRST CPT BAG	MOLEX	2	562550	562549	
C452	UNDER DASH INSTR. PANEL	MOLEX	2	562550	562549	
C453	SOUND SYS. JCT.PANEL-VCP	PED WP	2	561566	561590	
C454	SOUND SYS. JCT.PAN.-FILT. VCP	PED WP	2	561566	561590	
C455	WIRELESS MICRO-LH HAT-RACK	CINCH	2	562554	562551	
C456	WORLD TRANSM.-RETARDER ACCUM.	PED MP	2	-----	562427	
C457	WORLD TRANSM.-MAIN CONNECTOR	DEUTSCH	31	562572	562536	
C458	WORLD TRANSM.-TURBINE SP.SENS	PED MP	2	-----	562426	
C459	WORLD TRANSM.-ENGINE SP.SENS.	PED MP	2	-----	562426	
C460	WORLD TRANSM.-SPEED SENSOR	ITT	2	-----	562541	
C461	WORLD TRANSM.-RETARDER TEMP.	PED MP	2	561566	561590	
C462	WORLD TRANSM.-RETARD SOL."K"	PED MP	2	-----	562426	
C463	WORLD TRANSM.-SENSOR CONN.	DEUTSCH	16	562570	562571	
C464	FR SERVICE CPT.-DDL CONN W.T.	PED MP	12	-----	562574	PRIOR REV. 023
C464	FR SERVICE CPT.-DDL CONN W.T.	DEUTSCH	6	562360	-----	
C465	LH CONSOLE-SHIFTER SELECTOR	T & BET	10	-----	562429	PRIOR REV. 023
C465	LH CONSOLE-SHIFTER SELECTOR	PED	20	-----	562825	
C466	FR SERVICE CPT.-RESIS. MOD.	PED WP	3	-----	562428	
C467	FR SERVICE CPT.-RESIS. MOD.	PED WP	3	-----	562428	
C468	FR SERVICE CPT.-VIM MOD. W.T.	PED MP	18	-----	562573	
C470	FR SERVICE CPT.-SILENT 1000	AMP MNL	2	561248	561247	
C471	FR SERVICE CPT.-SILENT 1000	AMP MNL	2	561248	561247	
C472	FR SERVICE CPT.-SILENT 1000	PED WP	2	561566	561690	
C473	FR SERVICE CPT.-SILENT 1000	AMP MNL	3	561667	561550	
C475	FR SERVICE CPT-SPEED SIGN CON	DEUTSCH	6	-----	562581	
C475M	FR SERVICE CPT-SPEED SIGN M.T	DEUTSCH	6	562583	-----	
C475W	FR SERVICE CPT-SPEED SIGN W.T	DEUTSCH	6	562583	-----	
C500	FR JCT PANEL-PRODRIVER	MOLEX	6	562070	562069	
C501	RH CONSOLE-PRODRIVER	PED MP	7	562433	-----	
C502	DRIVER GUARD PRE-HTR SW.	SWF	8	-----	561107	
C503	DRIVER GUARD PRE-HTR SW.	SWF	2	-----	561837	
C504	DRIVER GUARD WEBASTO TIMER	AMP FF	8	561188	562363	PRIOR REV. 025
C504	DRIVER GUARD WEBASTO TIMER	AMP	8	-----	562857	
C505	DRIVER GUARD ESPAR TIMER	AMP	12	-----	562681	
C506	DRIVER SEAT RH.-HOSTESS CHIME	AMP MNL	3	561667	561550	
C508	RR JCT BOX-FAN CLUTCH MOD	AMP MNL	6	561552	561515	
C510	FR SERVICE CPT-RESIST.RUN LTS	PED MP	2	561566	561690	
C511	LH CONSOLE SW-FAN CLUTCH	SWF	8	-----	561107	

NO.	LOCATION	TYPE	(NB) CAVITY	*PIN HOUSING	*SOCKET HOUSING	
C541	SOUND SYS. JCT.PANEL-AUDIO SEAT SYS.	PED WP	2	561566	561690	
C542	LH HAT RACK-AUDIO SEAT SYSTEM	AMP MNL	3	561667	561550	
C544	SOUND SYS. JCT.PANEL-SEET AUD.	PED WP	3	561781	561782	
C545	LH HAT RACK-AUDIO SEAT SYSTEM	AMP MNL	3	561667	561550	
C553	UNDER DASH R.H. - CONTROL. HEAD	MOLEX	16	-----	562559	
C554	UNDER DASH R.H. - CONTROL. HEAD	MOLEX	16	-----	562559	
C555	UNDER DASH R.H. - CONTROL. HEAD	MOLEX	16	-----	562559	
C556	UNDER DASH R.H. - RADIO ACC.	MOLEX	2	562550	562549	
C557	UNDER DASH R.H. - RADIO ACC.	MOLEX	9	562556	562555	
C558	UNDER DASH R.H. - RADIO ACC.	MOLEX	4	562507	562503	
C559	L.H. HAT RACK - PASSENGER SPK.	MOLEX	4	562507	562503	
C560	SOUND SYS. JCT.PANEL- POW.AMPLI	MOLEX	4	562507	562503	
C561	L.H. HAT RACK- WIRELESS MICRO	MOLEX	4	562507	562503	
C562	L.H. HAT RACK - VCP	MOLEX	9	562556	562555	
C563	L.H MODESTY PANEL- DRIVERS SPK.	MOLEX	4	562507	562503	
C564	L.H MODESTY PANEL - MICRO	MOLEX	4	562507	562503	
C565	R.H MODESTY PANEL - MICRO	MOLEX	4	562507	562503	
C566	L.H. CONSOLE - BOOM MICRO	MOLEX	4	562507	562503	
C567	L.H. CONSOLE - DRIVERS MICRO	MOLEX	4	562507	562503	
C568	SOUND SYS. JCT. PANEL- PASS. SPK	CINCH	4	562553	562552	
C569	SOUND SYS. JCT.PANEL- POWER AMPLI.	MOLEX	9	562556	562555	
CS	FR SERVICE CPT-ECU WORLD TR.	PED	32	-----	562817	
CT	FR SERVICE CPT-ECU WORLD TR.	PED	32	-----	562824	
CV	FR SERVICE CPT-ECU WORLD TR.	PED	32	-----	562823	
CX1	FR SERVICE CPT-ECU ABS	AMP	18	-----	562792	
CX2	FR SERVICE CPT-ECU ABS	AMP	6	-----	562793	
CX3	FR SERVICE CPT-ECU ABS	AMP	9	-----	562794	
CX4	FR SERVICE CPT-ECU ABS	AMP	15	-----	562795	
WEB1	ENGINE CPT. WEBASTO WATER HTR	AMP FF	2	562474	562643	
WEB2	ENGINE CPT. WEBASTO WATER HTR	AMP FF	2	562474	562643	