



- SOL. CUT-OUT PNEUMATIC ACC. C586 P. 7.2
- WATER PUMP C157 P. 15.1
- DRIVER LIQ. SOL. VALVE C105 P. 15.1
- DRIVER WATER VALVE C106 P. 15.1
- PARK BRAKE PRESS. SWITCH P. 8.1
- KEYLESS ENTRY SYSTEM P. 12.1
- COIL RELAY CONTROL FR. JCT BOX
- BACK ALARM CANCEL SW. C278 P. 9.1
- 3-WAYS SW. DRIVER'S LTS P. 11.2
- SIDE FRONT FLASHER & MARKER LAMP P. 9.1
- R.H. HEADLAMP, FLASHER & MARKER P. 9.1
- L.H. HEADLAMP, FLASHER & MARKER P. 9.1
- FRONT DOCKING/CORNERING LTS P. 9.2
- SPARE NOT USED
- FOG LIGHT P. 9.3
- L.H. CENTRAL MARKER & FLASHER P. 9.1
- SPARE FOR MARKER & FLASHER ADD. (FR. LUGG.)
- L.H. CONSOLE DASH
- R.H. CENTRAL MARKER & FLASHER P. 9.1
- SPARE FOR MARKER & FLASHER ADD. (RR. LUGG.)
- WIPER'S MOTOR C176, C177 P. 10.1
- R.H. MIRROR C269, C590 P. 16.2
- DEFROSTER UNIT C480 P. 15.1
- WINDSHIELD WASHER LEVEL C96 P. 10.1
- ELECTRICAL HORN C101 P. 7.2
- DRIVER'S SEAT C483 P. 13.1
- SUN VISOR SWITCH C315, C317 P. 19.1
- L.H. MIRROR C268, C589 P. 16.2
- L.H. CONSOLE SW. C318 (P. 19.1) C591, C592 (P. 16.2)
- EVAP. FAN SPEED CONTROL DASH C428 P. 15.3
- WINDOW LIFTER OF ENTRANCE DOOR C359 P. 19.1
- LED INSIDE DASH SWITCH
- SW. DISPLAY CLUSTER C598 P. 7.1
- AUDIBLE FLASHER RELAY C424 P. 9.2
- FUEL FILTER WATER DETECT MODULE C348 P. 8.1
- TELL TALE LIGHT MODULE C570 P. 23.1
- WINDOW AJAR SWITCH P. 20.1
- HVAC DASH CONTROL C539, C540 P. 15.1
- ANTI-THEFT LED INDICATOR C381 P. 12.1
- CLUSTER LY. LX. CY P. 7.1
- LUGG. DOOR LOCK SWITCH C310 P. 12.1
- ALTERNATOR SIGNAL MODULE C43 P. 4.2
- 12 VOLTS POWER OUTLET P. 16.1

FRONT SECTION

FRONT JUNCTION BOX COMPARTMENT

FRONT JCT BLOCK

FRONT SERVICE COMPT.

- FIRE DETECTOR P. 7.2
- TAIL, B/U, FLASH., STOP LAMPS L.H. P. 9.1
- TAIL, B/U, FLASH., STOP LAMPS R.H. P. 9.1
- SMALL A/C COMPRESSOR CLUTCH C280 P. 15.1
- DRIVER'S AIR A/C PRESS. SW. C62, C63, C65 P. 15.1
- FULL AIR A/C PRESS. SW. C52, C53 P. 15.2
- 12V & 24V MASTER RELAY P. 1.1
- FUEL WATER FILTER C61 P. 8.1
- TAIL AUXILIARY LIGHTS P. 9.3
- REAR SIDE MARKERS & FLASHERS P. 9.1
- WATER PRE-HEATER C257, C259 P. 14.1
- VOLTAGE REGULATOR (DELCO ONLY) P. 4.3
- RELAY COIL & LAMP INSIDE REAR. JCT BOX
- SW. MANUAL TRANSM. (NOT USED) C326(B)
- FAN CLUTCH RELAY C508(3), R78, R79 P. 8.1
- FIRST SPEED FAN CLUTCH A/C CTRL R34 P. 15.1
- LUGG. DOOR LOCK R69, R70, R74, R75 P. 12.1
- FUEL PRIME PUMP C231 P. 19.1

REAR SECTION

REAR JUNCTION BOX CPT.

- A/C JUNCTION BOX ACCESSORIES
- PASSENGER LIQUIDE SOL. VALVE C102 P. 15.3
- WATER PUMP C389 P. 15.3
- BY-PASS VALVE C387 P. 15.3
- FUEL GAUGE TANK P. 7.1
- CONDENSER FAN P. 15.3

EVAPORATOR COMPT.

CONDENSER COMPT.

- SW. T.T.L.T. TEST C548 P. 23.1
- CLUSTER LX & RX P. 7.1
- MODULE T.T.L.T. C570 P. 23.1
- HVAC DASH CONTROL C539 & C540 P. 15.1

FRONT JUNCTION BOX

CHASSIS GROUND

BATTERY GROUND