

<b>Symbol</b>	<b>Description</b>
A14	Control unit, EMS (Engine Management System)
A45	WIF Valve & WIF Indicator (Incl. R06, B52, Y38)
A124	Comp. group engine. (Incl. M04, K65) Stater Motor
B04	Sensor, engine speed, crankshaft
B05	Sensor, engine speed, camshaft
B21	Sensor, coolant temperature, engine
B37	Sensor, boost pressure and boost temperature
B51	Sensor, fuel pressure
B54	Sensor, crankcase pressure
B66	Sensor, EGR temperature aftercooler
B87	Sensor, turbo speed
B118	Sensor, oil pressure
B119	Sensor, oil level and oil temp
B166	Sensor, EGR Differential pressure
B187	Sensor, after treatment fuel pressure
B210	Sensor, compressor discharge temp
B207	Sensor, oil cooling jet pressure
G02	Alternator
M04	Starter motor (Incl. in A124)
M19	Motor, EGR, control valve (Incl. in Y34)
K65	Starter motor relay (Incl. in A124)
R06	Heater, fuel pre filter (Incl. in A45)
Y33	Solenoid valves UI (Unit Injector)
Y34	Actuator, EGR system (Incl. M19)
Y39	Solenoid valve, VCB (Volvo Compression Brake)
Y54	Control unit, Volvo geometric turbo, Can based
Y103	Safety Valve, fuel system
Y110	Solenoid valve, oil thermostat
Y111	Solenoid valve, oil piston cooling jet

EDM-W 2000-04-01

**VOLVO**  
Volvo Powertrain Corporation

Document Title			
<b>WIRING DIAGRAM</b>			
Document Type			
<b>INSTALLATION REQUIREMENT</b>			
Document No	Issue Index	Volume No	Page No
<b>21357389</b>	<b>07</b>	<b>01</b>	<b>5(6)</b>