



\*1 - 12V PWR MUST BE TURNED ON  
 \*2 - 12V IGN MUST BE TURNED ON

TELL TALE LIGHTS MODULE