

# DIODES NUMBER CODE

No.	PAGE	AMP	#PREV.	LOCATION	FUNCTION	No.	PAGE	AMP	#PREV.	LOCATION	FUNCTION
D 1						D 60	15.2	3A	561740	RJB A/C JCT PANEL	A/C COMPR.CLUTCH SUPPRESSOR
D 2						D 61					
D 3						D 62	15.2	3A	561740	RJB A/C JCT PANEL	WATER PUMP FEED
D 4	9.2	3A	561740	FR JCT BOX	WARNING HAZARD-RH	D 63					
D 5	9.2	3A	561740	FR JCT BOX	WARNING HAZARD-LH	D 64					
D 6						D 65	15.2	3A	561740	RJB A/C JCT PANEL	WATER PUMP - PRE-HEAT FEED
D 7						D 66	15.2	3A	561740	RJB A/C JCT PANEL	WATER VALVE - HEAT SW. FEED
D 8						D 67	9.2	3A	561740	UNDER DASH	AUDIBLE FLASHER RLY - RH
D 9						D 68	9.2	3A	561740	UNDER DASH	AUDIBLE FLASHER RLY - LH
D 10						D 69					
D 11						D 70					
D 12						D 71					
D 13						D 72					
D 14						D 73					
D 15						D 74					
D 16						D 75	4.1	3A	560931	BAT CPT	STARTER-SUPPRESSOR COIL RLY
D 17	9.2	3A	561740	FR JCT BOX	WARNING HAZARD-LH	D 76					
D 18	9.2	3A	561740	FR JCT BOX	WARNING HAZARD-RH	D 77					
D 19	9.1	3A	561740	FR JCT BOX	DAYTIME RUN LTS-PARK BRK CALL SW.	D 78	14.1	3A	561740	LH CONSOLE	PRE-HEAT WATER HEATER SW.
D 20	9.1	3A	561740	FR JCT BOX	DAYTIME RUN LTS-HEAD LT SW	D 79	14.1	3A	561740	LH CONSOLE	PRE-HEAT WATER HEATER SW.
D 21						D 80					
D 22	18.1	3A	561740	FR SERVICE CPT	LEVEL LOW	D 81					
D 23	18.1	3A	561740	FR SERVICE CPT	LEVEL LOW	D 82					
D 25	11.1	3A	561740	FR JCT BOX	LUGGAGE DOOR AJAR T.T.LT.	D 83	8.1	3A	561740	RR JCT BOX	FAN CLUTCH W/RETARDER
D 26	11.1	3A	561740	FR JCT BOX	LUGGAGE DOOR AJAR T.T.LT.	D 84	15.2	3A	561740	RJB A/C JCT PANEL	WATER VALVE
D 27	11.1	3A	561740	FR JCT BOX	LUGGAGE DOOR AJAR T.T.LT.	D 85	15.2	3A	561740	RJB A/C JCT PANEL	WATER PUMP
D 28	11.1	3A	561740	FR JCT BOX	LUGGAGE DOOR AJAR T.T.LT.						
D 29	11.1	3A	561740	FR JCT BOX	LUGGAGE DOOR AJAR T.T.LT.						
D 30	11.1	3A	561740	FR JCT BOX	LUGGAGE DOOR AJAR T.T.LT.						
D 31											
D 32											
D 33											
D 34											
D 35											
D 36											
D 37											
D 38											
D 39	9.2	3A	561740	FR JCT BOX	CORNERING LT -LH						
D 40	9.2	3A	561740	FR JCT BOX	FR DOCKING LT LH -HI						
D 41	9.2	3A	561740	FR JCT BOX	FR DOCKING LT RH -HI						
D 42	9.2	3A	561740	FR JCT BOX	CORNERING LT -RH						
D 43	10.1	3A	561740	WIPER MOTOR	LOWER WIPER MOTOR SUPPRESSOR						
D 44	10.1	3A	561740	WIPER MOTOR	LOWER WIPER MOTOR SUPPRESSOR						
D 45	10.1	3A	561740	WIPER MOTOR	UPPER WIPER MOTOR SUPPRESSOR						
D 46											
D 47											
D 48											
D 49											
D 50											
D 51	11.2	3A	561740	FR JCT BOX	ENTRANCE DOOR -STEP LTS						
D 52											
D 53	9.3	3A	561740	FR JCT BOX	CORNERING LT -GROUND						
D 54	20.1	3A	561740	RR JCT BOX	BACK-UP MONITOR						
D 55											
D 56	9.2	12A	560863	FR JCT BOX	FR DOCKING LT LH -LOW						
D 57	9.2	12A	560863	FR JCT BOX	FR DOCKING LT RH -LOW						
D 58											
D 59	15.2	3A	561740	RJB A/C JCT PANEL	A/C & HEAT WATER VALVE						