



1-remove R-12VISS
 2-add jumper #063643
 in socket pin 30 and 87

To Coach Speaker
 Output Mono
 7.5 Ohms
 See P 35.2