

THE ULTIMATE EXPERIENCE

MAINTENANCE INTERVALS

SERVICE AT A GLANCE

PREVH, PREVX Model Year 2011 and newer (not applicable for Commuter Coaches)

D13 Engine EPA 2010 compliant engines and newer		Heavy 6 mpg or less 39 L / 100km or greater	Normal Greater than 6 mpg Less than 39 L / 100km
Engine Oil & Filters, Fuel Filters (Replace)	Miles	45,000	60,000
Using Volvo Premium VDS-4.5 Motor Oil	Km	70,000	95,000
If idle time is greater than 30%, use Heavy drain level	Hours	1,300	1,700
Using Other Volvo Approved VDS-4.5 Motor oils	Miles	40,000	55,000
If idle time is greater than 30%, use Heavy drain level	Km	65,000	90,000
	Hours	1,200	1,600
Using Volvo Premium VDS-4 Motor Oil	Miles	35,000	45,000
If idle time is greater than 30%, use Heavy drain level	Km	60,000	75,000
	Hours	1,000	1,300
Air Filter Replace the air filter	Time	When indicated by the air restriction indicator. Maximum 24 months	
Coolant	Miles	750,000	
Extended Life Coolant . Can only be topped off with premixed 50/50 Extended Life Coolant when coolant level is low		1,200,000	
		96 months	
Coolant Filters		150,000	
Long Life Filter without additives to be used with Extended Life Coolant	Km	240,000	
	Time	12 months	
	Miles	150,000 / then every 300,000	
Valve Adjustment	Km	240,000 / then every 500,000	
	Time	12 months / then every 24 months	
Fan & Accessory Drive Belts Inspect at every preventive maintenance	Miles	31,250	
	Km	50,000	
	Time	12 months	
Radiator Fan Gearbox		12,500	
Check oil level, add if necessary	Km	20,000	
	Time	6 months	
	Miles	106,000	
Change oil and seals	Km	170,	000
Alternators Check alternator drive belt for wear and proper tension	Miles	31,250	
	Km	50,000	
	Time	3 months	
Exhaust Aftertreatment System		Heavy	Normal
Diesel Particulate Filter (DPF)	Miles	400,000	
Either clean the ash from the DPF or replace DPF	Km	650,000	
		10,000	
Aftertreatment Hydrocarbon Injector (AHI)	Miles	150,000	
MY 2011 to 2012, clean AHI nozzle	Km	240,	
MY 2012 and newer (Parker AHI) replace AHI nozzle	Hours	4,500	
DEF, Pump & Tank Filler Neck Filter	Miles	150,	
Drain DEF tank, Replace DEF pump main filter, Clean		240,000	
DEF tank neck filter	Hours	4,5	00
Transmission		Heavy	Normal
	Miles	500 000 (Volvo I-Shift transmission	Fluids or other Volvo approved oils)
I-Shift Transmission	Km	800 000 (Volvo I-Shift transmission	
	Time	60 months (Volvo I-Shift transmission	n Fluids or other Volvo approved oils)
Allison Transmission B500, B500R (retarder)	Miles	25 000	(12 000 B500R)
With TES389 approved fluid and Prognostics mode disabled - change	Km		(20 000 B500R)
transmission fluid, Main & Lube filters	Time		(6 months B500R)
With TranSynd or TES295 synthetic fluid only, no mixture and	Miles	Fluid: 300 000 (150 000	,
TTIME TIME OF THE OLOGO SYNCHOLOGICAL OF THE THE ALICE AND		555 556 (155 666	
	Km	Fluid: 480 000 (240 000	,
Prognostics mode disabled - change transmission fluid, Main & Lube filters	Km Time	Fluid: 480 000 (240 000 Fluid: 48 months	B500R) Filters: 120 000
Prognostics mode disabled - change transmission fluid, Main & Lube filters With TranSynd or TES295 synthetic fluid only, no mixture and	Km Time	Fluid: 480 000 (240 000 Fluid: 48 months 60 months or when indicated by TF	B500R) Filters: 120 000 Filters: 36 months
Prognostics mode disabled - change transmission fluid, Main & Lube filters	Time	Fluid: 48 months	B500R) Filters: 120 000 Filters: 36 months RANSMISSION SERVICE indicator
Prognostics mode disabled - change transmission fluid, Main & Lube filters With TranSynd or TES295 synthetic fluid only, no mixture and Prognostics mode enabled - change fluid & filters With TES389 approved fluid with Prognostics mode enabled - change	Time	Fluid: 48 months 60 months or when indicated by TF	B500R) Filters: 120 000 Filters: 36 months RANSMISSION SERVICE indicator
Prognostics mode disabled - change transmission fluid, Main & Lube filters With TranSynd or TES295 synthetic fluid only, no mixture and Prognostics mode enabled - change fluid & filters With TES389 approved fluid with Prognostics mode enabled - change fluid & filters Chassis	Time Time	Fluid: 48 months 60 months or when indicated by TF 24 months or when indicated by TF Heavy	B500R) Filters: 120 000 Filters: 36 months RANSMISSION SERVICE indicator RANSMISSION SERVICE indicator Normal
Prognostics mode disabled - change transmission fluid, Main & Lube filters With TranSynd or TES295 synthetic fluid only, no mixture and Prognostics mode enabled - change fluid & filters With TES389 approved fluid with Prognostics mode enabled - change fluid & filters Chassis Power Steering	Time Time Miles	Fluid: 48 months 60 months or when indicated by TF 24 months or when indicated by TF Heavy 100,	B500R) Filters: 120 000 Filters: 36 months RANSMISSION SERVICE indicator RANSMISSION SERVICE indicator Normal
Prognostics mode disabled - change transmission fluid, Main & Lube filters With TranSynd or TES295 synthetic fluid only, no mixture and Prognostics mode enabled - change fluid & filters With TES389 approved fluid with Prognostics mode enabled - change fluid & filters Chassis	Time Time Miles Km	Fluid: 48 months 60 months or when indicated by TF 24 months or when indicated by TF Heavy 100, 160,	B500R) Filters: 120 000 Filters: 36 months RANSMISSION SERVICE indicator RANSMISSION SERVICE indicator Normal 000 000
Prognostics mode disabled - change transmission fluid, Main & Lube filters With TranSynd or TES295 synthetic fluid only, no mixture and Prognostics mode enabled - change fluid & filters With TES389 approved fluid with Prognostics mode enabled - change fluid & filters Chassis Power Steering Check power steering fluid condition through visual inspection	Time Time Miles Km Time	Fluid: 48 months 60 months or when indicated by TF 24 months or when indicated by TF Heavy 100, 160, 12 mo	B500R) Filters: 120 000 Filters: 36 months RANSMISSION SERVICE indicator RANSMISSION SERVICE indicator Normal 000 000 onths
Prognostics mode disabled - change transmission fluid, Main & Lube filters With TranSynd or TES295 synthetic fluid only, no mixture and Prognostics mode enabled - change fluid & filters With TES389 approved fluid with Prognostics mode enabled - change fluid & filters Chassis Power Steering Check power steering fluid condition through visual inspection Change power steering fluid filter	Time Time Miles Km Time Time	Fluid: 48 months 60 months or when indicated by TF 24 months or when indicated by TF Heavy 100, 160, 12 months	B500R) Filters: 120 000 Filters: 36 months RANSMISSION SERVICE indicator RANSMISSION SERVICE indicator Normal 000 000 onths onths
Prognostics mode disabled - change transmission fluid, Main & Lube filters With TranSynd or TES295 synthetic fluid only, no mixture and Prognostics mode enabled - change fluid & filters With TES389 approved fluid with Prognostics mode enabled - change fluid & filters Chassis Power Steering Check power steering fluid condition through visual inspection Change power steering fluid filter Differential	Time Time Miles Km Time Time Miles	Fluid: 48 months 60 months or when indicated by TF 24 months or when indicated by TF Heavy 100, 160, 12 mo 12 mo 25,	B500R) Filters: 120 000 Filters: 36 months RANSMISSION SERVICE indicator RANSMISSION SERVICE indicator Normal 000 000 onths onths 000
Prognostics mode disabled - change transmission fluid, Main & Lube filters With TranSynd or TES295 synthetic fluid only, no mixture and Prognostics mode enabled - change fluid & filters With TES389 approved fluid with Prognostics mode enabled - change fluid & filters Chassis Power Steering Check power steering fluid condition through visual inspection Change power steering fluid filter	Time Time Miles Km Time Time Miles Km Km Km	Fluid: 48 months 60 months or when indicated by TF 24 months or when indicated by TF Heavy 100, 160, 12 months 12 months	B500R) Filters: 120 000 Filters: 36 months RANSMISSION SERVICE indicator RANSMISSION SERVICE indicator Normal 000 000 0nths onths 000 000
Prognostics mode disabled - change transmission fluid, Main & Lube filters With TranSynd or TES295 synthetic fluid only, no mixture and Prognostics mode enabled - change fluid & filters With TES389 approved fluid with Prognostics mode enabled - change fluid & filters Chassis Power Steering Check power steering fluid condition through visual inspection Change power steering fluid filter Differential	Time Time Time Miles Km Time Time Miles Km Time Time Miles	Fluid: 48 months 60 months or when indicated by TF 24 months or when indicated by TF Heavy 100, 160, 12 mo 12 mo 25,0 40,0 6 mo	B500R) Filters: 120 000 Filters: 36 months RANSMISSION SERVICE indicator RANSMISSION SERVICE indicator Normal 000 000 00ths 00ths 000 000 00ths 000 000 00ths
Prognostics mode disabled - change transmission fluid, Main & Lube filters With TranSynd or TES295 synthetic fluid only, no mixture and Prognostics mode enabled - change fluid & filters With TES389 approved fluid with Prognostics mode enabled - change fluid & filters Chassis Power Steering Check power steering fluid condition through visual inspection Change power steering fluid filter Differential Check oil level, add if necessary	Time Time Time Miles Km Time Miles Km Time Miles Km Time Miles	Fluid: 48 months 60 months or when indicated by TF 24 months or when indicated by TF Heavy 100, 160, 12 mo 12 mo 25, 40, 6 mo 100 000 / Synth	B500R) Filters: 120 000 Filters: 36 months RANSMISSION SERVICE indicator RANSMISSION SERVICE indicator Normal 000 000 onths onths onths onths onths onths etic Oil 250 000
Prognostics mode disabled - change transmission fluid, Main & Lube filters With TranSynd or TES295 synthetic fluid only, no mixture and Prognostics mode enabled - change fluid & filters With TES389 approved fluid with Prognostics mode enabled - change fluid & filters Chassis Power Steering Check power steering fluid condition through visual inspection Change power steering fluid filter Differential	Time Time Time Miles Km Time Time Miles Km Time Time Miles	Fluid: 48 months 60 months or when indicated by TF 24 months or when indicated by TF Heavy 100, 160, 12 mo 12 mo 25,0 40,0 6 mo	B500R) Filters: 120 000 Filters: 36 months RANSMISSION SERVICE indicator RANSMISSION SERVICE indicator Normal 000 000 000 000 000 000 000 000 000

These maintenance intervals are general recommendations. Please refer to the appropriate maintenance and lubrication manual for your specific vehicle as the authoritative source for all details of a proper and complete inspection and maintenance plan for your vehicle.