

RESISTORS LIST

No	Location	Part #	Function	Page					
Res1	FJB	563205	ABS	16.1					
Res2	FJB	563205	BackupMon.PullDown	28.1					
Res3	RJB	563593	120RTerm.Resis.	6.1					
Res4	Right_Hand_Console	563593	120RTerm.Resis.	6.1					
Res5	Dash	563593	120RTerm.Resis.	6.2					
Res6	FJB	563593	120RTerm.Resis.	6.1					
Res7	FJB		120RTerm.Resis.	6.2					
Res8	EntranceDoorCeiling	563436	VoltageDropRes	18.1					
Res9	DashBoard	100R	CurrentLimitRes	10.1					
Res11	EntranceDoorCeiling	563436	VoltageDropRes	18.1					
Res12	Engine_Cmpt_	563593	120RTerm.Resis.	6.2					
Res13	RJB	563154	ExcitationresistorAlt.1	3.2					
Res14	RJB	563154	ExcitationresistorAlt.2	3.2					
Res15	*opt*	563587	ENDOFLINEDEVICE	38.1					
Res16		563267	330K	14.1					
Res19	*opt*	*opt*	*opt*	32.1					
Res20	*opt*	*opt*	*opt*	32.1					
Res21	FJB	563205	ABS	16.1					
Res22		*opt*	*opt*	40.1					
Res23		*opt*	*opt*	40.1					
Res24		*opt*	*opt*	40.1					
Res25		*opt*	*opt*	40.1					
Res26		*opt*	*opt*	40.1					
Res27		*opt*	*opt*	40.1					
Res28	FJB	563205	ABS	16.1					
Res31		*opt*	*opt*	14.5					
Res32		*opt*	*opt*	14.5					
Res40	*opt*	*opt*	*opt*	14.5					
Res41	*opt*	*opt*	*opt*	14.2					
Res42	*opt*	*opt*	*opt*	14.6					
Res31A		*opt*	*opt*	14.6					
Res32A		*opt*	*opt*	14.6					