

# CONNECTORS CODE

NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET	NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET
				HOUSING	HOUSING					HOUSING	HOUSING
A 1	UNDER DASH – AUDIO SIGNAL	RCA	1	562090	562330	C 57	RH PARCEL RACK - FEEDING	MOLEX	6	562558	562557
A 2	UNDER DASH – AUDIO SIGNAL	RCA	1	562090	562330	C 58					
A 10	UNDER DASH – AUDIO SIGNAL	RCA	1	562090	562330	C 59					
A 11	UNDER DASH – AUDIO SIGNAL	RCA	1	562090	562330	C 60					
A 18	S. S. PANEL – AUDIO SIGNAL	RCA	1	562090	562330	C 61	ENGINE COMPT - FUEL FILTER	PED WP	2	561566	561690
A 19	S. S. PANEL – AUDIO SIGNAL	RCA	1	562090	562330	C 62	ENGINE COMPT – COMPR. AUX. PRESS. SW.	PED WP	2	561566	561690
AA 1	UNDER DASH PANEL- SONALERT	BOSCH	5	-----	561183	C 63	ENGINE COMPT – COMPR. AUX. PRESS. SW.	PED WP	2	561566	561690
C 1	FR JCT BOX COMPARTIMENT	AMP CPC	14	561585	561584	C 64					
C 2	FR JCT BOX COMPARTIMENT	AMP CPC	16	561638	561640	C 65	ENGINE CPT – A/C PRESS SW FAN CLUTCH	PED WP	2	561566	561690
C 3	FR JCT BOX COMPARTIMENT	AMP CPC	37	561644	561646	C 66	ENGINE CPT – SPARE CONNECTOR	PED WP	1	561605	561577
C 4	FR JCT BOX COMPARTIMENT	AMP CPC	24	561641	561643	C 67					
C 5	FR SERVICE COMPT. - UNDERNEATH	AMP CPC	37	561645	561646	C 68					
C 6	FR SERVICE COMPT. - UNDERNEATH	AMP CPC	16	561639	561640	C 69					
C 7	FR SERVICE COMPT - CLUTCH SW	ITT SS	3	561080	561111	C 70	LH CONSOLE	AMP CPC	16	561639	561640
C 8	FR SERVICE COMPT. - UNDERNEATH	AMP CPC	24	561642	561643	C 71	FR JCT BOX COMPT.	AMP CPC	37	561645	561646
C 9	FR SERVICE COMPT. - UNDERNEATH	AMP CPC	24	561642	561643	C 72	FR JCT BOX COMPT.	AMP CPC	24	561642	561643
C 10	FR SERVICE DOOR ACCESS.	DEUTSCH	5	562565	562566	C 73					
C 11	FR SERV. CPT ACCESS	AMP CPC	37	561645	561646	C 74	FR JCT BOX COMPT.	AMP CPC	37	561645	561646
C 12	FR SERV. CPT ACCESS	AMP CPC	16	561639	561640	C 75	SERVICE COMPT. EXT. ENTRANCE DOOR SW.	DEUTSCH	4	562479	562477
C 13	FR JCT BOX COMPARTIMENT	AMP MNL	2	561248	561247	C 75	RH PARCEL RACK – READ. LTS FEED. WCL	MOLEX	6	562558	562557
C 14	LAST LUGGAGE COMP(4) - DOCKING LTS	AMP MNL	2	561248	561247	C 76	ENGINE COMPT. FIRE DETECTOR	DEUTSCH	2	562486	562485
C 15	UNDER STAIRS – CORNERING LTS	AMP MNL	2	560900	560898	C 77	ENGINE COMPT. FIRE DETECTOR	DEUTSCH	2	562486	562485
C 16	LH CONSOLE SW-CRUISE ON/OFF	EATON	12	-----	562763	C 78					
C 17	LH CONSOLE SW-CRUISE RESUME	EATON	12	-----	562763	C 79					
C 18	LH CONSOLE SW-CRUISE SET	EATON	12	-----	562763	C 80					
C 19	LH CONSOLE SW-DECEL SW	EATON	12	-----	562763	C 81	LUGGAGE COMPT - DOOR LOCK	AMP MNL	4	560851	560852
C 20	RR JCT BOX	DEUTSCH	70	562282	562285	C 82	UNDER SEAT – AISLE LTS	AMP MNL	2	560900	560898
C 21	ENGINE COMPT - LOCK DOOR MOT.	PED WP	2	-----	562076	C 82	LUGGAGE COMPT - DOOR LOCK	AMP MNL	4	560851	560852
C 22	LUGGAGE COMPT (A) - A/C & FUEL TANK	AMP CPC	16	561639	561640	C 83	LUGGAGE COMPT - DOOR LOCK	AMP MNL	4	560851	560852
C 23	LUGGAGE COMPT (1) – LUGG. ACCESS.	AMP CPC	24	561642	561643	C 84	LUGGAGE COMPT - DOOR LOCK	AMP MNL	4	560851	560852
C 24	ENGINE COMPT. – INTERF RJB	PED WP	6	561606	561607	C 85					
C 25	ENGINE COMPT. – INTERF RJB	PED WP	6	561606	561607	C 86					
C 26	ENGINE COMPT. ACCESS	DEUTSCH	40	562281	562284	C 87					
C 27	ENGINE COMPT. – INTERF. RJB	DEUTSCH	6	562583	562581	C 88	FR SERV. CPT. PRESS SW PARK BRAKE	PED WP	2	561566	561690
C 28	LUGGAGE COMPT(4) – LUGG. ACCESS	AMP CPC	24	561642	561643	C 89					
C 29	FR SERVICE COMPT – E.C.U. FEED	PED WP	3	561781	561782	C 90					
C 30	ENGINE COMPT – MASTER SW. SIGN.	DEUTSCH	2	562486	562485	C 91					
C 31	RR JCT BOX – PARCEL RACK FEEDING	DEUTSCH	31	562572	562536	C 92	FR JCT BOX COMPT - ABS	AMP CPC	9	561635	561637
C 32	ENGINE COMPT. – 12VI FOR OPTION	PED WP	1	-----	561577	C 93					
C 33	FR SERV. COMPT. – VSS SIGNAL	PED WP	2	561566	561690	C 94					
C 34	FR JCT BOX EATON TRANS. J1939	DEUTSCH	3	562877	562884	C 95					
C 35	A/C COMPT - AIR RETURN SENSOR	AMP MNL	2	561248	561247	C 96	FR SERVICE DOOR ACCESS	AMP MNL	9	561670	561669
C 36	UNDER STAIRS – STEP LIGHTS	AMP MNL	2	561248	561247	C 97	FR SERVICE DOOR – WATER TANK	PED MP	2	-----	562426
C 36	RH PARCEL RACK – EMERGENCY LTS	AMP MNL	2	560900	560898	C 98					
C 37	LH PARCEL RACK - FEEDING	MOLEX	6	562558	562557	C 99	FR SERVICE CPT. LTS	AMP MNL	2	561248	561247
C 38	RH PARCEL RACK - FEEDING	MOLEX	6	562558	562557	C 100					
C 39	ENGINE COMPT. ECM J1939	DEUTSCH	3	562877	562884	C 101	FR SERVICE COMPT. ELEC. HORNS	PED WP	2	561566	561690
C 40						C 101	CONDENSER COMPT - A/C PRES. SW 1SP	PED WP	2	561566	561690
C 41	ENGINE COMPT – RH DOOR LOCK	DEUTSCH	4	562479	562477	C 102	CONDENS. COMPT – LIQU. SOL. VAL. PRES.	PED WP	2	561566	561690
C 42	ENGINE COMPT – RR CAP LIGHTING	DEUTSCH	6	562583	562581	C 103	ENGINE COMPT. – LAVATORY FAN	PED WP	2	561566	561690
C 43	FR JCT BOX – ALT. MODULE	AMP MNL	12	561735	561734	C 104	ENGINE COMPT. – LAVATORY PUMP	DEUTSCH	4	562479	562477
C 44	ENGINE COMPT - LIGHTS	GROTE	2	-----	563268	C 105	UNDER DASH RH - DRV LIO SOL VL	PED WP	2	561566	561690
C 45	FR JCT BOX COMPT – ROOF ACCESS	AMP CPC	24	561642	561643	C 106	UNDER DASH RH - DRV WTR VALVE	PED WP	2	561566	561690
C 46	ENGINE COMPT. ECM J1939	DEUTSCH	3	562877	562884	C 107	ENGINE COMPT - LAVATORY PUSH BUTTON	PED WP	2	561566	561690
C 47	ENGINE DDEC-ECM J1939	PED MP	6	-----	561962	C 108	FR. SERICE COMPT – GAZ CYLINDER L.H.	DEUTSCH	2	562486	562485
C 48	FR SERV. CPT. PRESS SW PARK BRAKE	PED WP	2	561566	561690	C 109					
C 49	LAVATORY ROOF – NIGHT LIGHT	AMP MNL	2	560900	560898	C 110					
C 50	LAVATORY ROOF - LIGHT	LEECRAFT	2	-----	562803	C 111					
C 50	LH SWITCH PANEL – SAFETY SW.	EATON	12	-----	562763	C 112					
C 51	FR SERV.CPT.PARK. BRAKE SOL. VALVE	PNEUMAC	2	-----	641385	C 113					
C 52	ENGINE COMPT - COMPRESSOR	PED WP	2	561566	561690	C 114	ENGINE DDEC - SPEED SIGNAL	PED WP	2	561566	561690
C 53	ENGINE COMPT - COMPRESSOR	PED WP	2	561566	561690	C 115	RR JCT BOX – ENGINE ACCESS	DEUTSCH	40	562281	562284
C 54	FRONT ROOF – UPPER FAN DEFROST	AMP MNL	6	561552	561515	C 116					
C 55	CENTRAL DOOR LOCK	DEUTSCH	4	562479	562477	C 117					
C 56	LH PARCEL RACK - FEEDING	MOLEX	6	562558	562557	C 118	ENGINE COMPT - LICENCE	DOM. AUT	2	930210	

# CONNECTORS CODE

NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET	NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET
				HOUSING	HOUSING					HOUSING	HOUSING
C 119	ENGINE COMPT - RH LOWER LAMP	PED WP	6	561606	561607	C 182					
C 120	ENGINE COMPT - LH LOWER LAMP	PED WP	6	561606	561607	C 183					
C 121						C 184	FR SERV. COMPT. - KNEELING PROX. SW.	ITT SS	3	561080	561111
C 122						C 185	KNEELING PANEL - DOWN SOL. VALVE	PNEUMAC	3		641385
C 123						C 186					
C 124						C 187	FR SERVICE JCT BOX - RESISTORS	AMP MNL	6	561552	561515
C 125						C 187	KNEELING PANEL - PARK BRAKE INTERLOCK	PNEUMAC	3		641385
C 126						C 188					
C 127						C 189	ENGINE COMPT - DOOR LIGHT BACK UP	TRUCK-LITE	2	562755	
C 128						C 190	ENGINE COMPT - DOOR LIGHT STOP/TURN	AMP SS	3		562601
C 129						C 191	ENGINE COMPT - DOOR LIGHT STOP/TURN	AMP SS	3		562601
C 130						C 192	ENGINE COMPT - DOOR LIGHT PARKING	AMP SS	3		562601
C 131						C 193					
C 132						C 194					
C 133						C 195					
C 134	FR JCT BOX - DIODE CONN.	AMP MNL	15	561987	561986	C 196	KNEELING PANEL - UP SOL. VALVE	PNEUMAC	3		641385
C 135	FR JCT BOX - DIODE CONN.	AMP MNL	15	561987	561986	C 197	KNEELING PANEL - CTR SOL. VALVE	PNEUMAC	3		641385
C 136	FR JCT BOX - DIODE CONN.	AMP MNL	15	561987	561986	C 198					
C 137	FR JCT BOX - DIODE CONN.	AMP MNL	15	561987	561986	C 199					
C 138						C 200	PARCEL RACK - FLUORESCENT LTS	AMP MNL	2	561248	561247
C 139						C 201	PARCEL RACK - FLUORESCENT LTS	AMP MNL	2	561248	561247
C 140	HVAC DASH MODULE THERMOMETER	MOLEX	4		562782	C 202	RH PARCEL RACK - INDIRECT LTS	MOLEX	2		562758
C 141	RR DASH PANEL - LTS CONN. (SPARE)	AMP MNL	2	561248	561247	C 203	PARCEL RACK - FLUORESCENT LTS	MOLEX	6		562759
C 142	ENGINE COMPT. B/U ALARM	PED WP	2	561566	561690	C 204	RH PARCEL RACK - RACK LTS	AMP MNL	2	560900	560858
C 143						C 205	RH PARCEL RACK - FEEDING	AMP MNL	9	561661	561662
C 144	FR JCT BOX - AISLE LTS FEEDING	AMP MNL	2	561248	561247	C 206	RH PARCEL RACK - FEEDING	AMP FF	4	562760	562756
C 145						C 207	LH PARCEL RACK - FEEDING	AMP FF	4	562760	562756
C 146						C 208	PARCEL RACK - FLUORESCENT LTS	MOLEX	2		562758
C 147						C 209	LH PARCEL RACK - HOTESS CHIME	AMP MNL	3	561667	561550
C 148						C 210	LH PARCEL RACK - FEEDING	AMP MNL	9	561661	561662
C 149						C 211	FR ROOF - SUN VISOR LH	AMP MNL	2	560900	560898
C 150						C 212	FR ROOF - SUN VISOR RH	AMP MNL	2	560900	560898
C 151						C 213	WCL DOOR UP HING-DOOR READ & HOST. SW	AMP MNL	6	561552	561515
C 152						C 214					
C 153						C 215					
C 154						C 216					
C 155	EVAPORATOR CPT - WATER VALVE	BURKERT	3		563204	C 217	RH PANEL SW. - SCENIC VIEW CAMERA	EATON	12		562763
C 156						C 218	RH PANEL SW. - LIGHTS SPARE	AMP MNL	2	560900	560898
C 157	FR SERV. CPT - WATER PUMP DR'S	PED WP	3	561781	561782	C 219					
C 158	ENGINE CPT - DDEC INTERFACE CONNECTOR	DEUTSCH	31	562572	562536	C 220					
C 159	ENGINE CPT - DDE FEED	PED WP	6	561606	561607	C 221					
C 160	FR SERVICE CPT - INTERFACE	AMP CPC	37	561644	561646	C 222					
C 161	ENGINE DDEC - ECM	PED MP	30		561600	C 223	HEAD LIGHTS - FLASHER	DEUTSCH	5	562565	562566
C 162	ENGINE DDEC - ACCESSORIES	PED WP	4	561610	561611	C 224	HEAD LIGHTS	PED MP	3		562099
C 163	ENGINE CPT - COOLANT PROBE	PED MP	2		562350	C 225	FOG LIGHTS	DEUTSCH	3	562902	562901
C 164						C 226	FRONT HEADLIGHTS - MARKER & FLASHER	PED	3	562137	
C 165						C 226	BATT. COMPT. - INTERIOR LTS	AMP MNL	2	561248	561247
C 166						C 227					
C 167	FR SERVICE CPT - EL. FOOT PEDAL	PED WP	3	561781	561782	C 228					
C 168	FR SERVICE CPT - DDR	DEUTSCH	6	562360		C 229	BATT. COMPT. - CHARGER 110V.	PED WP	1	561577	561605
C 169	FR SERVICE CPT - WORLD TR. INTERFACE	AMP CPC	16	561639	561640	C 230	ENGINE COMPT. - FUEL PRIME PUMP SW.	PED WP	2	561566	561690
C 169	FR SERV. COMPT. - SPEED SWITCH	AMP	15	562011	562012	C 231	ENGINE COMPT. - FUEL PRIME PUMP	PED WP	2	561566	561690
C 170	FR JCT BOX FLASHER UNIT	PED	2		561940	C 232					
C 171	LH CONSOLE	AMP CPC	24	561642	561643	C 233	FIRST LUGGAGE CPT.	VDO	8		562043
C 172	FR SERVICE COMPT - KNEELING PANEL	AMP CPC	16	561639	561640	C 234	FIRST LUGGAGE CPT.	VDO	8		562044
C 172	ENGINE COMPT. - WATER TANK HEATER	PED WP	2	561566	561690	C 235	FIRST LUGGAGE CPT.	VDO	8		562041
C 173						C 236	FIRST LUGGAGE CPT.	AMP MNL	4	560851	560858
C 174						C 236	FR SERVICE CPT CENTER - ABS	AMP CPC	14	561636	561637
C 175						C 237	FR AXLE CPT - ABS RH SENSOR	WABCO	2	641132	
C 176	UNDER DASH RH - WIPER PULSE	AMP FF	6		561186	C 238	FR AXLE CPT - ABS RH VALVE	WABCO	3	641098	
C 177	UNDER DASH RH - WIPER MOTOR	AMP FF	6		561186	C 239	FR AXLE CPT - ABS LH VALVE	WABCO	3	641098	
C 178						C 240	FR AXLE CPT - ABS LH SENSOR	WABCO	2	641132	
C 179						C 241	LAST LUGGAGE COMPT - ABS	PED WP	6	561606	561607
C 180	KNEELING PANEL - DIODE SOCKET	AMP MNL	15	561987	561986	C 242	DRIVE AXLE CPT - ABS LH SENSOR	WABCO	2	641132	
C 181						C 243	DRIVE AXLE CPT - ABS LH VALVE	WABCO	3	641098	

# CONNECTORS CODE

NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET	NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET
				HOUSING	HOUSING					HOUSING	HOUSING
C 244	DRIVE AXLE CPT - ABS RH VALVE	WABCO	3	641098		C 306					
C 245	DRIVE AXLE CPT - ABS RH SENSOR	WABCO	2	641132		C 307					
C 246	DRIVE AXLE CPT - ATC SOL.	PED WP	2	561566	561690	C 308					
C 247	E.C.U. EATON TRANS.	PED MP	18		562573	C 309	ENGINE DDEC - ECM POWER	PED	4	561610	561611
C 248	LAST LUGGAGE CPT - ABS	PED WP	6	561606	561607	C 310	LH CONSOLE SW - LUG. DOOR LOCK	EATON	12		562763
C 249	FR SERVICE CPT - ABS/DDEC	PED WP	2	561566	561690	C 311	RH SWITCH PANEL - HOTESS CHIME	EATON	12		562763
C 250	LH CONSOLE - LOW BOUY	PED WP	2	561566	561690	C 312	ENGINE DDEC - ACCESSORIES	PED WP	3	561781	561782
C 251	LH SW PANEL - FAST IDLE	EATON	12		562763	C 312	RH SWITCH PANEL - READING LAMP	EATON	12		562763
C 252	LUGGAGE COMPT. - WINDOW AJAR	MOLEX	4	561477	561476	C 313	ENGINE DDEC - INTERFACE	FCI	10	563207	
C 253	LH SWITCH PANEL - ETHER	EATON	12		562763	C 313	RH SWITCH PANEL - INTERIOR LTS	EATON	12		562763
C 254						C 314	KNEELING PANEL - PRESS SW.	PED WP	2	561566	561690
C 255	LH SWITCH PANEL - ENGINE BRAKE	EATON	12		562763	C 314	RH SWITCH PANEL - INTERIOR LTS	EATON	12		562763
C 256						C 315	LH SWITCH PANEL - LH SUN VISOR SW.	EATON	12		562763
C 257						C 316	INTO HORN BOX - KNEELING BUZZER	DEUTSCH	2	562486	562485
C 258	LH SWITCH PANEL - MULTI FUNC. SW	AMP FF	8	561188		C 317	LH SWITCH PANEL - RH SUN VISOR SW.	EATON	12		562763
C 259						C 318	LH CONSOLE SW - DR'S WINDOW SW.	EATON	12		562763
C 259	LH SWITCH PANEL - MULTI FUNC. SW	AMP FF	6		561186	C 319	ENGINE DDEC - ECM POWER	PED	4	561610	561611
C 260						C 320	RT SWITCH PANEL - DRIVER'S LTS SW.	EATON	12		562763
C 261						C 321	UNDER DASH RH - KEYLESS MODULE	AMP COM	26		562676
C 262						C 322	UNDER DASH RH - KEYLESS MODULE	AMP COM	22		562675
C 263	LUGGAGE COMPT. LTS COMPT #3	AMP MNL	2	561248	561247	C 323	DRIVER'S WINDOW MOTOR	PED	2		561848
C 264	LUGGAGE COMPT. LTS COMPT #2	AMP MNL	2	561248	561247	C 324	LH SWITCH PANEL - UPPER FAN DEFROST	EATON	12		562763
C 265	LUGGAGE COMPT. LTS COMPT #1	AMP MNL	2	561248	561247	C 325	LH SWITCH PANEL - KNEELING	EATON	12		562763
C 266	ENTRANCE DOOR KEYLESS	AMP CPC	14	561585	561583	C 326					
C 267	UNDER DASH RH - ENT. DOOR PANEL	AMP CPC	24	561642	561643	C 327					
C 268	FR MIRROR RH	CONXALL	5	563091	563090	C 328	RR ROOF - GALLEY LAMP		2		
C 269	FR MIRROR LH	CONXALL	5	563091	563090	C 329					
C 270	LUGGAGE COMPT LTS - 3 LH	AMP MNL	2	561248	561247	C 330					
C 271	LUGGAGE COMPT LTS - 4	AMP MNL	2	561248	561247	C 331					
C 272						C 332					
C 273	ENT. DOOR PANEL - DIODE SOCKET	AMP MNL	9	561670	561669	C 333					
C 274						C 334					
C 275	ENT. DOOR PANEL - DIODE SOCKET	AMP MNL	9	561670	561669	C 335					
C 276						C 336					
C 277	RH UNDER DASH - ENT. DOOR REED SW.	AMP MNL	2	560900	560858	C 337					
C 278	RH PASS. AIR DUCT - ENT DOOR PRESS SW.	PED WP	2	561566	561690	C 338					
C 279	RH UNDER DASH - ENT. DOOR REED SW.	AMP MNL	2	560900	560858	C 339	KNEELING PANEL - HI BUOY SOL. VALVE	PNEUMAC	3		641385
C 279	FR SERVICE COMPT LH - STEERING ZF	DEUTSCH	2		562485	C 340	FR JCT BOX - FIRE PIEZO ALARM	AMP MNL	2	560900	560898
C 280	ENGINE COMPT - A/C COMPRESSOR AUX.	PED WP	2	561566	561690	C 341	LH SWITCH PANEL - HEAT MIRROR SW.	EATON	12		562763
C 281						C 342					
C 282	FR SERVICE COMPT - STEERING ZF	VOLVO	2		562928	C 343	LH SWITCH PANEL - HEAD LAMP SW.	EATON	12		562763
C 283	LH CONSOLE - SPARE SW. LTS	AMP MNL	2	561248	561247	C 344	LH SWITCH PANEL - HAZARD LT SW.	EATON	12		562763
C 284	LH DR'S ROOF - MONITOR FEED	PED WP	3	561781	561782	C 345	LH SWITCH PANEL - FOG LT SW.	EATON	12		562763
C 285	LH DR'S ROOF - SOUND SYSTEM	AMP CPC	24	561642	561643	C 346					
C 286						C 347					
C 287						C 348	INSTR. PANEL CENT. - RACOR MODULE	MOLEX	6	562070	562069
C 288						C 349					
C 289						C 350					
C 290	LUGGAGE CPT - DOOR LOCK	AMP MNL	4	560851	560852	C 351					
C 291	LUGGAGE CPT - DOOR LOCK	AMP MNL	4	560851	560852	C 352					
C 292	LH PARCEL RACK VIDEO PANEL- MONITOR	MOLEX	4	563040	563071	C 353					
C 293	LH PARCEL RACK VIDEO PANEL - RCA RELAY	AMP MNL	2	561248	561247	C 354					
C 294	LH PARCEL RACK VIDEO PANEL - RCA RELAY	AMP MNL	2	561248	561247	C 355					
C 295	LH PARCEL RACK VID. PANEL- AMPLI VIDEO	MOLEX	4	563040	563071	C 356					
C 296	LH PARCEL RACK VIDEO PANEL - MICRO SIGNAL	MOLEX	4	562507	562503	C 357					
C 297						C 358					
C 298						C 359	RH SWITCH PANEL - ENT. DOOR WIND. SW.	EATON	12		562763
C 299	RH SWITCH PANEL - GALLEY	EATON	12		562763	C 360	ENTRANCE WINDOW MOTOR	PED	2		561848
C 300						C 361					
C 301						C 362					
C 302						C 363					
C 303	RR JCT BOX - DIODES	AMP MNL	15	561987	561986	C 364	FRONT ROOF - ELECTRICAL DEST. SIGN	AMP MNL	3	561667	561550
C 304	RR JCT BOX - DIODES	AMP MNL	15	561987	561986	C 365					
C 305						C 366					
						C 367					

# CONNECTORS CODE

NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET	NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET
				HOUSING	HOUSING					HOUSING	HOUSING
C 368	FRONT ROOF – ELECTRICAL DEST. SIGN	AMP MNL	3	561667	561550	C 432					
C 369	FRONT ROOF – ELECTRICAL DEST. SIGN	TORRIX	5	562110		C 433					
C 370	FRONT ROOF – ELECTRICAL DEST. SIGN	AMP MNL	2	560900	560858	C 434					
C 371	FRONT ROOF – ELECTRICAL DEST. SIGN	AMP MNL	3	561667	561550	C 435					
C 372	FRONT ROOF – ELECTRICAL DEST. SIGN	MOLEX	4	561477	561476	C 436					
C 373						C 437					
C 374						C 438					
C 375						C 439					
C 376						C 440					
C 377	LH SWITCH PANEL – STOP ENGINE OVERRIDE	EATON	12		562763	C 441					
C 378						C 442					
C 379	LUGGAGE COMPT. – WINDOW AJAR SW.	MOLEX	4	561477	561476	C 443					
C 380						C 444					
C 381	UNDER DASH PANEL – ANTI THILED	AMP MNL	2	561248	561247	C 445					
C 382	ENGINE GENERATOR (1)	PED WP	1	561605	561577	C 446					
C 383	ENGINE COMPT – VOLTAGE REGULATOR	PED WP	1	561605	561577	C 447					
C 384						C 448					
C 385	BATT. COMPT. – BJB INTERFACE	AMP MNL	12	561735	561736	C 449					
C 386	LH SWITCH PANEL – W.C.LIFT	EATON	12		562763	C 450	S.S. PANEL - FEEDING	MOLEX	4	562507	562503
C 387	EVAPORATOR COMPT. - BY-PASS VALVE	PED WP	2	561566	561690	C 451	S.S. PANEL - FEEDING	MOLEX	2	562550	562549
C 387	BATTERY COMPT. – WCL ACCES.	AMP CPC	16	561639	561640	C 452	UNDER DASH – S.S. ACC. SIGNAL	MOLEX	2	562550	562549
C 388	LUGG. COMPT.(4) – WCL DOOR ACCESS.	AMP MNL	12	561735	561736	C 453	S. S. PANEL – VCR FEEDING	PED WP	2	561566	561690
C 389	EVAPORATOR COMPT. – WATER PUMP	PED WP	2	561566	561690	C 454	S. S. PANEL – VCR FEEDING	PED WP	2	561566	561690
C 390	EVAPORATOR COMPT. – A/C JCT. BOX	DEUTSCH	24	562280	562283	C 455	PARCEL RACK – WIRELESS MICROPHONE	MOLEX	6		562464
C 391	CONDENSER COMPT. A/C PRESS SW 2 SP	PED WP	2	561566	561690	C 456	WORLD TRANS. - RETARDER ACCUM.	PED MP	2		562427
C 392						C 457	WORLD TRANS. - MAIN CONNECTOR	DEUTSCH	31	562572	562536
C 393						C 458	WORLD TRANS. - TURBINE SP. SENS.	PED MP	2		562426
C 394	UNDER DASH - B/U MONITOR	AMP MNL	4	560851	560852	C 459	WORLD TRANS. - ENGINE SP. SENS.	PED MP	2		562426
C 395	UNDER DASH - B/U MONITOR	CLARION	4		990335	C 460	WORLD TRANS. - SPEED SENSOR	ITT	2		562541
C 396	PARCEL RACK – SPEAKER FEEDING	MOLEX	4	562507	562503	C 461	WORLD TRANS. - RETARDER TEMP.	PED MP	2		562856
C 397						C 462	WORLD TRANS. - RETARDER SOL. "K"	PED MP	2		562426
C 398						C 463	WORLD TRANS. - SENSOR CONN.	DEUTSCH	16	562570	562571
C 399	ENGINE GENERATOR (2)	PED WP	2	561566	561690	C 464	RR JCT BOX - DDL CONN	DEUTSCH	6		565360
C 400	ENGINE COMPT. – BLOCK HEATER	PED WP	3	561781	561782	C 465	LH CONSOLE - SHIFTER SELECTOR	PED	20		562825
C 401						C 466	FR SERVICE CPT - RESIS. MOD.	PED WP	3		562428
C 402						C 467	FR SERVICE CPT - RESIS. MOD.	PED WP	3		562428
C 403	GALLEY – REFRIGERATOR		2			C 468	STEERING COLUMN – RET. HAND LEVER	AMP FF	8	561188	562363
C 404	GALLEY – LAMP SWITCH		2			C 469	FR SERVICE COMPT. – RESIS. MOD.	AMP FF	8	561188	562363
C 405	INVERTER SIGNAL	AMP MNL	2	561248	561247	C 470					
C 406						C 471					
C 407						C 472	FR SERVICE CPT – SILENT 1000 OR EATON	PED WP	2	561566	561690
C 408						C 473					
C 409						C 474	DRIVER'S TEMP SENSOR	AMP MNL	2	561248	561247
C 410						C 475	FR SERVICE CPT - SPEED SIGN. CONNECT.	DEUTSCH	6	562583	562581
C 411						C 475M	FR SERVICE CPT – SPEED SIGN. W. TR.	DEUTSCH	6	562583	562581
C 412						C 475W	FR SERVICE CPT – SPEED SIGN. W. TR.	DEUTSCH	6	562583	562581
C 413						C 476					
C 414						C 477					
C 415						C 478	FRONT ROOF – ELECTRONIC DEST. SIGN	AMP CPC	9	561636	561637
C 416						C 479	UNDER DASH – HVAC DASH MODULE	MOLEX	3		562783
C 417						C 480	UNDER DASH RH – DR'S FAN SPEED CTR	PED WP	4	561889	561890
C 418						C 481	UNDER DASH RH – DR'S FAN SPEED CTR	PED WP	3	561781	561782
C 419	FR JCT BOX – RET/JAKE SELECTION	AMP MNL	3	561667	561550	C 482					
C 420						C 483	FR SERVICE CPT – ELECTRICAL SEAT	PED	2	562237	
C 421	ENGINE COMPT. - WEBASTO	AMP FF	2	562473	562474	C 484	UNDER DASH LH – FOOT DAMPER MOTOR	PED	2		562076
C 422	ENGINE COMPT. - WEBASTO	PED	2	562644	561597	C 485	UNDER DASH LH – DASH & DEFR. DAMP. M.	AMP MNL	3	561667	561558
C 423						C 486	WCL ROOF DOOR – DOOR LT.	LEECRAFT	2	-----	562803
C 424	UNDER DASH – AUDIBLE FLASHER	AMP MNL	3	561667	561550	C 487	S.S PANEL – AUDIO IN AMPLI	MOLEX	4	-----	563071
C 425						C 488	S.S PANEL – AMPLI SIGNAL	MOLEX	8	-----	562465
C 426	ENGINE S60 RAD. FAN CLUTCH	PED WP	3	561781	561782	C 489	S.S PANEL – SPEAKER OUTLET	MOLEX	6	-----	562464
C 427						C 490					
C 428	RH SW PANEL – DASH LTS RHEOSTAT	AMP MNL	3	561667	561550	C 491					
C 429						C 492					
C 430	LH CONSOLE – PRE-HEAT TIMER	AMP FF	8	561188	562363	C 493					
C 431	LH CONSOLE – PRE-HEAT TIMER		1		560488	C 494					

# CONNECTORS CODE

NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET	NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET
				HOUSING	HOUSING					HOUSING	HOUSING
C 495						C 565	FR. SERV. COMPT. - MIC. OUTLET	MOLEX	4	562507	562503
C 496						C 566	FR. SERV. COMPT. - MIC. OUTLET	MOLEX	4	562507	562503
C 497						C 567	FR. SERV. COMPT. - MIC. OUTLET	MOLEX	4	562507	562503
C 498						C 568	S.S. PANEL - SPEAKER OUTLET	CINTCH	4	562553	
C 499						C 569	S. S. PANEL - AMPLI SIGNAL	MOLEX	9	562556	562555
C 500	FR JCT PANEL - PRODRIVER	MOLEX	6	562070	562069	C 570	UNDER DASH PANEL - T.T.LT MODULE	MOLEX	6		562464
C 501						C 571	UNDER DASH PANEL - T.T.LT MODULE	MOLEX	20		562778
C 502	LH DASH PANEL - PRE- HEAT SW.	EATON	12		562763	C 572	UNDER DASH PANEL - T.T.LT MODULE	MOLEX	18		562779
C 503	LH CONSOLE-PROHEAT TIMER	PED MP	6		562878	C 573	UNDER DASH PANEL - T.T.LT MODULE	MOLEX	8		562465
C 504	LH CONSOLE -WEBASTO TIMER	AMP	8		562852	C 574	PARCEL RACK - INDIRECT LTS BALLAST	MOLEX			562759
C 505	LH CONSOLE -ESPAR TIMER	AMP	12		562681	C 575	RH PARCEL RACK - FFEDING	MOLEX	4	562507	562503
C 506	FR JCT BOX - DIGITAL CLOCK	AMP CPC	4	561685	561687	C 576	RH PARCEL RACK - FFEDING	AMP MNL	3	561667	561550
C 507	LH HAT RACK - DIGITAL CLOCK	MOLEX	4	561477	561476	C 577	LH PARCEL RACK - FFEDING	AMP MNL	3	561667	561550
C 508	RR JCT BOX - FAN CLUTCH RETARDER	AMP MNL	6	561552	561515	C 578	LH PARCEL RACK - FFEDING	MOLEX	4	562507	562503
C 509	EVAP. COMPT. - NOT USED	DEUTSCH	5		562566	C 579	LH PARCEL RACK-VCR POWER	MOLEX	4		563071
C 515	FR JCT BOX CPT. - INTERCOM	MOLEX	4	561477	561476	C 580	LH DASH PANEL - PARCEL RACK A/C SW.	EATON	12		562763
C 516	FR JCT BOX CPT. - INTERCOM	MOLEX	6	562070	562069	C 581	LH DASH PANEL - ELECTRICAL HORN	PED MP	2		562777
C 517	LAVATORY WALL - INTERCOM	MOLEX	6	562070	562069	C 582					
C 519A	RH UNDER DASH - ENTRANCE DOOR SOL.	PNEUMAC	3		641385	C 583	LH DASH PANEL - MASTER KEY SW.	DEUTSCH	2	562486	562485
C 519B	RH UNDER DASH - ENTRANCE DOOR SOL.	PNEUMAC	3		641385	C 584	FR. SERVICE COMPT - HORN PNEU. VALVE	PNEUMAC	3		562848
C 520	RH UNDER DASH - ENTRANCE DOOR SOL.	PNEUMAC	3		641385	C 585					
C 521	RH UNDER DASH - ENTRANCE DOOR SOL.	PNEUMAC	3		641385	C 586	FR SERVICE COMPT - ACC. PNEU.VALVE	PNEUMAC	3		562848
C 522	FR JCT BOX - DAYTIME LTS MODULE	BOSCH	5		561183	C 587	LH PARCEL RACK DVD UNIT	MOLEX	4	563040	563071
C 523	FR JCT BOX - FUSE BLOCK	PED	8	562647	562646	C 588	FR SERV. COMPT. - S.S. INTERFACE	AMP CPC	37	561645	561646
C 524	FR JCT BOX - FUSE BLOCK	PED	8	562647	562646	C 589	FR. MIRROR LH	CONXALL	8	563163	563088
C 525	FR JCT BOX - FUSE BLOCK	PED	8	562647	562646	C 590	FR. MIRROR RH	CONXALL	8	563163	563088
C 526	FR JCT BOX - FUSE BLOCK	PED	8	562647	562646	C 591	LH CONSOLE - LH MIRROR SW.	EURAMT.	8		562749
C 527	FR JCT BOX - FUSE BLOCK	PED	8	562647	562646	C 592	LH CONSOLE - RH MIRROR SW.	EURAMT.	8		562749
C 528						C 594	FRONT ROOF - DRIVER'S LTS	LEEKRAFT	2		562803
C 529						C 595	RH DASH PANEL - ENTRANCE DOOR SW.	MOLEX	4	562507	562503
C 530	RR JCT BOX - FUSE BLOCK	PED	8	562647	562646	C 596	RH DASH PANEL - ENTRANCE DOOR SW.	MOLEX	4	562507	562503
C 531	RR JCT BOX - FUSE BLOCK	PED	8	562647	562646	C 597	LH DASH PANEL - DISPLAY SET SW.	AMP	5		562905
C 532	LH PARCEL RACK - A/C LIQ. SOL.	AMP MNL	2	561248	561247	C 598	LH DASH PANEL - DISPLAY SET SW.	AMP	5		562905
C 533	RH PARCEL RACK - A/C LIQ. SOL.	AMP MNL	2	561248	561247	C 599	UND. DASH - MAGN. SW CTR POS. DR'S AIR	AMP MNL	2	561248	561247
C 534						C 604	LH PARCEL RACK DVD VIDEO STABILIZER	SWITCHCRAFT	1	563074	
C 535						C 605	LH PARCEL RACK - A/C UNIT	AMP MNL	6	561552	561515
C 536						C 606	RH PARCEL RACK - A/C UNIT	AMP MNL	6	561552	561515
C 537	A/C JCT BOX RESISTOR SIGN. RLY	AMP MNL	2	561248	561247	C 607					
C 538	FR SERV. CPT RH - OUTSIDE TEMP. SENS	AMP MNL	2	561248	561247	C 608	FR SERV. COMPT - SPEED SIGNAL (SPARE)	PED WP	2	561566	561690
C 539	HVAC DASH MODULE OUTPUT CONN.	MOLEX	24		562780	C 609					
C 540	HVAC DASH MODULE INPUT CONN.	MOLEX	22		562781	C 610					
C 541						C 611	RH PARCEL RACK READING LTS WCL	MOLEX	6	562558	562557
C 542						C 612	RH PARCEL RACK LUOR. INSTATION LTS WCL	MOLEX	4	562507	562503
C 543						C 613	RH PARCEL RACK INDIRECT LTS WCL	AMP MNL	3	561667	561550
C 544	S.S. PANEL - AUDIO SEAT	PED WP	3	561781	561782	C 614	RH PARCEL RACK INDIRECT LTS WCL	AMP MNL	3	561667	561550
C 545						C 615	LH PARCEL RACK DVD SIGN ALONG ADAPTOR	MOLEX	2	562550	562549
C 546	FR. JCT BOX - CHARGER WIRELESS MIC.	MOLEX	2		563025	C 701	ZF TRANSMISSION ECU	KOSTAL	20		
C 547						C 702	SHIFT SELECTOR - LH CONSOLE	AMP	14		563338
C 548	LH DASH PANEL - T.T.LT TEST SW.	EATON	12		562763	C 712	NEUTRAL SWITCH ON ZF TRANSM. (TOP)	AMP	4		563340
C 549	LH DASH PANEL - ENGINE FAN OVERRIDE	EATON	12		562763	C 714	OUTPUT SENSOR ON ZF TRANSM. (BOTTOM)	AMP	4		563340
C 550	LAST LUGG. CPT. -WCL MODULE	POLLAK	7	563350	563352	C 717	FR SERV. COMPT - MAIN CONN.	AMP CPC	22	561642	561643
C 551	LAST LUGG. CPT. -WCL CASSETTE	POLLAK	7	563350	563352	C 720	ENGINE COMPT - BLKHD CONNECTOR	DEUTSCH	31	563359	563358
C 552	LAST LUGG. CPT. -WCL REMOTE	AMP CPC	9	561636	561637	C 721	LH CONSOLE - ZF TESTMAN DIAG. TOOLS	AMP MNL	6	563356	
C 553	UNDER DASH - S.S. CONTROL HEAD	MOLEX	16		562559	C 723	ENGINE COMPT - FOR TRANSM.	DEUTSCH	3		562884
C 554	UNDER DASH - S.S. CONTROL HEAD	MOLEX	16		562559	C 736	FR SERV. COMPT - ZMTEC MODULE	PACKARD	30	563053	
C 555	UNDER DASH - S.S. CONTROL HEAD	MOLEX	16		562559	C 740	ABOVE DRIVE AXLE - EASY START SOL VALVE	LEONI	2		641949
C 556	UNDER DASH - RADIO FEEDING	MOLEX	2	562550	562549	C 742	REAR JCT BOX - FUSE BLOCK	AMP	8	562446	
C 557	UNDER DASH - RADIO FEEDING	MOLEX	9	562556	562555	C 745	FR SERV COMPT - THROTTLE POS. SENSOR	PED WP	3	561781	
C 558	FR. SERV. COMPT. - MIC. OUTLET	MOLEX	4	562507	562503	C 760	FR SERVICE COMPT - TO J1939	DEUTSCH	3		
C 559						C 761	FR SERVICE COMPT - TO J1939	DEUTSCH	3		562884
C 560						C 762	ENGINE COMPT - TO J1939	DEUTSCH	3		562884
C 561	LH PARCEL RACK - WIRELESS MIC.	MOLEX	8		562465	C 763	ENGINE COMPT - TO J1939	DEUTSCH	3		562884
C 562	LH PARCEL RACK - VCR SIGNAL	MOLEX	12		563070	C 764	ENGINE COMPT - TO J1939	DEUTSCH	3		562884
C 563	FR. SERV. COMPT. - DRIVER SPEAKER	MOLEX	4	562507	562503	C 765	ENGINE COMPT - TO J1939	DEUTSCH	3		562884
C 564	FR. SERV. COMPT. - MIC. OUTLET	MOLEX	4	562507	562503	C 766	ENGINE COMPT - TO J1939	DEUTSCH	3		562884

# CONNECTORS CODE

NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET	NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET
				HOUSING	HOUSING					HOUSING	HOUSING
CS	FR SERVICE CPT - ECU WOLRD TR.	PED MP	32		562817						
CT	FR SERVICE CPT - ECU WORLD TR.	PED MP	32		562824						
CV	FR SERVICE CPT - ECU WORLD TR.	PED MP	32		562823						
CX	CLUSTER	JAE	5		562957						
CX 1	FR SERVICE CPT - ECU ABS	AMP JN	15		563200						
CX 2	FR SERVICE CPT - ECU ABS	AMP JN	18		563201						
CY	CLUSTER	JAE	30		562765						
CW X1	ENGINE COMPT. - WATER HEATER	AMP	7	563134	563135						
CW X3	ENGINE COMPT. - WATER HEATER	AMP	7	563134	563135						
LX	CLUSTER	JAE	22		562766						
LY	CLUSTER	JAE	30		562767						
RX	CLUSTER	JAE	30		562767						
WEB 1	ENGINE COMPT. - WEBASTO	AMP FF	2	562473	562474						
WEB 2	ENGINE COMPT. - WEBASTO	AMP FF	2	562643							
ZF 1	FR JCT BOX - STEERING E.C.U.	HELLA	9		562929						