

Part Name	Description	Location	Part Type
B12	Sensor,tachograph/speedometer	{NB 4 A}	componentSymbol
B13	Sensor,wheel speed, lhs. 1:st front axle	{EO 2 D}	componentSymbol
B14	Sensor,wheel speed, rhs. 1:st front axle	{EO 2 D}	componentSymbol
B15	Sensor,Wheel speed, lhs. 1:st driven rear axle	{EO 1 D}	componentSymbol
B16	Sensor,Wheel speed, rhs. 1:st driven rear axle	{EO 1 D}	componentSymbol
B22	Sensor, outdoor temperature	{NA 3 A}	componentSymbol
B25	Sensor,accelerator pedal	{BA 2 C}	componentSymbol
B29	sensor chassis level rear axle LHS	{FB 2 B}	componentSymbol
B30	sensor chassis level rear axle RHS	{FB 2 B}	componentSymbol
B32_10		{CS 1 D}	componentSymbol
B32_13	Sensor Eng. cooling fan speed	{CS 1 D}	componentSymbol
B39	Sensor,air filter press/Temp.	{CS 3 B}	componentSymbol
B40	Sensor,brake lining wear indicator,lhs. 1:st front axle	{EO 3 D}	componentSymbol
B41	Sensor,brake lining wear indicator,rhs. 1:st front axle	{EO 3 D}	componentSymbol
B42	Sensor,brake lining wear indicator,lhs. 1:st driven rear axle	{EO 2 D}	componentSymbol
B43	Sensor,brake lining wear indicator,rhs. 1:st driven rear axle	{EO 2 D}	componentSymbol
B49	Sensor,steering angle	{EP 2 B}	componentSymbol
B50	Sensor,yaw-rate	{EP 2 B}	componentSymbol
B57	Sensor,air pressure, suspension bellows, lhs.rear	{FB 4 C}	componentSymbol
B58	Sensor,air perssure,suspension bellow, rhs. rear	{FB 4 C}	componentSymbol
B59	Sensor, indoor temperature	{NA 3 A}	componentSymbol
B69C	Sensor,coolant temperature, retarder	{CX 0 B} {DN3 4 B}	componentSymbol
B904	hydr_oil_level_sens	{NA 4 C}	componentSymbol
B906	Sensor,Brake Press ( 6*2 )	{BC 4 C}	componentSymbol
B910	sensor air press. ECS port 21	{FB 5 C}	componentSymbol
B914	sensor chassis level front axle LHS	{FB 2 B}	componentSymbol
B915	sensor chassis level front axle RHS	{FB 1 B}	componentSymbol
B918	Hydraulic oil level sensor_2	{NA 4 C}	componentSymbol
B920	Sensor,fuel level 2 front axle	{NA 4 A}	componentSymbol
B923	Sensor_temp/level_adblue_tank_SCRT_DNOX2	{CU 2 B}	componentSymbol
B927	Sensor Hydr.oil press	{BB 1 C}	componentSymbol
B930	Sensor_temp_upstream_scart_DNOX2	{CU 2 D}	componentSymbol
B940	Sensor brake lining wear indicator,A/B R	{EP 4 B}	componentSymbol
B941	Sensor brake lining wear indicator,A/B L	{EP 4 B}	componentSymbol
B942	sensor_wheel_speed_A/B_R	{EP 3 B}	componentSymbol

**VOLVO**

Volvo Bus Corporation

Document Title

**WIRING DIAGRAM**

Document Type

**PRODUCT SCHEMATIC**

Document No

**21827151**

Issue Index

**02**

Volume No

**02(02)**

Page No

**4(40)**