

Smart-Vision

Troubleshooting

05/100-118

Index	Date	Writer	Auditor	Approver	Evolutions
А	22/06/2020	A. ROBIN	J. ERBA	C. GAY	Document creation

Vision Systems Safety Tech– 5 Chemin de Chiradie – BP 32 – 69530 Brignais – France Phone +33 4 72 31 98 10 – Fax +33 4 78 05 51 96 – www.visionsystems.fr

The content of this document is the property of Vision System Safety Tech. It is supplied in confidence and commercial securty on its contents must be maintained. It must not be used for any purpose other than that for which it is supplied nor may information contained in it be disclosed to unauthorized persons. It must not be reproduced in whole or in part without permission in writing from Vision Systems. ©VISION SYSTEMS. All rights reserved

INTRODUCTION




Please, refer to one of the 13 cases presented, and read the procedure to follow on the corresponding page.

Please, follow the procedure step by step. If the first step doesn't solve the issue, go to the next one

Case 1	Case 2	Case 3	Case 4	Case 5	Case 6	Case 7
SYSTEM BOOT	SYSTEM RUNNING	SLEEPING MODE	MINOR ISSUE	WIDE ANGLE - CLASS IV NOT FUNCTIONING	MAIN VIEW - CLASS II NOT FUNCTIONING	MAJOR FAULT
Permanent		Pulse	Blinking	Blinking		Permanent
•		•				
			Page 3	Page 4	Page 5	Page 6

Case 8	Case 9	Case 10	Case 11	Case 12	Case 13
NO POWERED	CAMERA FAILURE	CAMERA FAILURE	CAMERA FAILURE	MONITOR FAILURE	MONITOR FAILURE
Page 6	Page 7	Page 7	Page 7	Page 8	Page 8






How performed an Ignition ?

- 1 Shut down your vehicle
- 2 Wait for 2s
- 3 Turn on your vehicle



WIDE ANGLE -CLASS IV NOT FUNCTIONING Blinking







How performed an Ignition ? 1 - Shut down your vehicle 2 - Wait for 2s

3 - Turn on your vehicle








How performed an Ignition ? 1 - Shut down your vehicle

- 1 Shut down your veni
- 2 Wait for 2s
- 3 Turn on your vehicle






How performed an Ignition ? 1 - Shut down your vehicle 2 - Wait for 2s

3 - Turn on your vehicle



Case 9, Case 10 and Case 11


Case 9	Case 10	Case 11
CAMERA FAILURE	CAMERA FAILURE	CAMERA FAILURE



How performed an Ignition ? 1 - Shut down your vehicle

- 2 Wait for 2s
- 3 Turn on your vehicle





How performed an Ignition ? 1 - Shut down your vehicle

- 2 Wait for 2s
- 3 Turn on your vehicle