

RELAYS NUMBER CODE

No.	PAGE	COIL V	#PREV.	LOCATION	FUNCTION	No.	PAGE	COIL V	#PREV.	LOCATION	FUNCTION
RF1	8	24V	561707	RR JCT BOX	FAN CLUTCH W/RET. SPEED 1	R 58					
RF2	8	24V	561707	RR JCT BOX	FAN CLUTCH W/RET. SPEED 2	R 59	9.3	12V	562092	RR JCT BOX	DOCKING LTS
RF3	8	24V	560772	RR JCT BOX	TIME DELAY	R 60					
RLA	16	24V	561707	UNDER DASH RH.	ENTRANCE DOOR SEDAN (LATCH)	R 61	9.3	24V	561707	RR JCT BOX	STOP LTS-JACOB & RET. SIGNAL
RLO	16	24V	561707	UNDER DASH RH.	ENTRANCE DOOR SEDAN (PRESS. SW.)	R 62					
RLT	16	24V	561707	UNDER DASH RH.	ENTRANCE DOOR SEDAN (LIGHT)	R 63					
RLV	16	24V	561707	UNDER DASH RH.	ENTRANCE DOOR SEDAN (VALVE)	R 64					
R 1	1.1	24V	561991	FR JCT BOX	ENGINE RUN (24) FR	R 65					
R 2	2	24V	561991	BATT. CPT.	ENGINE RUN (12) FR & RR	R 66	20.3	24V	561707	SS JCT PANEL	SOUND SYSTEM VIDEO
R 3	4	24V	561707	BATT. CPT.	FIELD RELAY	R 67	20.1	24V	561707	SS JCT PANEL	SOUND SYSTEM RADIO
R 4	4	24V	561005	BATT. CPT.	STARTING MOTOR	R 68	20.1	24V	561991	SS JCT PANEL	SOUND SYSTEM AMPLIFIER
R 5	5	24V	561707	FR JCT BOX	CRUISE CTR. STOP SIGN.	R 69					
R 6	9.3	24V	561707	RR JCT BOX	STOP LTS-PARKING BRAKE	R 70					
R 7	5	24V	561707	FR JCT BOX	FAST IDLE	R 71					
R 8	6	24V	561707	RR JCT BOX	12V IGNITION WT	R 72					
R 9	9.3	24V	561707	RR JCT BOX	BACK-UP LTS	R 73					
R 10						R 74					
R 11	5	24V	561707	RR JCT BOX	12V IGNITION DDEC3	R 75					
R 12	7	12V	562092	FR JCT BOX	ELECTRICAL HORNS	R 76					
R 13	9.3	24V	561707	FR JCT BOX	FOG LTS	R 77					
R 14	9.1	24V	561707	FR JCT BOX	BLINKER	R 78	1.1	12V	562092	FR JCT BOX	MASTER SWITCH
R 15	9.1	24V	561707	FR JCT BOX	FR MARKER LTS	R 79	23	24V	561707	GALLEY CPT.	GALLEY-REFRIGERATOR
R 16	9.1	24V	561707	FR JCT BOX	IDENT. & CLEARANCE LTS	R 80	11.1	24V	561707	RR JCT BOX	ENGINE COMPARTMENT LTS
R 17	9.1	24V	561707	RR JCT BOX	TAIL,LICENCE,MARKER-RR LTS	R 81					
R 18	9.1	24V	561707	FR JCT BOX	D R L-PARK BRK CUT-IN	R 82	19	24V	561707	FR JCT BOX	RETARDER WT
R 19	9.1	24V	561707	FR JCT BOX	HEADLAMPS (HI)	R 83					
R 20	9.1	24V	561707	FR JCT BOX	HEADLAMPS (LO)	R 84	8	24V	561707	RR JCT BOX	FAN CLUTCH-FIRST SPEED
R 21	9.2	24V	561707	FR JCT BOX	L.H. DIRECTIONNAL LT	R 85	8	24V	561707	RR JCT BOX	FAN CLUTCH-SECOND SPEED
R 22						R 86					
R 23	9.2	24V	561707	FR JCT BOX	R.H. DIRECTIONNAL LT	R 87	19	24V	561707	RR JCT BOX	ENGINE BRAKE REQUEST WT
R 24	9.2	24V	561707	FR JCT BOX	R.H. CORNERING LT	R 88					
R 25	9.2	24V	561707	FR JCT BOX	L.H. CORNERING LT	R 89	22	24V	561707	FR JCT BOX	HEATING WINDSHIELD
R 26	9.3	24V	561707	RR JCT BOX	STOP LTS	R 90	22	24V	561707	FR JCT BOX	HEATING WINDSHIELD
R 27	11.2	24V	561707	RR JCT BOX	AISLE & EMERG.EXIT - LTS	R 91	22	24V	561707	FR JCT BOX	HEATING WINDSHIELD
R 28	11.2	24V	561707	FR JCT BOX	DASH LTS RHEOSTAT	R 92	22	24V	561707	FR JCT BOX	HEATING WINDSHIELD
R 29	11.3	24V	561707	RR JCT BOX	READING LTS R.H.	R 93	26	24V	561707	RR JCT BOX	PRE-HEAT WATER HEATER (WEBASTO)
R 30	11.3	24V	561707	RR JCT BOX	READING LTS L.H.	R 94	25	24V	561707	RR JCT BOX	WCL - SYSTEM
R 31	11.3	24V	561707	RR JCT BOX	GENERAL LTS	R 95	25	24V	561707	RR JCT BOX	WCL - MAGNETIC SW. SIGN.
R 32	11.4	24V	561707	RR JCT BOX	24V FLUORESCENT	R 96	25	24V	561707	RR JCT BOX	WCL - DOOR AJAR ALARM
R 33	13.1	12V	562092	FR JCT BOX	BLOWER CUT-IN RLY	R 97	25	24V	561707	RR JCT BOX	WCL - DOOR AJAR PARK. BRAKE
R 34	13.1	24V	561707	RJB A/C JCT PANEL	A/C LOGIC PANEL	R 98	25	12V	561538	RR JCT BOX	WCL -
R 35	13.1	24V	561707	RJB A/C JCT PANEL	WATER PUMP	R 99	8	24V	561707	RR JCT BOX	RADIATOR FAN CLUTCH
R 36	13.1	24V	561707	RJB A/C JCT PANEL	A/C COMPRESSOR CLUTCH	R 100	4	12V	561538	RR JCT BOX	GENERATOR SIGNAL
R 37	10	24V	561707	FR JCT BOX	KNEELING LT	R 101					
R 38						R 102	17	24V	561707	RR JCT BOX	FUEL FILTER HEATER
R 39	13.2	24V	561005	BATT. CPT.	CONDENSER FAN MOTOR	R 103					
R 40	13.2	24V	561014	BATT. CPT.	CONDENSER SPEED CTR HI	R 104	13.3	24V	561707	RR JCT BOX	HAT-RACK FAN - L.H.
R 41	13.2	24V	561005	BATT. CPT.	CONDENSER SPEED CTR HI	R 105	13.3	24V	561707	RR JCT BOX	HAT-RACK FAN - R.H.
R 42						R 106	17.1	24V	561707	RR JCT BOX	LAVATORY FAN
R 43	18	24V	561707	FR JCT BOX	KNEELING SYSTEM	R 107					
R 44	18	24V	561707	FR JCT BOX	KNEELING SYSTEM	R 2010	26.2	24V	561230	WEBASTO PRE-HEAT	WEBASTO
R 45						V IMN	6	12V	562092	RR JCT BOX	VIM WORLD TR.-NEUTRAL SIGNAL
R 46						V IMR	6	12V	562092	RR JCT BOX	VIM WORLD TR.-B/U SIGNAL
R 47	23	24V	561707	GALLEY COMPT	GALLEY-LIQUID CONTAINERS	V IM1	6	12V	562092	RR JCT BOX	VIM WORLD TR.-OUTPUT 1
R 48	23	24V	561707	GALLEY COMPT	COFFEE MAKER	V IM2	6	12V	562092	RR JCT BOX	VIM WORLD TR.-OUTPUT 2 ENG. BRK DISABLE
R 49	21	24V	561707	FR JCT BOX	ABS - SERVICE BRK RLY	V IM3	6	12V	562092	RR JCT BOX	VIM WORLD TR.-OUTPUT 3 SPD SW. 5MPH NO NC
R 50	10	24V	561707	FR JCT BOX	UPPER WINDSHIELD WIPER	V IM4	6	12V	562092	RR JCT BOX	VIM WORLD TR.-OUTPUT 4 RETARD. ON SIGNAL
R 51	11.3	12V	562092	FR JCT BOX	DRIVER'S LTS RLY- ENT. DOOR SIGN.						
R 52	21	24V	561707	FR JCT BOX	ABS - W/TR SIGN. RETARDER						
R 53	1.1	24V	561991	RR JCT BOX	ENGINE RUN (24) RR						
R 54	1.1	24V	561991	BATT. CPT.	12V CUT OUT RLY RR						
R 55	1.1	24V	561991	BATT. CPT.	12V CUT OUT RLY FR						
R 56											
R 57	9.1	24V	561707	FR JCT BOX	DAY'S BLINKER						

RELAYS NUMBER CODE

No. PAGE COIL V #PREV. LOCATION FUNCTION

No. PAGE COIL V #PREV. LOCATION FUNCTION