

Diodes list

No	Location	Part no	Function	Page
D1	FJB	561740	Accessories Diode	3.2_Ign_Start 3 B
D2	FJB	561740	Diode Driver Liq. Sol.	18.1_Defroster 2 D
D4	RH Console	561740	Suppressor Diode Lower Wiper 2nd Spd	34.1_wiper_washer 4 D
D5	RH Console	561740	Suppressor Diode Lower Wiper 1st Spd	34.1_wiper_washer 4 D
D6	RJB	561740	Suppressor Diode Master relay	3.1_Main_Disti 1 B
D11	Evap_Cmpt	561740	Diode Pass. Liq. Sol	18.2_Full_AC 2 B
D12	FJB	565973	10amp	9.1_Horn 2 B
D13	FJB	561740	3amp	26.1_Front_Lighting 2 D
D14	FJB	561740	3amp	9.1_Horn 2 B
D29	RJB	561740	Suppressor Diode Unloader RH	18.2_Full_AC 3 D
D30	Evap_Cmpt	561740	Suppressor Diode Water Pump	18.2_Full_AC 2 C
D31	RJB	561740	Suppressor Diode A/C Clutch	18.2_Full_AC 3 D
D44	FJB	561740	Ignition Diode	3.2_Ign_Start 3 B
D51	Service Cmpt.	561740	LevelLow_Diode	32.1_Level_low 1 E
D66	Service Cmpt.	561740	Water pump flyback diode	18.3_Small_AC 4 B
D73	Evap_Cmpt	561740	Pre Heater	29.1_Entrance_door_Keyless 2 B
D75	Slide_Outs_Elect._Cmpt	561740	Park Brake Diode	20.1_SlideOut1 1 B
D79	Service Cmpt.	561740	LevelLow_Diode	32.1_Level_low 2 D
D81	Evap_Cmpt	561740	LevelLow_Diode	32.1_Level_low 1 D
D88	FJB	560931	Lugg. Lights Diode	25.1_Cmpt_Lighting
D89	FJB	560931	Lugg. Lights Diode	25.1_Cmpt_Lighting
DSO1_1	FR_LH_Slide_Out	563375	Slide out motor 1	20.1_SlideOut1 3 B
DSO1_2	FR_LH_Slide_Out	563375	Slide out motor 1	20.1_SlideOut1 3 B
DSO2_1	RR_LH_Slide_Out	563375	Slide out motor 2	20.2_SlideOut2 4 B
DSO2_2	RR_LH_Slide_Out	563375	Slide out motor 2	20.2_SlideOut2 4 B