

RELAYS NUMBER CODE

No.	PAGE	COIL V	#PREV.	LOCATION	FUNCTION	No.	PAGE	COIL V	#PREV.	LOCATION	FUNCTION
RF1	8	24V	561707	RR JCT BOX	FAN CLUTCH W/RET. SPEED 1	R 92	13	24V	561707	FR JCT BOX	HEATING WINDSHIELD
RF2	8	24V	561707	RR JCT BOX	FAN CLUTCH W/RET. SPEED 2	R 93	14	24V	561707	RR JCT BOX	PRE-HEAT WATER HEATER (WEBASTO)
RF3	8	24V	560772	RR JCT BOX	TIME DELAY	R 99	8	24V	561707	RR JCT BOX	RADIATOR FAN CLUTCH
R1	1.1	24V	561991	FR JCT BOX	ENGINE RUN (24) FR	R 100	4	12V	561538	RR JCT BOX	GENERATOR SIGNAL
R2	2	24V	561991	BATT. CPT.	ENGINE RUN (12) FR & RR	V IMN	6	12V	562092	RR JCT BOX	VIM WORLD TR.-NEUTRAL SIGNAL
R3	4	24V	561707	BATT. CPT.	FIELD RELAY	V IMR	6	12V	562092	RR JCT BOX	VIM WORLD TR.-B/U SIGNAL
R4	4	24V	561005	BATT. CPT.	STARTING MOTOR	V IM1	6	12V	562092	RR JCT BOX	VIM WORLD TR.-OUTPUT 1
R5	5	24V	561707	FR JCT BOX	CRUISE CTR. STOP SIGN.	V IM2	6	12V	562092	RR JCT BOX	VIM WORLD TR.-OUTPUT 2 ENG. BRK DISABLE
R6	9.3	24V	561707	RR JCT BOX	STOP LTS-PARKING BRAKE	V IM3	6	12V	562092	RR JCT BOX	VIM WORLD TR.-OUTPUT 3 SPD SW. 5MPH NO NO
R7	5	24V	561707	FR JCT BOX	FAST IDLE	V IM4	6	12V	562092	RR JCT BOX	VIM WORLD TR.-OUTPUT 4 RETARD. ON SIGNAL
R8	6	24V	561707	RR JCT BOX	12V IGNITION WT						
R9	9.3	24V	561707	RR JCT BOX	BACK-UP LTS						
R11	5	24V	561707	RR JCT BOX	12V IGNITION DDEC3						
R12	7	12V	562092	FR JCT BOX	ELECTRICAL HORNS						
R13	9.3	24V	561707	FR JCT BOX	FOG LTS						
R14	9.1	24V	561707	FR JCT BOX	BLINKER						
R15	9.1	24V	561707	FR JCT BOX	FR MARKER LTS						
R16	9.1	24V	561707	FR JCT BOX	IDENT. & CLEARANCE LTS						
R17	9.1	24V	561707	RR JCT BOX	TAIL,LICENCE,MARKER-RR LTS						
R18	9.1	24V	561707	FR JCT BOX	D R L-PARK BRK CUT-IN						
R19	9.1	24V	561707	FR JCT BOX	HEADLAMPS (HI)						
R20	9.1	24V	561707	FR JCT BOX	HEADLAMPS (LO)						
R21	9.2	24V	561707	FR JCT BOX	L.H. DIRECTIONNAL LT						
R22	8	24V	561707	FR JCT BOX	PARKING BRAKE -ALARM						
R23	9.2	24V	561707	FR JCT BOX	R.H. DIRECTIONNAL LT						
R24	9.2	24V	561707	FR JCT BOX	R.H. CORNERING LT						
R25	9.2	24V	561707	FR JCT BOX	L.H. CORNERING LT						
R26	9.3	24V	561707	RR JCT BOX	STOP LTS						
R28	11.2	24V	561707	FR JCT BOX	DASH LTS RHEOSTAT						
R33	15.1	12V	562092	FR JCT BOX	BLOWER CUT-IN RLY						
R34	15.1	24V	561707	RJB A/C JCT PANEL	A/C LOGIC PANEL						
R35	15.1	24V	561707	RJB A/C JCT PANEL	WATER PUMP						
R36	15.1	24V	561707	RJB A/C JCT PANEL	A/C COMPRESSOR CLUTCH						
R39	15.2	24V	560407	BATT. CPT.	CONDENSER FAN MOTOR						
R40	15.2	24V	561014	BATT. CPT.	CONDENSER SPEED CTR HI						
R41	15.2	24V	560407	BATT. CPT.	CONDENSER SPEED CTR HI						
R46	20	24V	561707	FR JCT BOX	CAMERA DOOR						
R49	22	24V	561707	FR JCT BOX	ABS - SERVICE BRK RLY						
R50	22	24V	561707	FR JCT BOX	ABS - VR2 RLY						
R51	22	24V	561707	FR JCT BOX	ABS - WARNING RLY						
R52	22	24V	561707	FR JCT BOX	ABS - VR1 RLY						
R53	1.1	24V	561991	RR JCT BOX	ENGINE RUN (24) RR						
R54	1.1	24V	561991	BATT. CPT.	12V CUT OUT RLY RR						
R55	1.1	24V	561991	BATT. CPT.	12V CUT OUT RLY FR						
R57	9.1	24V	561707	FR JCT BOX	DAY'S BLINKER						
R59	9.3	12V	562092	RR JCT BOX	DOCKING LTS						
R61	9.3	24V	561707	RR JCT BOX	STOP LTS-JACOB & RET. SIGNAL						
R64	11.2	12V	562092	FR JCT BOX	ENTRANCE DOOR SW. & LTS						
R65	9.2	24V	561707	FR JCT BOX	CORNERING LTS CONTROL						
R66	9.2	24V	561707	FR JCT BOX	LOW DOCKING LTS -FR CORNERING						
R67	9.3	24V	561707	RR JCT BOX	LOW DOCKING LTS						
R69	12	12V	562092	RR JCT BOX	LUGGAGE DOOR LOCK						
R70	12	12V	562092	RR JCT BOX	LUGGAGE DOOR UNLOCK						
R71	12	24V	561707	RR JCT BOX	LUGGAGE DOOR UNLOCK T.T. LT.						
R74	12	12V	562092	RR JCT BOX	LUGGAGE DOOR LOCK						
R75	12	12V	562092	RR JCT BOX	LUGGAGE DOOR UNLOCK						
R78	1.1	12V	562092	FR JCT BOX	MASTER SWITCH						
R80	11.1	24V	561707	RR JCT BOX	ENGINE COMPARTMENT LTS						
R82	21	24V	561707	FR JCT BOX	RETARDER WT						
R84	8	24V	561707	RR JCT BOX	FAN CLUTCH-FIRST SPEED						
R85	8	24V	561707	RR JCT BOX	FAN CLUTCH-SECOND SPEED						
R87	21	24V	561707	RR JCT BOX	ENGINE BRAKE REQUEST WT						
R89	13	24V	561707	FR JCT BOX	HEATING WINDSHIELD						
R90	13	24V	561707	FR JCT BOX	HEATING WINDSHIELD						
R91	13	24V	561707	FR JCT BOX	HEATING WINDSHIELD						