

# CONNECTORS CODE

NO	LOCATION	TYPE	CAVITY	#PIN HOUSING	#SOCKET HOUSING	NO	LOCATION	TYPE	CAVITY	#PIN HOUSING	#SOCKET HOUSING
C8A	RR JCT BOX-ECU WORLD TR.	T & BET	34	.....	562419	C31	RR JCT BOX	AMP CPC	37	561714	561713
C8B	RR JCT BOX-ECU WORLD TR.	AMP CPC	34	.....	562420	C32	RR LH UPPER WHELL OPT-ABS	AMP CPC	9	561635	561637
C8C	RR JCT BOX-COMPARTMENT	AMP CPC	14	561585	561584	C33	FR LH UPPER WHELL OPT-ABS	WABCO	35	.....	561635
C8D	RR JCT BOX-COMPARTMENT	AMP CPC	16	561639	561639	C36	FR AXLE ACCESSORIES	AMP CPC	14	561585	641094
C8E	RR JCT BOX-COMPARTMENT	AMP CPC	24	561641	561641	C37	FR AXLE ACC-INSIDE PVC END	AMP CPC	5	561586	561578
C8F	FR SERVICE COMP.-UNDERNEATH	AMP CPC	37	561644	561644	C38	FR SERVICE COMP.-ELFT PEDAL	AMP CPC	3	561782	561781
C8G	FR SERVICE COMP.-UNDERNEATH	AMP CPC	16	561639	561639	C39	FR SERVICE COMP-ELC. HORNS	AMP MNL	2	561248	561690
C8H	FR SERVICE COMP.-UNDERNEATH	AMP CPC	24	561641	561641	C101	FR SERV & SIDE OPT-FLASH LH	GROTE	2	561586	561690
C8I	FR SERVICE COMP.-UNDERNEATH	AMP CPC	24	561641	561641	C102	FR SERV & SIDE OPT-FLASH RH	GROTE	2	561586	561690
C8J	FR SERVICE COMP.-UNDERNEATH	AMP CPC	37	561644	561644	C103	FR SERV & SIDE OPT-FLASH RH	GROTE	2	561586	561690
C8K	FR SERVICE COMP.-UNDERNEATH	AMP CPC	16	561639	561639	C104	FR SERV & SIDE OPT-FLASH RH	GROTE	2	561586	561690
C8L	FR SERVICE COMP.-UNDERNEATH	AMP CPC	24	561641	561641	C105	FR SERVICE COMP-TLDS VALVE	GROTE	2	561586	561690
C8M	FR SERVICE COMP.-UNDERNEATH	AMP CPC	24	561641	561641	C106	FR SERVICE COMP-WATER VALVE	GROTE	2	561586	561690
C8N	FR SERVICE COMP.-UNDERNEATH	AMP CPC	16	561639	561639	C107	EVAPORATOR COMP-DAMPBR	GROTE	2	561586	561690
C8O	FR SERVICE COMP.-UNDERNEATH	AMP CPC	6	561552	561552	C108	FR SERVICE COMP-KNEEL SYS	GROTE	2	561586	561690
C8P	FR SERVICE COMP.-UNDERNEATH	AMP CPC	9	561641	561641	C109	FR SERVICE COMP-KNEEL SYS	GROTE	2	561586	561690
C8Q	FR SERVICE COMP.-UNDERNEATH	AMP CPC	24	561641	561641	C110	FR SERVICE COMP-KNEEL SYS	GROTE	2	561586	561690
C8R	FR SERVICE COMP.-UNDERNEATH	AMP CPC	9	561641	561641	C111	FR SERVICE COMP-KNEEL SYS	GROTE	2	561586	561690
C8S	FR SERVICE COMP.-UNDERNEATH	AMP CPC	9	561641	561641	C112	FR SERVICE COMP-KNEEL SYS	GROTE	2	561586	561690
C8T	FR SERVICE COMP.-UNDERNEATH	AMP CPC	9	561641	561641	C113	FR SERVICE COMP-KNEEL SYS	GROTE	2	561586	561690
C8U	FR SERVICE COMP.-UNDERNEATH	AMP CPC	9	561641	561641	C114	FR SERVICE COMP-KNEEL SYS	GROTE	2	561586	561690
C8V	FR SERVICE COMP.-UNDERNEATH	AMP CPC	9	561641	561641	C115	FR SERVICE COMP-KNEEL SYS	GROTE	2	561586	561690
C8W	FR SERVICE COMP.-UNDERNEATH	AMP CPC	9	561641	561641	C116	FR SERVICE COMP-KNEEL SYS	GROTE	2	561586	561690
C8X	FR SERVICE COMP.-UNDERNEATH	AMP CPC	9	561641	561641	C117	FR SERVICE COMP-KNEEL SYS	GROTE	2	561586	561690
C8Y	FR SERVICE COMP.-UNDERNEATH	AMP CPC	9	561641	561641	C118	FR SERVICE COMP-KNEEL SYS	GROTE	2	561586	561690
C8Z	FR SERVICE COMP.-UNDERNEATH	AMP CPC	9	561641	561641	C119	FR SERVICE COMP-KNEEL SYS	GROTE	2	561586	561690
C21	RR JCT BOX	AMP CPC	8	.....	561107	C120	RR J BOX OPT DOOR DIR LH	DEUTSCH	2	562486	561690
C22	RR JCT BOX	AMP CPC	8	.....	561107	C121	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C23	RR JCT BOX	AMP CPC	8	.....	561107	C122	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C24	RR JCT BOX	AMP CPC	8	.....	561107	C123	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C25	RR JCT BOX	AMP CPC	8	.....	561107	C124	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C26	RR JCT BOX	AMP CPC	8	.....	561107	C125	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C27	RR JCT BOX	AMP CPC	8	.....	561107	C126	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C28	RR JCT BOX	AMP CPC	8	.....	561107	C127	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C29	RR JCT BOX	AMP CPC	8	.....	561107	C128	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C30	RR JCT BOX	AMP CPC	8	.....	561107	C129	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C31	RR JCT BOX	AMP CPC	8	.....	561107	C130	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C32	RR JCT BOX	AMP CPC	8	.....	561107	C131	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C33	RR JCT BOX	AMP CPC	8	.....	561107	C132	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C34	RR JCT BOX	AMP CPC	8	.....	561107	C133	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C35	RR JCT BOX	AMP CPC	8	.....	561107	C134	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C36	RR JCT BOX	AMP CPC	8	.....	561107	C135	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C37	RR JCT BOX	AMP CPC	8	.....	561107	C136	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C38	RR JCT BOX	AMP CPC	8	.....	561107	C137	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C39	RR JCT BOX	AMP CPC	8	.....	561107	C138	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C40	RR JCT BOX	AMP CPC	8	.....	561107	C139	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C41	RR JCT BOX	AMP CPC	8	.....	561107	C140	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C42	RR JCT BOX	AMP CPC	8	.....	561107	C141	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C43	RR JCT BOX	AMP CPC	8	.....	561107	C142	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C44	RR JCT BOX	AMP CPC	8	.....	561107	C143	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C45	RR JCT BOX	AMP CPC	8	.....	561107	C144	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C46	RR JCT BOX	AMP CPC	8	.....	561107	C145	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C47	RR JCT BOX	AMP CPC	8	.....	561107	C146	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C48	RR JCT BOX	AMP CPC	8	.....	561107	C147	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C49	RR JCT BOX	AMP CPC	8	.....	561107	C148	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C50	RR JCT BOX	AMP CPC	8	.....	561107	C149	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C51	RR JCT BOX	AMP CPC	8	.....	561107	C150	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C52	RR JCT BOX	AMP CPC	8	.....	561107	C151	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C53	RR JCT BOX	AMP CPC	8	.....	561107	C152	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C54	RR JCT BOX	AMP CPC	8	.....	561107	C153	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C55	RR JCT BOX	AMP CPC	8	.....	561107	C154	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C56	RR JCT BOX	AMP CPC	8	.....	561107	C155	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C57	RR JCT BOX	AMP CPC	8	.....	561107	C156	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C58	RR JCT BOX	AMP CPC	8	.....	561107	C157	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C59	RR JCT BOX	AMP CPC	8	.....	561107	C158	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C60	RR JCT BOX	AMP CPC	8	.....	561107	C159	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C61	RR JCT BOX	AMP CPC	8	.....	561107	C160	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C62	RR JCT BOX	AMP CPC	8	.....	561107	C161	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C63	RR JCT BOX	AMP CPC	8	.....	561107	C162	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C64	RR JCT BOX	AMP CPC	8	.....	561107	C163	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C65	RR JCT BOX	AMP CPC	8	.....	561107	C164	BATT. & RR JB OPT MARKER LI	DEUTSCH	2	562486	561690
C66	RR JCT BOX	AMP CPC	8	.....	561107						
C67	RR JCT BOX	AMP CPC	8	.....	561107						
C68	RR JCT BOX	AMP CPC	8	.....	561107						
C69	RR JCT BOX	AMP CPC	8	.....	561107						
C70	RR JCT BOX	AMP CPC	8	.....	561107						
C71	RR JCT BOX	AMP CPC	8	.....	561107						
C72	RR JCT BOX	AMP CPC	8	.....	561107						
C73	RR JCT BOX	AMP CPC	8	.....	561107						
C74	RR JCT BOX	AMP CPC	8	.....	561107						
C75	RR JCT BOX	AMP CPC	8	.....	561107						
C76	RR JCT BOX	AMP CPC	8	.....	561107						
C77	RR JCT BOX	AMP CPC	8	.....	561107						
C78	RR JCT BOX	AMP CPC	8	.....	561107						
C79	RR JCT BOX	AMP CPC	8	.....	561107						
C80	RR JCT BOX	AMP CPC	8	.....	561107						
C81	RR JCT BOX	AMP CPC	8	.....	561107						
C82	RR JCT BOX	AMP CPC	8	.....	561107						
C83	RR JCT BOX	AMP CPC	8	.....	561107						
C84	RR JCT BOX	AMP CPC	8	.....	561107						
C85	RR JCT BOX	AMP CPC	8	.....	561107						
C86	RR JCT BOX	AMP CPC	8	.....	561107						
C87	RR JCT BOX	AMP CPC	8	.....	561107						
C88	RR JCT BOX	AMP CPC	8	.....	561107						
C89	RR JCT BOX	AMP CPC	8	.....	561107						
C90	RR JCT BOX	AMP CPC	8	.....	561107						

**PREVOST**

**WIRING**

**DIAGRAM**

**D060882**

PAGE: **G1**

REVISION **03**

# CONNECTORS CODE

NO	LOCATION	TYPE	CAVITY	#PIN HOUSING	#SOCKET HOUSING
C165	RR AXLE ABS LH VALVE	WABCO	3	.....	641098
C166	RR AXLE ABS RH VALVE	WABCO	3	.....	641098
C167	RR AXLE ABS RH SENSOR	DEUTSCH	2	562486	562485
C168	RR AXLE ABS OPT ATC	PED WP	4	561610	561611
C169	RR JCT BOX SPEED SW	AMP HDP	15	.....	562012
C170	FR JCT BOX FLASHER UNIT	TC	2	.....	561930
C171	LH CONSOLE	AMP CPC	37	561645	561646
C172	ENGINE COMP. WATER TANK HEAT	PED WP	2	561566	561690
C173	LAV POTABLE WATER TANK HEAT	AMP MNL	2	560990	560998
C174	UNDER DASH RH-HTR MODULE	AMP MNL	2	561670	561689
C175	UNDER DASH RH-HTR MODULE	AMP MNL	9	561670	561689
C176	UNDER DASH RH-WIPER PULSE	AMP FF	6	561186	561186
C177	UNDER DASH RH-WIPER MOTOR	AMP FF	6	.....	561997
C178	UNDER DASH RH-LH FAN	TC	2	561030	560997
C179	RR JCT BOX DIODE CONNECTOR	AMP MNL	2	561030	560997
C181	RR JCT BOX COMP. INT VWV	AMP CPC	15	561987	561986
C182	FR SERVICE CPT-KNEELING PAN	AMP CPC	16	561639	561640
C183	FR SERVICE CPT-KNEELING PAN	AMP MNL	4	561610	561611
C184	FR SERVICE CPT-KNEELING SW	PED WP	3	561111	561080
C185	RR JCT BOX COMP. INT VWV	PLU	30	.....	561690
C186	RR JCT BOX CPT-SPEED SIGN TR	PED WP	2	561566	561690
C186M	RR JCT BOX CPT-SPD SIGN M TR	PED WP	2	561566	561690
C187	RR JCT BOX RRM RESISTOR CON.	AMP MNL	2	561552	561515
C189	ENGINE CPT RR DOOR 9JU LT	AMP MNL	6	561566	561690
C190	ENGINE CPT RR DOOR TAIL LT	AMP MNL	2	561566	561690
C191	ENGINE CPT RR DOOR RH STOP LT	AMP MNL	2	561566	561690
C192	ENGINE CPT RR DOOR RH DIR LT	AMP MNL	2	561566	561690
C193	FR SECT. LH HAT RACK-FLUOR	AMP MNL	2	561566	561690
C194	ENGINE CPT RR DOOR LH DIR LT	AMP MNL	2	561566	561690
C195	ENGINE CPT RR DOOR LH STOP LT	AMP MNL	2	561566	561690
C196	ENGINE CPT RR DOOR CYCLO LT	AMP MNL	2	561566	561690
C199	ENGINE CPT RR DOOR LICENSE LT	AMP MNL	2	561566	561690
C200	RR HAT RACK-FLUORESCENT	DOM AUTO	2	930210	.....
C201	RR HAT RACK-FLUORESCENT	AMP MNL	4	561551	561668
C202	RR HAT RACK-BALLAST	AMP MNL	4	561551	561668
C203	RR HAT RACK-BALLAST	AMP MNL	4	560851	560852
C204	RR HAT RACK-GL N1 W/L T	AMP MNL	6	561552	561515
C205	FR SECT. RH HAT RACK-FLUOR H	AMP MNL	3	561667	561590
C206	RR HAT RACK-READING LT	AMP MNL	9	561661	561662
C207	LH HAT RACK-READING LT	AMP MNL	2	560900	560998
C208	LH HAT RACK-BALLAST	AMP MNL	2	560900	560998
C210	FR SECT. LH HAT RACK-SPEAKER	AMP MNL	4	560851	560998
C211	FR ROOF-STORE LH	AMP MNL	9	561661	561662
C212	FR ROOF-STORE RH	AMP MNL	2	560900	560998
C213	FR ROOF-CLEARANCE LT	AMP MNL	2	560900	560998
C220	RR JCT BOX-FUEL PRIME PUMP	TC	1	561070	561073
C225	FR SECT. RH HAT RACK-FLUOR	AMP MNL	2	561248	561247
C230	ENG. CPT. FUEL PRIME PUMP FEED	DEUTSCH	2	562486	562485
C231	ENG. CPT. FUEL PRIME PUMP SW	AMP MNL	2	561566	561690
C232	ENG. CPT. FUEL PRIME PUMP	AMP MNL	2	561566	561690
C233	INSTRUMENT PANEL CENTER	AMP MNL	8	561566	561690
C234	INSTRUMENT PANEL CENTER	V.D.O.	4	.....	562014
C235	INSTRUMENT PANEL CENTER	V.D.O.	4	.....	562014
C236	INSTRUMENT PANEL CENTER	AMP MNL	4	560851	560852
C237	INSTRUMENT PANEL CENTER	ITT SS	4	561111	561080
C238	RR JCT BOX-DIODE CONNECTOR	AMP MNL	3	561670	561689
C239	FR SERVICE CPT-HI BUOY VALVE	AMP MNL	9	561566	561690
C240	FR SERVICE CPT-KNEEL PROX SW	AMP MNL	2	561566	561690
C242	FR SERVICE CPT-KNEEL PROX SW	AMP MNL	2	561566	561690
C243	FR SERVICE CPT-HEADLAMPS	ITT SS	3	561111	561071
C244	FR SERVICE CPT-LH FOG LAMP	ITT SS	2	561813	561812
C245	FR SERVICE CPT-RH FOG LAMP	ITT SS	2	561813	561812
C246	FR SERVICE CPT-MARK & DIR LT	ITT SS	3	561111	561080
C248	FR JCT BOX-WIPER PULSE GEN	AMP FF	6	.....	561108

PREVOST

WIRING DIAGRAM

D060882

PAGE: G2 REVISION 03

# CONNECTORS CODE

NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET	NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET
				HOUSING	HOUSING					HOUSING	HOUSING
C 343	INSTR PANEL LH-HEADLAMP SW	SWF	8	-----	561107	C 425	FR JCT BOX-DIODES	AMP MNL	15	561987	561986
C 344	INSTR PANEL LH-HAZARD LT SW	SWF	8	-----	561107	C 426	ENGINE COMPT. CLUTCH CTR FAN	PED WP	3	561781	561782
C 345	INSTR PANEL LH-FOG LT SW	SWF	8	-----	561107	C 429	FR JCT BOX COMPT.	AMP MNL	6	561552	561515
C 346	INSTR PANEL LH-SWITCH LTS	SWF	2	-----	561837	C 430	LH CONSOLE-TIMER	AMP FF	8	561188	562363
C 347	INSTR PANEL LH-DASH LT SW	AMP MNL	2	560900	560898	C 431	LH CONSOLE-PRER HEAT.	TAB AMP	1	561540	561539
C 348	INSTR PANEL CENT-RACOR MODULE	MOLEX	6	562070	562067	C 432	ENGINE CPT.-PROX. SW. DOOR AJAR	DEUTSCH	4	562479	562477
C 350	RH CONSOLE-THERMOMETER	AMP MNL	3	561667	561550	C 433	FR SERVICE CPT. KNEEL. PRESS. SW	PED WP	2	561566	561690
C 351	LH HAT RACK-FLUOR 110V	MOLEX	4	561477	561476	C 434	FRONT JCT. BOX-DIODES	AMP MNL	15	561987	561986
C 352	RH CONSOLE-DRV TEMP SENSOR	BURNDY	4	-----	561104	C 435	FR SERVICE CPT.(RH) KNEEL. PIEZO	AMP MNL	2	560900	560898
C 353	INSTR PANEL RH-DRV FAN RHEOST	AMP MNL	6	561552	561515	C 436	RH HAT RACK-WCL CENTER ROOF ACC	AMP CPC	16	561639	561640
C 354	INSTR PANEL RH-DRV TEMP CTR	AMP MNL	6	561552	561515	C 437	RH HAT RACK-WCL FR & RR SECT.	AMP CPC	24	561642	561643
C 355	INSTR PANEL RH-FR TEMP CTR	AMP MNL	3	561667	561550	C 450	SOUND SYS. JCT. PANEL	MOLEX	4	562507	562503
C 357	INSTR PANEL RH-WATER TEMP GA	AMP MNL	3	561667	561550	C 451	WIRELESS MICRO-FIRST CPT BAG	MOLEX	2	562550	562549
C 358	INSTR PANEL RH-FUEL LEVEL GA	AMP MNL	3	561667	561550	C 452	UNDER DASH INSTR. PANEL	MOLEX	2	562550	562549
C 361	FR ROOF-WIPER MOTOR	AMP FF	6	-----	561186	C 453	SOUND SYS. JCT.PANEL-VCP	PED WP	2	561566	561680
C 362	FR ROOF-LAVATORY OCCUPIED LT	AMP MNL	2	561248	561247	C 454	SOUND SYS.JCT.PAN.-FILT. VCP	PED WP	2	561566	561680
C 363	FR ROOF-WATCH YOUR STEP LT	AMP MNL	2	561248	561247	C 455	WIRELESS MICRO-LH HAT-RACK	CINCH	2	562554	562551
C 364	FR ROOF-DESTINATION SIGN	AMP MNL	3	561667	561550	C 456	WORLD TRANSM.-RETARDER ACCUM.	PED MP	2	-----	562427
C 365	FR ROOF-UP WINDSHIELD DEFROST	AMP MNL	3	561667	561550	C 457	WORLD TRANSM.-MAIN CONNECTOR	DEUTSCH	31	562572	562536
C 366	RH DASH PANEL-GRN & RED LEDS	AMP MNL	3	560908	562006	C 458	WORLD TRANSM.-TURBINE SP.SENS	PED MP	2	-----	562426
C 367	ENGINE COMPT-DIF OIL T SENSOR	PED WP	2	561566	561690	C 459	WORLD TRANSM.-ENGINE SP.SENS.	PED MP	2	-----	562426
C 368	FR ROOF-DEST. SIGN BALLAST	AMP MNL	3	561667	561550	C 460	WORLD TRANSM.-SPEED SENSOR	ITT	2	-----	562541
C 369	FR ROOF-DEST. SIGN OPER. SW	TORRIX	5	-----	562110	C 461	WORLD TRANSM.-RETARDER TEMP.	PED MP	2	561566	561680
C 370	FR ROOF-DEST. SIGN FLUOR.	AMP MNL	2	560900	560898	C 462	WORLD TRANSM.-RETARD SOL."K"	PED MP	2	-----	562426
C 371	FR ROOF-DEST. SIGN FLUOR.	AMP MNL	2	560900	560898	C 463	WORLD TRANSM.-SENSOR CONN.	DEUTSCH	16	562570	562571
C 372	FR ROOF-DEST. SIGN SPEED SW	MOLEX	4	561477	561476	C 464	RR JCT BOX-DDL CONN W. T.	PED MP	12	-----	562574
C 373	FR ROOF-NO SMOKING LT	AMP MNL	2	561248	561247	C 465	LH CONSOLE-SHIFTER SELECTOR	T & BET	10	-----	562429
C 374	LH SWITCH PANEL	AMP MNL	6	561552	561515	C 466	FR SERVICE CPT.-RESIS. MOD.	PED WP	3	-----	562428
C 376	LH SWITCH PANEL	AMP CPC	37	561714	562005	C 467	FR SERVICE CPT.-RESIS. MOD.	PED WP	3	-----	562428
C 377	LH SW PANEL-STOP ENG.OVERRIDE	SWF	8	-----	561107	C 468	RR JCT BOX-VIM MOD. W.T.	PED MP	18	-----	562573
C 380	LH CONSOLE-DDR CONNECTOR	DEUTSCH	6	562360	-----	C 470	FR LH UPPER WHELL CPT-SILENT 1000	AMP MNL	2	561248	561247
C 386	LH CONSOLE-WCL POWER SYSTEM	SWF	8	-----	561107	C 471	FR LH UPPER WHELL CPT-SILENT 1000	AMP MNL	2	561248	561247
C 387	RR JCT BOX (WCL)	AMP MNL	9	561661	561662	C 472	FR LH UPPER WHELL CPT-SILENT 1000	PED WP	2	561566	561690
C 388	RR JCT BOX (WCL)	AMP MNL	12	561735	561734	C 473	FR LH UPPER WHELL CPT-SILENT 1000	AMP MNL	3	561667	561550
C 389	WCL REAR DOOR	MOLEX	4	561477	561476	C 474	LUGGAGE CPT.-TEMP. SENSOR	AMP MNL	2	561247	561248
C 390	LAVATORY WALL-WCL REMOTE CTR	SWF	8	-----	561107	C 475	RR JCT BOX-SPEED SIGN CONNECTOR	AMP MNL	2	561248	561247
C 391	LAVATORY WALL-WCL LAMP	SWF	8	-----	561107	C 475M	RR JCT BOX-SPEED SIGN MANUAL TR.	MOLEX	6	562070	562069
C 392	LAVATORY WALL-WCL SW. LT.	SWF	2	-----	561835	C 475W	RR JCT BOX-SPEED SIGN WORLD TR.	MOLEX	6	562070	562069
C 393	LAVATORY WALL-WCL REMOTE SYS.	AMP CPC	4	561686	561687	C 476	RR JCT BOX-VIM WORLD TRANSM.	AMP CPC	16	561639	561640
C 394	UNDER INSTR. PANEL- B/U MONITOR	AMP MNL	4	560851	560852	C 477	RR JCT BOX-WORLD TR. SHIFT &RET.	AMP CPC	9	561636	561637
C 395	DRIVER'S COMPT. - B/U MONITOR	AMP	5	-----	-----	C 478	ELECTRONIC DESTINATION SIGN	AMP CPC	9	561636	561637
C 396	FR SECT. LH HAT RACK-SPEAKER	MOLEX	4	562507	562503	C 483	FR SERVICE CPT. (NOT USED)	PED PC	2	-----	562237
C 397	ENGINE COMPT. CRADLE ACC.	DEUTSCH	40	562281	562284	C 500	FR LH UPPER WHELL CPT -PRODRIVER	MOLEX	6	562070	562069
C 400	ENGINE COMPT. BLOCK HEATER	PED MP	3	561781	561782	C 501	FR LH UPPER WHELL CPT -PRODRIVER MOD	PED MP	7	562433	-----
C 402	RR DRIVE AXLE-AIR DRYER	PED MP	2	-----	562251	C 502	LH CONSOLE-PRE HEATER SW.	SWF	8	-----	561107
C 403	GALLEY FRIGO NORCOLD	AMP MNL	2	561248	561247	C 503	LH CONSOLE-PRE HEATER SW.	SWF	2	-----	561837
C 404	GALLEY LAMP	AMP MNL	2	561248	561247	C 504	LH CONSOLE WEBASTO TIMER	AMP	8	561188	562363
C 406	FR JCT BOX COMPT.-ABS	AMP MNL	2	560900	560898	C 505	LH CONSOLE ESPAR TIMER	AMP	12	-----	562681
C 407	ENGINE COMPT. -SIGNAL	PED WP	6	561606	561607	C 506	FR JCT BOX CPT. DIGITAL CLOCK	AMP	4	561685	561687
C 408	ENGINE COMPT. -SIGNAL	PED WP	6	561606	561607	C 507	FR SECT. LH HAT-RACK DIG. CLOCK	MOLEX	4	561477	561476
C 409	ENGINE CPT -LOW COOL. LEVEL	PED MP	2	-----	562350	C 508	RR JCT BOX-FAN CLUTCH RETARDER	AMP MNL	6	561552	561515
C 410	FR JCT BOX-DIODE CONNECTOR	AMP MNL	15	561987	561986	C 509	FR LH UPPER WHELL CPT -DATA LOGGER	PED MP	16	-----	562530
C 411	FR JCT BOX-DIODE CONNECTOR	AMP MNL	15	561987	561986	C 510	FR LH UPPER WHELL CPT -DATA LOGGER	DEUTSCH	9	562531	-----
C 412	LH SW PANEL-MASTER SWITCH	SWF	8	-----	561107	C 511	FR LH UPPER WHELL CPT -DATA LOGGER	PED MP	4	562532	-----
C 413	ENG CPT-AVC HI UNLOAD PRS SW	PED WP	2	561566	561690	C 512	FR LH UPPER WHELL CPT -DATA LOGGER	PED MP	10	562533	-----
C 414	RR JCT BOX	AMP MNL	9	561670	561669	C 513	FR LH UPPER WHELL CPT -DATA LOGGER	AMP MNL	3	561667	561550
C 415	ENGINE CRADLE-FAN SIGNAL	PED WP	3	561781	561782	C 514	FR LH UPPER WHELL CPT -DATA LOGGER	PED MP	6	562433	562417
C 416	ENGINE CRADLE-FAN SIGNAL	PED P-C	3	562237	-----	C 515	RH DASH PANEL-T.T.LT.	AMP CPC	14	561585	561583
C 417	FRONT JCT BOX-DIODES	AMP MNL	15	561987	561986	C 515	FR JCT BOX CPT.-INTERCOM	MOLEX	4	561477	561476
C 418	INSTR. PANEL LH-HTR WINDSH.SW	SWF	8	-----	561107	C 516	CENTER DASH PANEL -UPPER T.T.LT.	AMP CPC	24	561642	561643
C 419	FR JCT BOX-RETARDER OR JACOB	AMP MNL	3	561667	561550	C 516	FR JCT BOX CPT.-INTERCOM	MOLEX	6	562070	562069
C 420	ENGINE COMPT. WEBASTO WATER HTR	TC	2	561597	-----	C 517	CENTER DASH PANEL -LOWER T.T.LT.	AMP CPC	24	561642	561643
C 421	ENGINE COMPT. WEBASTO WATER HTR	TC	1	561073	-----	C 517	LAVATORY WALL-INTERCOM	MOLEX	6	562070	562069
C 422	ENGINE COMPT. WEBASTO WATER HTR	TC	2	561597	-----	C 519	UNDER DASH RH-SEDAN DOOR	HUMPHREY	2	-----	562580
C 424	UNDER INSTRUMENT PANEL CENTER	AMP MNL	3	561667	561550	C 520	UNDER DASH RH-SEDAN DOOR	HUMPHREY	2	-----	641385

# CONNECTORS CODE

NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET	NO	LOCATION	TYPE	CAVITY	#PIN	#SOCKET
				HOUSING	HOUSING					HOUSING	HOUSING
C 521	UNDER DASH RH-SEDAN DOOR	HUMPHREY	2	-----	641385						
C 522	FR JCT BOX-DAYTIME LTS MODULE	BOSCH	5	-----	561183						
C 523	FR JCT BOX-FUSE BLOCK	PED	8	562647	562646						
C 524	FR JCT BOX-FUSE BLOCK	PED	8	562647	562646						
C 525	FR JCT BOX-FUSE BLOCK	PED	8	562647	562646						
C 526	FR JCT BOX-FUSE BLOCK	PED	8	562647	562646						
C 527	FR JCT BOX-FUSE BLOCK	PED	8	562647	562646						
C 528	FR JCT BOX-FUSE BLOCK	PED	8	562647	562646						
C 529	FR JCT BOX-12V OUTLET	AMP MNL	2	561247	561248						
C 530	RR JCT BOX-FUSE BLOCK	PED	8	562647	562646						
C 531	RR JCT BOX-FUSE BLOCK	PED	8	562647	562646						
C 532	RR JCT BOX-FUSE BLOCK	PED	8	562647	562646						
C 533	RR JCT BOX-FUSE BLOCK	PED	8	562647	562646						
C 534	RR JCT BOX-FUSE BLOCK	PED	8	562647	562646						
C 535	RR JCT BOX-FIRE MODULE DETECT.	AMP MNL	3	561667	561550						
C 536	UNDER DASH RH-DRIVER'S HTR TEMP. CTR	AMP MNL	6	561552	561515						
C 537	BATT. CPT.-A/C PRESS. SIGN. RLY	AMP MNL	2	561248	561247						
C 538	FR SERVICE CPT.-OUTSIDE TEMP. SENSOR	AMP MNL	2	561248	561247						
C 539	RH DASH PANEL-THERMOMETER SOUND	AMP MNL	2	561248	561247						
C 540	RH DASH PANEL-THERMOMETER SOUND	AMP MNL	2	561248	561247						
C 541	SOUND SYS. JCT PANEL-AUDIO SEAT SYS.	PED WP	2	561566	561690						
C 542	LH HAT RACK-AUDIO SEAT SYSTEM	AMP MNL	3	561667	561550						
C 543	RR JCT BOX-PARK. BRAKE STOP LTS RESIS.	PED WP	2	561566	561690						
C 544	SOUND SYS JCT PANEL-AUDIO SEAT SYS.	PED WP	3	561781	562428						
C 545	LH HAT RACK-AUDIO SEAT SYSTEM	AMP MNL	3	561667	561550						
C 546	LH DASH PANEL-ACCESSORIES	AMP CPC	37	561645	561646						
C 547	RH DASH PANEL-ACCESSORIES	AMP CPC	37	561645	561646						
C 548	LH DASH PANEL-T.T. LT. TEST SW.	SWF	8	-----	561107						
C 549	LH CONSOLE-FAN CLUTCH OVERRIDE SW.	SWF	8	-----	561107						
C 550	EVAPORATOR COMPARTMENT	ITT	2	561813	562159						
C 551	RR JCT BOX - A/C PANEL	PED	2	561566	561690						