

DIODES NUMBER CODE

No.	PAGE	AMP	#PREV.	LOCATION	FUNCTION	No.	PAGE	AMP	#PREV.	LOCATION	FUNCTION
D 1	7	3A	561740	FR JCT BOX	LO-AIR SONALERT-PRIMARY	D 88	16	3A	561740	UNDER DASH RH	ENTRANCE DOOR SEDAN
D 2	7	3A	561740	FR JCT BOX	LO-AIR SONALERT-SECONDARY	D 89	16	3A	561740	UNDER DASH RH	ENTRANCE DOOR SEDAN
D 4	9.2	3A	561740	FR JCT BOX	WARNING HAZARD-RH	D 90	16	3A	561740	UNDER DASH RH	ENTRANCE DOOR SEDAN
D 5	9.2	3A	561740	FR JCT BOX	WARNING HAZARD-LH	D 91	16	3A	561740	UNDER DASH RH	ENTRANCE DOOR SEDAN
D 6	5	3A	561740	FR JCT BOX	WCL NEUT. SIGN INTERFACE TO PARK BRK TTLT						
D 9	12	3A	561740	FR L.H. HAT-RACK	HOSTESS & PASSENGER CHIME						
D 11	17	3A	561740	RR JCT BOX	LAVATORY OCCUPIED SIGN						
D 12	17	3A	561740	RR JCT BOX	LAVATORY OCCUPIED SIGN						
D 13	17	3A	561740	FR DEST. SIGN	FR DESTINATION SIGN						
D 14	17	3A	561740	FR DEST. SIGN	FR DESTINATION SIGN						
D 15	18	3A	561740	FR JCT BOX	KNEELING SYSTEM CTR-UP						
D 16	18	3A	561740	FR JCT BOX	KNEELING SYSTEM CTR-DOWN						
D 17	9.2	3A	561740	FR JCT BOX	WARNING HAZARD-LH						
D 18	9.2	3A	561740	FR JCT BOX	WARNING HAZARD-RH						
D 19	9	3A	561740	FR JCT BOX	DAYTIME RUN LTS-PARK BRK CALL SW.						
D 20	9	3A	561740	FR JCT BOX	DAYTIME RUN LTS-HEAD LT SW						
D 21	18	3A	561740	FR JCT BOX	KNEELING SYSTEM FEED BACK						
D 25	11.1	3A	561740	FR JCT BOX	LUGGAGE DOOR AJAR T.T.LT.						
D 26	11.1	3A	561740	FR JCT BOX	LUGGAGE DOOR AJAR T.T.LT.						
D 27	11.1	3A	561740	FR JCT BOX	LUGGAGE DOOR AJAR T.T.LT.						
D 28	11.1	3A	561740	FR JCT BOX	LUGGAGE DOOR AJAR T.T.LT.						
D 29	11.1	3A	561740	FR JCT BOX	LUGGAGE DOOR AJAR T.T.LT.						
D 30	11.1	3A	561740	FR JCT BOX	LUGGAGE DOOR AJAR T.T.LT.						
D 32	11.3	3A	561740	FRONT ROOF CABL.	DRIVER'S LTS FEED BY STEP LTS						
D 33	11.3	3A	561740	FRONT ROOF CABL.	DRIVER'S LTS FEED BY STEP LTS						
D 35	25	3A	561740	RR JCT BOX	WCL DOOR AJAR ALARM T.T.LT.						
D 43	10	3A	561740	LOWER WIPER MOT.	WIPER MOTOR SUPPRESSOR						
D 44	10	3A	561740	LOWER WIPER MOT.	WIPER MOTOR SUPPRESSOR						
D 45	10	3A	561740	LOWER WIPER MOT.	WIPER MOTOR SUPPRESSOR						
D 58	17	3A	561740	FR JCT BOX	RR HIGH BUOY - KNEELING						
D 59	13.1	3A	561740	RJB A/C JCT PANEL	A/C & HEAT BYPASS SWITCH						
D 60	13.1	3A	561740	RJB A/C JCT PANEL	A/C COMPR.CLUTCH SUPPRESSOR						
D 61	9.2	3A	561740	FR JCT BOX	KNEELING SIDE FR RH DIRECTIONNAL LT						
D 62	13.1	3A	561740	RJB A/C JCT PANEL	WATER PUMP FEED						
D 63	17	3A	561740	FR JCT BOX	LAVATORY SONALERT						
D 64	17	3A	561740	FR JCT BOX	WCL DOOR ALARM						
D 65	13.1	3A	561740	RJB A/C JCT PANEL	WATER PUMP - PRE-HEAT FEED						
D 66	13.1	3A	561740	RJB A/C JCT PANEL	WATER VALVE - HEAT SW. FEED						
D 67	9.2	3A	561740	UNDER DASH	AUDIBLE FLASHER RLY - RH						
D 68	9.2	3A	561740	UNDER DASH	AUDIBLE FLASHER RLY - LH						
D 70	18	3A	561740	FR JCT BOX	FR HIGH BUOY - KNEELING						
D 71	18	3A	561740	FR JCT BOX	FR HIGH BUOY - KNEELING						
D 72	18	3A	561740	FR JCT BOX	FR HIGH BUOY - KNEELING						
D 73	18	3A	561740	FR JCT BOX	FR HIGH BUOY - KNEELING						
D 74	1	3A	561740	FR JCT BOX	DASH MASTER CUT OUT SW.						
D 75	4	3A	381351	BAT CPT	STARTER-SUPPRESSOR COIL RLY						
D 77	18	3A	561740	FR JCT BOX	PARKING BRAKE - KNEELING						
D 78	26	3A	561740	LH CONSOLE	PRE-HEAT WATER HEATER SW.						
D 79	26	3A	561740	LH CONSOLE	PRE-HEAT WATER HEATER SW.						
D 81	18	3A	561740	FR JCT BOX	PIEZO-KNEELING						
D 82	18	3A	561740	FR JCT BOX	PIEZO-KNEELING						
D 83	8	3A	561740	RR JCT BOX	FAN CLUTCH W/RETARDER						
D 84	13.1	3A	561740	RJB A/C JCT PANEL	WATER VALVE						
D 85	13.1	3A	561740	RJB A/C JCT PANEL	WATER PUMP						
D 86	16	3A	561740	UNDER DASH RH	ENTRANCE DOOR SEDAN						
D 87	16	3A	561740	UNDER DASH RH	ENTRANCE DOOR SEDAN						