

NO.	PAGE	OHM(S)	*PREVOST	LOCATION	FUNCTION
RS1	5	11 K	561898	FR JCT BOX	FAST IDLE DDEC CONTROL
RS2	5	3.6 K	561897	FR JCT BOX	FAST IDLE DDEC CONTROL
RS3	11	1 (2)	561537	FR SERV. COMPT.	FOG LT - RH
RS4	11	1 (2)	561537	FR SERV. COMPT.	FOG LT - LH
RS5	10	1 (2)	061976	FR JCT BOX	CORNERING LT - LH
RS7	11	.82 (2)	060806	RR JCT BOX	PARKING BRAKE STOP LTS
RS8	10	1 (2)	061976	FR JCT BOX	CORNERING LT - RH
RS9	11	1 (2)	061976	RR JCT BOX	DOCKING LT - RH
RS10	11	1 (2)	061976	RR JCT BOX	DOCKING LT - LH
RS11	28	12	561191	FR TOP	DEFROSTER SPEED
RS12	28	12	561191	FR TOP	DEFROSTER SPEED
RS13	23	80	562108	FR TOP	FR DESTINATION SIGN
RS14	9	.82 (2)	060806	FR JCT BOX	DAYTIME RUN LTS
RS17	7	220	562498	ALARM JCT.BOX	FIRE ALARM
RS18	8	75 K	064208	RR JCT BOX	FAN CLUTCH W/RETARDER
RS20	21	1 K	562470	RR JCT BOX	WORLD TR. SPEED TO DDEC III
RS21	19	3.32 K	562617	A/C JCT BOX	A/C FRESH AIR RESISTOR

NO.	PAGE	OHM(S)	*PREVOST	LOCATION	FUNCTION
-----	------	--------	----------	----------	----------