

Page G - 1 CONNECTORS CODE (C) Table with columns: No., LOCATION, TYPE, INB, *PIN, *SOCKET, HOUSING, HOUSING. Contains wiring data for components like UNDER DASH LH, LH CONSOLE SW-MIRROR, etc.

Page G - 1 CONNECTORS CODE (C) Table with columns: No., LOCATION, TYPE, INB, *PIN, *SOCKET, HOUSING, HOUSING. Continuation of wiring data from previous page.

Page G - 2 CONNECTORS CODE (C) Table with columns: No., LOCATION, TYPE, INB, *PIN, *SOCKET, HOUSING, HOUSING. Contains wiring data for components like FR SERV OPT-KNEEL MOD BRK, LH CONSOLE SW-GENERAL LTS, etc.

Page G - 3 CONNECTORS CODE (C) Table with columns: No., LOCATION, TYPE, INB, *PIN, *SOCKET, HOUSING, HOUSING. Contains wiring data for components like WORLD TRANSM-RETARDER ACCUM PED, WORLD TRANSM-TURNING SP SENS PED, etc.