

RESISTORS LIST

No	Location	Part #	Function	Page					
Res3	Parcel_Rack	563593	CAN_Nertwork	6,1					
Res4	RH_Console	563593	CAN_Nertwork	6,1					
Res6	RJB	563593	DBus_Network	6,2					
Res7	Dash	563593	J1939Network	6,2					
Res10	Dash	562892	KeypadBacklighting	10,1					
Res14	Evap_Cmpt	563205	CondFans	18,2					
Res15	Engine_Cmpt	563587	Flamedetection	38,1					
Res20	Dash	563593	CAN1Network	42,1					
Res24	RJB	565156	FuelTankGnd	2,2					
Res25	FJB	562470	StairFanCtrl	18,2					
Res26	FJB	561897	StairFanCtrl	18,2					
Res31	Fuel_Tank	41123	HeatedelementforUreatank	14,2					
Res32	Fuel_Tank	41123	HeatedelementforUreatank	14,2					
Res37	Front_Clearance	*opt*	UpperDefrost	18,4					
Res46	FJB	563593	J1939Network	39,1					
Res53	Dash	563593	J2284Network	6,2					