

CIRCUITS LIST

CircuitID	Description	CircuitID	Description	CircuitID	Description
0	GNDBatteries	0W	WCL	A5.B	TransmissionAlisson
0A	GNDChassis	0WC	GndWCLRemoteCTRL	A8.1	ClockSpringSig
00A	Keylessentrysystem	12Ecu	12VECU	A8.2	ClockSpringLIN
00A2	eMirrors_VS	12ISH	Pwrl_Shift	A8.3	ClockSpringLIN
0AItEXTR	ChassisGnd	12VA	Batteries	A8.4	ClockSpringSig
0AItL	GNDChassis	12VD	Batteries	A8.6	ClockSpringSig
0AItR	GNDChassis	12VD1	12VD	A9CX1.2	Cluster
0AItUL	GNDChassis	24RHC	24VVECRHC	A9CX1.4	ESP
0B	GNDChassis	24VA	Batteries	A9CX1.5	ESP
00B	LuggagesLocksSwitchesSignal	24VD	Batteries	A9CX1.6	ESP
0C	Ignition&enginestart	24VD1	Booster_Block	A9CX2.1	ESP
0COND	A/C	24VD2	Equalizer	A9CX2.2	ESP
0ECU	EngineECUVolvo	24VD3	Ignition&enginestart	A9CX2.3	ESP
0EVAP1	HVACpassengers	24VI	24WUP	A9CX2.4	ESP
0F	GNDChassis	170K	LuggagesLocksSwitchesSignal	A9CX2.6	ESP
00F	FJBelectronicGND	170S	LuggagesLocksSwitchesSignal	A9CX2.7	ESP
00F1	Multiplexpower	170T	LuggagesLocksSwitchesSignal	A9CX2.9	ESP
00F2	Multiplexpower	900	Networks	A9CX2.10	ESP
00F4	FJB	901	Networks	A9CX2.12	ESP
00F5	Trailer	_00	GNDBatteries	A9CX2.13	ESP
00F6	ElectronicGnd	A1.11	TransmissionAlisson	A9CX2.16	ESP
0FA	GNDChassis	A1.12	TransmissionAlisson	A9CX2.17	ESP
0FA2	GndAuxLiqSolenoidValve	A1.15	TransmissionAlisson	A9CX3.3	ESP
0FE	GNDstud	A1.16	TransmissionAlisson	A9CX3.5	ESP
0FH	WipersChassisGnd	A1.18	TransmissionAlisson	A9CX3.7	ESP
00FR	FJB-RJBjunction	A1.19	TransmissionAlisson	A9CX3.9	ESP
0R	GNDChassis	A1.24	TransmissionAlisson	A9CX3.10	ESP
0OR	Networks	A1.25	TransmissionAlisson	A9CX4.1	ESP
0OR1	Masterrelay&12Vlgn	A1.31	TransmissionAlisson	A9CX4.4	ESP
0OR2	Multiplexpower	A1.33	TransmissionAlisson	A9CX4.7	ESP
0OR3	Multiplexpower	A1.36	TransmissionAlisson	A9CX4.8	ESP
0OR4	Multiplexpower	A1.37	TransmissionAlisson	A9CX4.10	ESP
0OR5	RJBelectronicGND	A1.51	TransmissionAlisson	A9CX4.11	ESP
0OR6	Multiplexpower	A1.52	TransmissionAlisson	A12.2	StalkBaseLIN
0RAD	GNDChassis	A1.54	TransmissionAlisson	A12.3	StalkBaseLIN
0RAD2	Fansdriveelectric	A1.55	TransmissionAlisson	A14.B1	Cluster
0RC	ChassisGnd	A1.58	TransmissionAlisson	A14.B18	Cluster
0ORHC	ElectronicGnd	A1.71	TransmissionAlisson	A14A.2	WiperSig
0ORHC1	ElectronicGnd	A1.74	TransmissionAlisson	A14A.3	WiperSig
0ORHC2	Multiplexpower	A1.76	TransmissionAlisson	A14A.6	StalkBasePwr
0SO	Slideout	A1.77	TransmissionAlisson	A14A.11	FlasherSig
0TR.White	Trailer	A2A.9	TransmissionAlisson	A14A.12	FlasherSig
00VA	RJBelectronicGND	A2A.11	TransmissionAlisson	A14C.1	Cluster

CIRCUITS LIST

CircuitID	Description	CircuitID	Description	CircuitID	Description
A14D.2	Cluster	A41J1.4	Brake	A45J1.10	TagSystem
A21.1	WiperSig	A41J1.7	Shutdown	A45J1.16	Mirrors
A21.B1	WiperSig	A41J1.10	Keylessentrysystem	A45J1.19	WakeUpCustomer
A21.B2	WiperSig	A41J1.13	EntranceDoorLights	A45J2.7	TagSystem
A27.30	ZFsteering	A41J1.16	EngineECUVolvo	A45J2.10	StatusLedPwr
A27.87A	ZFsteering	A41J1.19	EngineECUVolvo	A45J2.13	Frflashers
A31J1.5	Keylessentrysystem	A41RJ1.6	Keylessentrysystem	A45RJ1.5	StatusLedPwrRtn
A31J1.6	Keylessentrysystem	A41RJ1.18	Cmpt.lights	A45RJ1.6	Keylessentrysystem
A31J1.10	Keyless	A41RJ2.14	FJB	A45RJ1.18	TagGnd
A31J2.1	Keyless	A42J1.3	FJB	A45RJ2.2	Frflashers
A31J2.7	Keylessentrysystem	A42J1.4	FJB	A46J1.1	LuggageDoorLockRH
A31J2.8	Keylessentrysystem	A42J1.7	FJB	A46J1.3	LuggageDoorLockRH
A31J2.10	EntDoorUnLatch	A42J1.10	Kneeling	A46J1.4	Keylessentrysystem
A31J5.3	Keylessentrysystem	A42J1.13	Kneeling	A46J2.1	LuggageDoorLockLH
A32C.A	Auxiliarydefrost	A42J1.16	FJB	A46J2.4	LuggageDoorLock
A32C.B	Auxiliarydefrost	A42J1.18	FJB	A46RJ2.2	GndAuxLiqSolenoidValve
A34.A5	Fansdriveelectric	A42J2.15	FJB	A47J1.1	HVACdefroster
A34.B5	Fansdriveelectric	A43J1.10	Entracedoor	A47J1.3	HVACdefroster
A34.C5	Fansdriveelectric	A43J1.13	ZFsteering	A47J1.4	LHFlasherBrigade
A34.D5	Fansdriveelectric	A43J1.19	TPMS	A47J1.7	HeadLampModuleLH
A34.E5	Fansdriveelectric	A43J2.1	LuggageDoorLockRH	A47J1.13	HeadLampModuleLH
A34.F5	Fansdriveelectric	A43J2.4	LuggageDoorLockRH	A47J1.16	FogLH
A34.G5	Fansdriveelectric	A43J2.7	LuggageDoorLock	A47J1.19	HeadLampModuleLH
A34.H5	Fansdriveelectric	A43J2.10	LuggageDoorLockLH	A47J1.4	LHFlasherBrigade
A34J.E	Fansdriveelectric	A43RJ1.17	TPMS	A47J2.7	HeadLampModuleLH
A34J.F	Fansdriveelectric	A43RJ1.18	Entracedoor	A47J2.10	HeadLampModuleLH
A34R.A3	Fansdriveelectric	A43RJ2.2	Airdryer	A47J2.13	HeadLampModuleLH
A34R.B3	Fansdriveelectric	A44J1.13	AuxiliaruLiqSolValve	A47RJ1.17	HeadLampModuleLH
A34R.C3	Fansdriveelectric	A44J1.16	Horn	A47RJ2.2	Cornering&foglights
A34R.D3	Fansdriveelectric	A44J1.19	Cmpt.lights	A48J1.4	HVACdefroster
A34R.E3	Fansdriveelectric	A44J2.1	Sunvisor	A48J1.7	HVACdefroster
A34R.F3	Fansdriveelectric	A44J2.4	Sunvisor	A48J1.16	EntDoorUpperPenSol
A34R.G3	Fansdriveelectric	A44J2.7	AuxiliaryFanSpeedControl	A48J2.1	DefrosterFan
A34R.H3	Fansdriveelectric	A44J2.10	Sunvisor	A48J2.4	Recycledefrostdamper
A36AJA.10	Horn	A44J2.13	Sunvisor	A48J2.7	Dashdamper
A36JA.7	Ignition&enginestart	A44RJ1.17	Horn	A48J2.10	SmallA/C
A36JA.10	ISM	A44RJ2.2	Driverlights	A48J2.15	SmallA/C
A36JA.15	Ignition&enginestart	A44RJ2.3	Wipers&washer	A48RJ1.6	SmallA/C
A36JA.16	ISM	A44RJ2.14	AuxiliaryFanSpeedControl	A48RJ1.17	HVACdefroster
A36JA.17	Ignition	A45J1.1	Driverwindow	A48RJ1.18	DefrostSystGnd
A36JB.2	Ignition	A45J1.3	Driverwindow	A48RJ2.3	SmallA/C
A40.3.Blue	Trailer	A45J1.4	Ignition&enginestart	A49J1.1	Driverlights
A41J1.3	Driverlights	A45J1.7	BackupCam	A49J1.3	HeadLampModuleRH

CIRCUITS LIST

CircuitID	Description	CircuitID	Description	CircuitID	Description
A49J1.4	Wipers&washer	A51RJ2.2	Back-upwarnings	A55J1.1	StartButtonLed
A49J1.7	HeadLampModuleRH	A52J1.1	Dockinglights	A55J1.4	Cluster
A49J1.10	RHFlasherBrigade	A52J1.3	Dockinglights	A55J1.7	ElectronicMirror
A49J1.13	HeadLampModuleRH	A52J1.4	Rrflashers	A55J1.10	ElectronicMirror
A49J1.16	FogRH	A52J1.7	Rrflashers	A55J1.13	HUDSystem
A49J1.19	HeadLampModuleRH	A52J1.10	Rrflashers	A55J1.16	ElectronicMirror
A49J1:10	RHFlasherBrigade	A52J1.13	Rrflashers	A55J1.19	StartSw
A49J2.1	HeadLampModuleRH	A52J1.16	TransmissionAlisson	A55J2.15	DayLightSe
A49J2.4	Axialfan	A52J1.19	WCL	A55RJ1.6	HUDGnd
A49J2.13	HeadLampModuleRH	A52J2.1	Rrflashers	A55RJ1.18	ValveMirrorAirPressureGnd
A49J2.15	PwrDriver'sHumiditySe	A52J2.4	TransmissionAlisson	A56J1.1	24VI
A49RJ1.6	HVACdefroster	A52J2.7	Rrflashers	A56J1.3	Cluster
A49RJ1.17	Cornering&foglights	A52J2.10	Rrflashers	A56J1.4	Cluster
A49RJ2.2	HeadLampModuleRH	A52J2.13	Back-upcamera	A56J1.7	Cluster
A50J1.1	Fansdriveelectric	A52RJ1.5	Dockinglights	A56J1.10	Cluster
A50J1.3	Fansdriveelectric	A52RJ1.17	Rrflashers	A56J1.13	Multiplexpower
A50J1.10	HVACpassengers	A52RJ1.18	WCL	A56J1.16	ClusterFasherTrig
A50J1.13	Trailer	A52RJ2.3	Back-upcamera	A57J1.1	WCL
A50J1.18	SmallA/C	A53J1.1	Fansdriveelectric	A57J1.3	WCL
A50J1.19	Trailer	A53J1.3	Fansdriveelectric	A57J1.19	WCL
A50J2.1	Alternators	A53J1.7	Engine&RJBcmpt.lights	A57RJ1.18	WCLsystem
A50J2.4	Axialfan	A53J1.10	Ignition&enginestart	A58J1.1	Slideout
A50J2.10	Trailer	A53J1.13	RJBfan	A58J1.4	Slideout
A50J2.13	Brake	A53J2.1	Alternators	A58J1.7	Slideout
A50J2.15	SmallA/C	A53J2.4	Alternators	A58J1.10	Slideout
A50RJ1.6	SmallA/C	A53J2.13	Ignition&enginestart	A58J1.16	Slideout
A50RJ1.18	HVACpassengers	A53RJ1.17	RJBfan	A58J1.19	Slideout
A50RJ2.2	Fansdriveelectric	A53RJ1.18	Engine&RJBcmpt.lights	A58J2.1	Slideout
A50RJ2.3	SmallA/C	A54J1.1	HVACpassengers	A58J2.4	Slideout
A51J1.4	MarkrRHFrSide	A54J1.3	HVACpassengers	A58J2.11	Slideout
A51J1.7	Back-upwarnings	A54J1.7	HVACpassengers	A58J2.15	Slideout
A51J1.10	Rrflashers	A54J1.10	Waterpump	A58RJ1.17	Slideout
A51J1.13	Rrflashers	A54J1.19	HVACpassengers	A58RJ2.2	Slideout
A51J1.16	FlasherRHFrSide	A54J2.4	HVACpassengers	A58RJ2.14	Slideout
A51J1.19	Rrflashers	A54J2.7	HVACpassengers	A59J1.1	Slideout
A51J2.1	Rrflashers	A54J2.10	HVACpassengers	A59J1.4	Slideout
A51J2.7	Rrflashers	A54J2.15	HVACpassengers	A59J1.7	Slideout
A51J2.10	Back-upwarnings	A54RJ1.6	HVACpassengers	A59J1.10	Slideout
A51J2.15	PwrTagePressureSe	A54RJ1.17	HVACpassengers	A59J1.16	Slideout
A51RJ1.5	Rrflashers	A54RJ1.18	HVACpassengers	A59J1.19	Slideout
A51RJ1.6	GndTagPressureSe	A54RJ2.2	Cond.doorswitch	A59J2.15	Slideout
A51RJ1.17	Rrflashers	A54RJ2.3	HVACpassengers	A59RJ1.17	Slideout
A51RJ1.18	Rrflashers	A54RJ2.14	HVACpassengers	A59RJ2.2	Slideout

CIRCUITS LIST

CircuitID	Description	CircuitID	Description	CircuitID	Description
A59RJ2.14	Slideout	A81JB.6	ZFsteering	ANT_A_CANH	TPMS
A60J1.1	Slideout	A108.5	TransmissionI_Shift	ANT_A_CANL	TPMS
A60J1.4	Slideout	A120B.3	Sound_System	ANT_A_GND	TpmsAntennaGnd
A60J1.7	Slideout	A120B.4	Sound_System	ANT_A_PWR	TpmsAntennaPwr
A60J1.10	Slideout	A120B.5	Sound_System	ANT_B_CANH	TPMS
A60J1.16	Slideout	A120B.6	Sound_System	ANT_B_CANL	TPMS
A60J1.19	Slideout	A120C1.1	Sound_System	ANT_B_GND	TpmsAntennaGnd
A60J2.15	Slideout	A120C1.3	Sound_System	ANT_B_PWR	TpmsAntennaPwr
A60RJ1.17	Slideout	A120C3.14	Sound_System	ANT_C_CANH	TPMS
A60RJ2.2	Slideout	A120C3.19	Sound_System	ANT_C_CANL	TPMS
A60RJ2.14	Slideout	A130.3	Firesuppression	ANT_C_GND	TpmsAntennaGnd
A61J1.1	Slideout	A130.4	Firesuppression	ANT_C_PWR	TpmsAntennaPwr
A61J1.3	Slideout	A130.6	Firesuppression	B85.2	Ureasystem
A61J1.4	Slideout	A130.8	Firesuppression	B97.2	Ureasystem
A61J1.7	Slideout	A130.11	Firesuppression	B98.2	Ureasystem
A61J1.10	Slideout	A131A.C	Firesuppression	B99.2	UreaSystemSensor
A61J1.16	Slideout	A131B.A	Firesuppression	B115A.3	Ureasystem
A61J1.19	Slideout	A131B.C	Firesuppression	BLK-OR	Sound_System
A61J2.1	Slideout	A137A.4	Ureasystem	BLK3	Sound_System
A61J2.4	Slideout	A137A.7	Ureasystem	BLK4	Sound_System
A61J2.7	Slideout	A137A.8	Ureasystem	BLU	Back-upcamera
A61RJ1.6	Slideout	A137A.24	Ureasystem	BRN/RHFlasher	RHFlasherBrigade
A61RJ1.17	Slideout	A137A.28	Ureasystem	BussBar	12VDTOCB2
A61RJ1.18	Slideout	A137A.40	Ureasystem	CAN_Hi	eMirrors_VS
A61RJ2.2	Slideout	A137A.44	Ureasystem	CAN_Low	eMirrors_VS
A61RJ2.3	Slideout	A137A.49	Ureasystem	CB1	24WUP
A61RJ2.14	Slideout	A137A.50	Ureasystem	CB2	Ignition&enginestart
A77.A	Equalizer	A137A.51	Ureasystem	CB3	HVACpassengers
A77.H	Equalizer	A137A.54	Ureasystem	CB5	24WUP
A78.3	Equalizer	A137A.56	Ureasystem	CB6	24VD
A78.4	Equalizer	A137A.59	Ureasystem	CB7	SmallA/C
A79.3	Equalizer	A137A.62	Ureasystem	CB8	12WUP
A80.3	Equalizer	A138.3	Ureasystem	CB9	Ureasystem
A80.4	Equalizer	A138.12	Ureasystem	CB10	12WUP
A81CN3A.3	EngineECUVolvo	ACC		CB14	WiperSystem
A81CN3A.4	Control_Ground_Relay	Alt_LL.2	Alternators	CB15	MuxPwrA49
A81CN3A.5	EngineECUVolvo	Alt_UL.2	Alternators	CB16	MuxPwrA47
A81CN3A.9	EngineECUVolvo	Alt_UR.2	Alternators	CB17	MuxPwrA48
A81CN3B.26	EngineECUVolvo	AltLL	Alternators	CB18	MuxPwrA55
A81CN3B.27	PwrAirDryer	AltUL	Alternators	CB19	MuxPwrA56
A81CN3B.28	EngineECUVolvo	AltUR	Alternators	CB20	DefrosterSystemPwr
A81CN3B.35	EngineECUVolvo	Ant2Rtn	Keyless	CB21	ELD
A81CN3B.36	Airdryer	Ant2Sig	Keyless	CB117	Trailer

CIRCUITS LIST

CircuitID	Description	CircuitID	Description	CircuitID	Description
CB119	Trailer	DL2H	Network	F44	Multiplexpower
CB128	24VD	DL2L	Network	F47	MCMPwr
CB201	Fansdriveelectric	DL3H	Networks	F50	MuxPwrA45
CB202	Fansdriveelectric	DL3L	Networks	F51	Multiplexpower
CB203	Fansdriveelectric	DL7H	Network	F52	Slideout
CB204	Fansdriveelectric	DL7L	Network	F53	ValidReady
CB205	Fansdriveelectric	DL11H	CanNetworkFusionSys	F54	ElectronicMirrorPwr
CB206	Fansdriveelectric	DL11L	CanNetworkFusionSys	F55	Frflashers
CB207	Fansdriveelectric	DL100H	J1939network	F56	Auxfandefroster
CB208	Fansdriveelectric	DL100L	J1939network	F58	LuggLightsPwr
CB301.Black	Trailer	DSO1.1	Slideout	F58A	LuggLightsPwr
CC16	FJB	DSO2.1	Slideout	F58B	LuggLightsPwr
CC17	FJB	DSO3.1	Slideout	F73	EngineECUVolvo
Clnt1	FJB	DSO4.1	Slideout	F90	Ureasystem
Clnt2	FJB	DSO4.3	Slideout	F91	EngineECUVolvo
Clnt3	FJB	EI.7	EngineECUVolvo	F95	ELDandMirrorPwr
Clnt4	FJB	EI.18	EngineECUVolvo	F96	VECPwr
Clnt5	FJB	EMS.EB29	Ignition&enginestart	F99	EngineECUVolvo
Clnt6	FJB	F10	Cluster	F101	R1toStarter
Clnt7	FJB	F11	Horn	F106	Multiplexpower
Clnt8	FJB	F13	12VDCustomer	F107	Multiplexpower
Clnt15	FJB	F14	Multiplexpower	F108	Networks
Clnt16	FJB	F15	Keylessentrysystem	F109	Engine&RJBcmpt.lights
Clnt17	FJB	F16	12VEng.run	F110	TransmissionAlisson
Clnt18	FJB	F17	Multiplexpower	F112	SparesVECR
CTS	RS232Signals	F19	Multiplexpower	F113	Back-upcamera
D1	Ignition&enginestart	F22	ELDPwr	F117	SparesVECR
D3	Trailer	F23	ESP	F118	Trailer
D4	EntranceDoorClosed	F24	Slideout	F121	CCust
D12	Horn	F25	12Voutlets	F122	Equalizer
D13	Horn	F26	AirDryerPwr	F126	SmallA/CDiag
D41	Ignition&enginestart	F27	SparesVECF	F130	Windowsajar
D43	IgnitionSig	F29	ECUignition	F131	CCust
D75	Slideout	F30	Networks	F132	Multiplexpower
D75.A	Slideout	F33	VolvolinkTGW	F133	Multiplexpower
DCIN+	BrigadePwr	F35	MCMPwr	F134	Multiplexpower
DFF4.1	Slideout	F36	24VDEng.StartSw83	F135	Multiplexpower
DLOH	MUXNetworkSpare	F37	Driverlight	F136	Multiplexpower
DLOHA	MuxNetwork	F39	24VDCustomer	F138	RJBCmpt.light
DL0L	MuxNetworkSpare	F40	Firesuppression	F139	Alternators
DL0LA	MuxNetwork	F41	Multiplexpower	F141	HVACpassengers
DL1H	Networks	F42	TransmissionI_Shift	F142	HVACpassengers
DL1L	Networks	F43	TransmissionI_Shift	F143	HVACpassengers

CIRCUITS LIST

CircuitID	Description	CircuitID	Description	CircuitID	Description
F144	HVACpassengers	N11	Networks	R35.30	VECUPwr
F147	CCust	N12	Networks	R36.30	Horn
F148	12VD	N13	Networks	R37.30	Horn
F149	Ureasystem	N14	Networks	R38.87	12Voutlets
F151	Sound_System	N15	Networks	R47.87	WCL
F152	SparesVECR	N16	Networks	R51.87.Yellow	Trailer
F199	Fansdriveelectric	N17	Networks	R52.87.Green	Trailer
F300	Sound_System	N18	Networks	R53.30.Red	Trailer
GRN/SPEED		N19	Networks	R54.87	Trailer
L207.1	WCL	N20	Networks	R55.30.Brown	Trailer
L207.3	WCLlight	N21	Networks	R300.30	Sound_System
L207.4	WCL	N22	Networks	R_Starter	Ignition&enginestart
L207.GND	WCL	N23	Networks	RED3	Sound_System
L350A.B2	EngineECUVolvo	N24	Networks	RED4	Sound_System
L400.G	Engineheateroutlet	N25	AddressA53	Res13	Mirrors
L400.L	Engineheateroutlet	N26	AddressA53	Res18	ElectricMirror
L400.N	Engineheateroutlet	N27	Networks	Res21	RJBCmpt.light
LinN	LinNSig	N28	Networks	Res22	Engine&RJBCmpt.lights
LinP	LinPSig	N29	AddressA36	ResFF4.1	Slideout
MIC+	Sound_System	N30	AddressA55	ResFF4.2	Slideout
MIC-	Sound_System	N31	AddressA55	ResFF4.3	Slideout
Mo11.3	SmallA/CDiag	N56.1	AddressA56	ResFF4.4	Slideout
Mo21.2	WiperSig	N56.2	AddressA56	ResFF4.5	Slideout
Mo22.2	WiperSig	N57_1	Networks	ResFF4.6	Slideout
Mo40.2	Windowsajar	N57_2	Networks	RFF4.1.30	Slideout
Mo65.3	Fansdriveelectric	N58_1	Network	RFF4.2.30	Slideout
Mo67.3	Fansdriveelectric	N58_2	Network	RSO1.1.30	Slideout
Mo68.3	Fansdriveelectric	N59_1	Network	RSO1.2.30	Slideout
Mo69.3	Fansdriveelectric	N59_2	Network	RSO2.1.30	Slideout
Mo70.3	Fansdriveelectric	N60	Network	RSO2.2.30	Slideout
Mo71.3	Fansdriveelectric	N61	Network	RSO3.1.30	Slideout
Mo72.3	Fansdriveelectric	ORA/LHFlasher	LHFlasherBrigade	RSO3.2.30	Slideout
Mo73.3	Fansdriveelectric	R12	HVACpassengers	RSO4.1.30	Slideout
N1	Networks	R12VISS	Sound_System	RSO4.2.30	Slideout
N2	Networks	R21.87	RJBoutswitch	RSO4.3.30	Slideout
N3	Networks	R21.B	IgnitionSig	RSO4.4.30	Slideout
N4	Networks	R22.87	ECUignition	RTS	RS232Signals
N5	Networks	R23.30	TransmissionAlisson	RxD	RS232Signals
N6	Networks	R23A.87A	IgnSigforVECU	RxTx	RS232Signals
N7	Networks	R25.87	24VIgnition	Se2	BrakeSigtoTrans
N8	Networks	R29	EngineECUVolvo	Se4	TagPressureSig
N9	Networks	R30.87	12VEngruncustomer	Se11.Sig	Cluster
N10	Networks	R34.30	12VECU	Se11.Wrn	Cluster

CIRCUITS LIST

CircuitID	Description	CircuitID	Description	CircuitID	Description
Se13.B	EngineECUVolvo	Se51.Jmp	SeatBeltSigJumper	spare22	Spareswires
Se14.A.B	EngineECUVolvo	Se53.C	Cluster	spare23	Spareswires
Se14B.C	EngineECUVolvo	Se54.C	Cluster	spare24	Spareswires
Se15	KeylessSyst	Se55.C	Cluster	STO-LOCselenoid	WCL
Se16	Keylessentrysyst	Se56	WCLsystem	Sw2.4	Frflashers
Se16.A	DayLightSe	Se57.C	ParkBrakeSig	Sw2.8	Frflashers
Se17.NC	EntranceDoorClosed	Se63.1	ESP	Sw3.4	Cornering&foglights
Se17NO	KeylessSyst	Se63.2	ESP	Sw3.8	Cornering&foglights
Se18.B	BrakeSig	Se64.1	ESP	Sw4.4	StatusSw4
Se19_P.D	Brake	Se64.2	ESP	Sw4.8	Frflashers
Se19_S.D	Brake	Se67.C	ESP	Sw5.4	Ignition&enginestart
Se20.B	Cluster	Se69.C	ESP	Sw5.8	Ignition&enginestart
Se21.2	HVACdefroster	Se89.A	Engine_Ecu	Sw6.6	TagSwSig
Se23	SmallA/C	Se94	WCLsystem	Sw14.4	EngineECUVolvo
Se23.C	HVACpassengers	Se100.4	WCL	Sw14.8	EngineECUVolvo
Se23A	SmallA/C	SeFF4	Slideout	Sw16.6	Brake
Se24.2	HVACpassengers	SES02.4	Slideout	Sw17.4	EngineECUVolvo
Se24.3	HVACpassengers	SES03.2	Slideout	Sw17.6	EngineECUVolvo
Se25.2	HVACpassengers	SeSO4	Slideout	Sw18.6	Luggageslock
Se30.A	Engine&RJBcmpt.lights	SeSO4Fr.2	Slideout	Sw20.4	WCL
Se32.A	TransmissionAlisson	SeSO4Rr.2	Slideout	Sw20.6	WCL
Se32.B	TransmissionAlisson	SES05.4	Slideout	Sw22.B	ServiceDoorLockSeSig
Se33.A	TransmissionAlisson	SES06.2	Slideout	Sw24.8	Driver`sLightSig
Se34.A	TransmissionAlisson	SES07.4	Slideout	Sw32	Luggageslights
Se34.B	TransmissionAlisson	SES08.2	Slideout	Sw33	Luggageslights
Se35.A	TransmissionAlisson	SHIELD3	Sound_System	Sw38.6	Driverwindow
Se35.B	TransmissionAlisson	SHIELD4	Sound_System	Sw39	RJBcmpt.light
Se37.1	ESP	Shield_149	GNDstud	Sw40.B	Trailerparkbrake
Se37.2	ESP	Shield_149A	GNDstud	Sw41.A1	Mirrors
Se38.1	ESP	SHLD-0R	Shield	Sw41.A3	Mirrors
Se38.2	ESP	So9.B	HVACpassengers	Sw41.B1	Mirrors
Se39.1	ESP	So28.2	Tagandlevellow	Sw41.B2	Mirrors
Se39.2	ESP	So29.2	Tagandlevellow	Sw41.B4	Mirrors
Se40.1	ESP	So30.2	Tagandlevellow	Sw42.2	WCL
Se40.2	ESP	So31.2	Tagandlevellow	Sw42.3	WCL
Se41	Cond.doorswitch	So32.2	Tagandlevellow	Sw42.4	WCL
Se43.2	HumiditySig	So33.2	LHFRctrvalve	Sw42.5	WCL
Se43.4	FreonTemp	So36	SmallA/C	Sw42.6	WCL
SE45.2	Washerliqlevel	spare17	Spareswires	Sw42.7	WCL
Se45.2	Washerliqlevel	spare18	Spareswires	Sw44	Engine&RJBcmpt.lights
Se46.B	Trailerparkbrake	spare19	Spareswires	Sw45	Luggageslights
Se49	HVACpassengers	Spare20	Spare20	Sw46	Luggageslights
Se51.2	SeatBeltSig	spare21	Spare21	Sw46A	WCLsystem

CIRCUITS LIST

CircuitID	Description	CircuitID	Description		
Sw47	Luggageslights	Sw156.8	Mirrors		
Sw48	Luggageslights	Sw157.6	Sunvisor		
Sw49	Luggageslights	Sw158.6	Sunvisor		
Sw50	Luggageslights	Sw161.2	DashDimmerSig		
Sw51	Luggageslights	SwSo1.4	Slideout		
Sw52	Luggageslights	SwSo1.5	Slideout		
Sw58.2	Ignition&enginestart	SwSo2.4	Slideout		
Sw58.3	Ignition&enginestart	SwSo2.5	Slideout		
Sw58.5	Ignition&enginestart	SwSo3.4	Slideout		
Sw58.7	Ignition&enginestart	SwSo3.5	Slideout		
Sw59.3	Ignition&enginestart	SwSo4.4	Slideout		
Sw82.5	Masterrelay&12VIgn	SwSo4.5	Slideout		
Sw83.Ign	12VIgn	TWU.3	WCL		
Sw83.Out1	Ignition&enginestart	TxD	RS232Signals		
Sw85.A1	Mirrors	WHT-F151	Sound_System		
Sw85.A3	Mirrors	WHT3	Sound_System		
Sw85.B1	Mirrors	WHT4	Sound_System		
Sw85.B2	Mirrors				
Sw85.B4	Mirrors				
Sw99.5	Dockinglights				
Sw99.8	Dockinglights				
Sw102.4	Dockinglights				
Sw102.8	Dockinglights				
Sw103.4	Backupwarnings				
Sw103.8	Backupwarnings				
Sw104.5	Keylessentrysystem				
Sw104.8	Keylessentrysystem				
Sw109	LuggagesLocksSwitchesSignal				
Sw110	LuggagesLocksSwitchesSignal				
Sw111	LuggagesLocksSwitchesSignal				
Sw112	LuggagesLocksSwitchesSignal				
Sw113	LuggagesLocksSwitchesSignal				
Sw114	LuggagesLocksSwitchesSignal				
Sw115	LuggagesLocksSwitchesSignal				
Sw116	LuggagesLocksSwitchesSignal				
Sw117					
Sw118	LuggagesLocksSwitchesSignal				
Sw119.4	Back-upcamera				
Sw119.8	Back-upcamera				
Sw122.6	AuxFanSpdSig				
Sw123.8	LDWSig				
Sw152.B	Firesuppression				
Sw156.4	Mirrors				