

# CONNECTORS LIST

No	Location	Part #	Gender	No	Location	Part #	Gender
120V_inlet	RearVehicle	561572	male	A34.4	EngineCmpt.	564258	male
A1	RJB	563975	male	A34.5	EngineCmpt.	564258	male
A2	FJB	563984	male	A34.6	EngineCmpt.	564258	male
A3	Dash	562363	male	A34.7	EngineCmpt.	564258	male
A4.A	Service_Cmpt	562428	female	A34.8	EngineCmpt.	564258	male
A4.B	Service_Cmpt	561188	female	A34.J	Enginecmpt.	568118	male
A5	Service_Cmpt	562428	female	A34.K	Enginecmpt.	564270	male
A6	Engine_Cmpt	562427	male	A34.L	Enginecmpt.	564269	male
A7	Rear_Axle_Cmpt	563979	male	A36.JA	FJB	562767	male
A9.Cx1	FJB	564041	female	A36.JB	FJB	562765	male
A9.Cx2	FJB	563678	male	A36.JC	FJB	562957	male
A9.Cx3	FJB	564037	female	A39.P101	Parcelrack	563201	male
A9.Cx4	FJB	564038	female	A39.P901	Parcelrack	563953	male
A10.X1	Engine_Cmpt	563135	male	A60.A	Parcelrack	563071	male
A10.X3	Engine_Cmpt	563134	female	A60.B	Parcelrack	562706	female
A11	LH_Console	563142	male	A60.C	Parcelrack	901110	male
A14.A	Dash	562766	male	A60.D	Parcelrack	901110	male
A14.B	Dash	562767	male	A61.A	Parcelrack	562464	male
A14.C	Dash	562765	male	A61.B	Parcelrack	562465	male
A15	Dash	562464	male	A65.B	Parcelrack	901110	male
A16	Front_Roof	561637	male	A65.C	Parcelrack	901110	male
A17.D	RJB	561932	male	A65.Csv	Parcelrack	562465	male
A18.J1	FJB	562794	male	A65.D	Parcelrack	901110	male
A18.J2	FJB	562650	male	A69.A	Parcelrack	563071	male
A19	LH_Console	562878	female	A69.B	Parcelrack	561716	female
A20	Parcel_Rack_LH	561477	female	A69.C	Parcelrack	561716	female
A24.A	RH_Console	561890	male	A69.D	Parcelrack	561716	female
A24.B	RH_Console	561566	female	A69.E	Parcelrack	561716	female
A24.C	RH_Console	561889	female	A69.F	Parcelrack	561716	female
A25	Parcelrack	563025	male	A69.G	Parcelrack	561716	female
A26.P1	Enginecmpt.	562350	male	A69.H	Parcelrack	561716	female
A26.P2	Enginecmpt.	563322	female	A70c	Parcelrack	561540	female
A26.P4	Enginecmpt.	568088	male	A77	Parcelrack	564547	male
A27	Service_Cmpt	562929	male	A78	Parcelrack	562583	female
A28	Service_Cmpt	562928	male	A79	Parcelrack	562583	female
A29	Dash	562464	male	A80	Parcelrack	562479	female
A32.A	FJB	564221	male	A81.JA	FJB	562767	male
A32.B	FJB	564518	male	A81.JB	FJB	562765	male
A33.A	Parcelrack	563071	male	A81.JC	FJB	562957	male
A33.B	Parcelrack	562330	female	A83	Parcelrack	565970	female
A34.1	EngineCmpt.	564258	male	A84.A	Parcelrack	563071	male
A34.2	EngineCmpt.	564258	male	A96	FJB	564073	female
A34.3	EngineCmpt.	564258	male	A97	Dash	563226	male

# CONNECTORS LIST

No	Location	Part #	Gender	No	Location	Part #	Gender
A97A	FJB	563226	male	AE43.J2	FJB	564037	male
A97A	FJB	563613	female	AE43.J3	FJB	565957	male
A97B	FJB	563226	male	AE44.J1	FJB	563679	male
A97B	FJB	563613	female	AE44.J2	FJB	564037	female
A100	Front_Axle_Cmpt	563758	female	AE44.J3	FJB	565957	male
A101	Rear_RH_Axle_Cmpt	563758	female	AE45.J1	FJB	563679	male
A102	Rear_RH_Axle_Cmpt	563758	female	AE45.J2	FJB	564037	female
A103	Dash	562070	female	AE45.J3	FJB	565957	male
A107	EngineCmpt.	560336	male	AE46.J1	FJB	563679	male
A108	RJB	562766	male	AE46.J2	FJB	564037	female
A109A	FJB	564141	male	AE46.J3	FJB	565957	male
A113.A	Parcel_Rack_LH	563960	male	AE47.J1	RH_console	563679	male
A113.B	Parcel_Rack_LH	563962	male	AE47.J2	RH_console	564037	female
A113.C1	Parcel_Rack_LH	563956	male	AE47.J3	RH_console	565957	male
A113.C2	Parcel_Rack_LH	563957	male	AE48.J1	RH_console	563679	male
A113.C3	Parcel_Rack_LH	563958	male	AE48.J2	RH_console	564037	female
A114A	Dash	564252	male	AE48.J3	RH_console	565957	male
A120.A	Dashboard	563960	male	AE49.J1	RJB	563679	male
A120.B	Dashboard	563962	male	AE49.J2	RJB	564037	male
A120.C1	Dashboard	563956	male	AE49.J3	RJB	565957	male
A120.C2	Dashboard	563957	male	AE50.J1	RJB	563679	male
A120.C3	Dashboard	563958	male	AE50.J2	RJB	564037	male
A121.Vsa	Dash	563679	male	AE50.J3	RJB	565957	male
A121.Vsb	Dash	563678	male	AE51.J1	RJB	563679	male
A121.Vsc	Dash	564037	male	AE51.J2	RJB	564037	female
A121.Vsd	Dash	564118	male	AE51.J3	RJB	565957	male
A130	Driver_Area	563226	male	AE52.J1	RJB	563679	male
A131.A	Engine_Cmpt	561782	male	AE52.J2	RJB	564037	female
A131.B	Engine_Cmpt	561781	female	AE52.J3	RJB	565957	male
A137A	Condensercmpt.	20429843	male	AE53.J1	RJB	563679	male
A138	Cond_Cmpt	563787	male	AE53.J2	RJB	564037	female
A139	Dash	564501	male	AE53.J3	RJB	565957	male
A151.A	Parcelrack	561582	female	AE54.J1	Evaporatorcmpt.	563679	male
A151.B	Parcelrack	561582	female	AE54.J2	Evaporatorcmpt.	564037	female
A152.J	Parcelrack	563071	male	AE54.J3	Evaporatorcmpt.	565957	male
A153.A	Parcelrack	562465	male	AE55.J1	Dash	563679	male
AE41.J1	FJB	563679	male	AE55.J2	Dash	564037	female
AE41.J2	FJB	564037	female	AE55.J3	Dash	564004	male
AE41.J3	FJB	564004	male	AE56.J1	Dash	563679	male
AE42.J1	FJB	563679	male	AE56.J2	Dash	564037	male
AE42.J2	FJB	564037	female	AE56.J3	Dash	564004	male
AE42.J3	FJB	564004	male	AE57.J1	WCLcmpt.	563679	male
AE43.J1	FJB	563679	male	AE57.J2	WCLcmpt.	564037	male

# CONNECTORS LIST

No	Location	Part #	Gender	No	Location	Part #	Gender
AE57.J3	WCLcmpt.	564004	male	C8	FJB	563614	female
Alt_LL.A	Enginectpt.	563746	female	C9	RJB	561986	male
Alt_LL.B	Enginectpt.	560815	female	C9	RJB	561987	female
Alt_LL.C	Enginectpt.	564469	female	C10	Engine_Cmpt	562477	male
Alt_LR.A	enginectpt.	563746	female	C10	Engine_Cmpt	562479	female
Alt_LR.B	Enginectpt.	560815	female	C11	Service_Cmpt	563580	male
Alt_LR.C	Enginectpt.	564469	female	C11	Service_Cmpt	563581	female
Alt_UR.A	Enginectpt.	563746	female	C12	Engine_Cmpt	562581	male
Alt_UR.B	Enginectpt.	560815	female	C12	Engine_Cmpt	562583	female
Alt_UR.C	Enginectpt.	564469	female	C13_plug	RH_Console	563589	male
B85	Engine_Cmpt	563815	male	C13_socket	RH_Console	563590	female
B96	Engine_Cmpt	563821	male	C13S	RH_Console	563589	male
B96B	Engine_Cmpt	563823	male	C13S	RH_Console	563590	female
B97	Engine_Cmpt	563816	male	C15A	Evapotatorcmpt.	568110	male
B98	Engine_Cmpt	563817	male	C15A	Evaporatotcmpt.	568109	female
B115A	Enginectpt.	564226	male	C16	RJB	561577	male
B142C	Enginectpt.	563793	male	C16	RJB	561605	female
B310	Enginectpt.	565967	male	C17	RJB	560195	male
C1	FJB	563589	male	C17	RJB	560169	female
C1	FJB	563590	female	C18	FJB	561986	male
C1S	FJB	563589	male	C18	FJB	561987	female
C1S	FJB	563590	female	C19	RJB	561986	male
C2	Service_Cmpt	563580	male	C19	RJB	561987	female
C2	Service_Cmpt	563581	female	C20A	Evap_Cmpt	562485	male
C2A	FJB	563580	male	C20A	Evap_Cmpt	562486	female
C2A	FJB	563581	female	C20B	Evap_Cmpt	562485	male
C2B	FJB	564034	male	C20B	Evap_Cmpt	562486	female
C2B	FJB	564035	female	C23	Evaporatorcmpt.	564034	male
C3_plug	RJB	563589	male	C23	Evaporatorcmpt.	564035	female
C3_socket	RJB	563590	female	C24_plug	Evap_Cmpt	561690	male
C3S	RJB	563593	male	C24_socket	Evap_Cmpt	561566	female
C3S	RJB	563590	female	C25	Parcel_Rack_LH	561550	male
C4	FJB	563580	male	C25	Parcel_Rack_LH	561667	female
C4	FJB	563581	female	C26	Ureacmpt.	563226	male
C5	FJB	563589	male	C26	Ureacmpt.	563613	female
C5	FJB	563590	female	C26A	Ureacmpt.	568110	male
C5S	FJB	563589	male	C26A	Ureacmpt.	568109	female
C5S	FJB	563590	female	C26B	Ureacmpt.	563227	male
C6	FJB	563582	male	C26B	Ureacmpt.	563614	female
C6	FJB	563583	female	C29	4rd_Lugg_Cmpt	563651	male
C7	Service_Cmpt	562566	male	C29	3rd_Lugg_Cmpt	563652	female
C7	Service_Cmpt	562565	female	C30	3rd_Lugg_Cmpt	561710	male
C8	FJB	563227	male	C30	3rd_Lugg_Cmpt	561709	female

# CONNECTORS LIST

No	Location	Part #	Gender	No	Location	Part #	Gender
C31W	Parcelrack	561515	male	C54A	Ureacmpt.	568109	female
C31W	Parcelrack	561552	female	C54B	Enginecmpt.	563589	male
C32	lavatory	561734	male	C54B	Enginecmpt.	563590	female
C32	Lavatory	561735	female	C55	Evap_Cmpt	561577	male
C32L	Lavatory	562006	male	C55	Evap_Cmpt	561605	female
C32L	Lavatory	560908	female	C58	Condensorcmt.	564567	male
C32W	WCLcmpt.	561640	male	C58	Condensorcmt.	564568	female
C32W	WCLcmpt.	561639	female	C59	RJB	561643	male
C32X	Lavatory	561247	male	C59	RJB	561642	female
C32X	Lavatory	561248	female	C61	Fr_Service_Door	561669	male
C33	WCLcmpt.	564034	male	C61	Fr_Service_Door	561670	female
C33	WCLcmpt.	564035	female	C62	Fr_Service_Door	562566	male
C34	RH_Console	561986	male	C62	Fr_Service_Door	562565	female
C34	RH_Console	561987	female	C63	Entrance_Door	562477	male
C37	Parcel_Rack_LH	562557	male	C63	Entrance_Door	562479	female
C37	Parcel_Rack_LH	562558	female	C64	Enginecmpt.	568110	male
C38	Parcelrack	562555	male	C64	Enginecmpt.	568109	female
C38	Parcelrack	562556	female	C66_plug	Evap_Cmpt	561577	male
C39A	Firesuppressioncmt.	561782	male	C66_socket	Evap_Cmpt	561605	female
C39A	Firesuppressioncmt.	561781	female	C70	FJB	562557	male
C40	Dash	562485	male	C70	FJB	562558	female
C40	Dash	562486	female	C71	FJB	561646	male
C41	RJB	561782	male	C71	FJB	561645	female
C41	RJB	561781	female	C72	FJB	561646	male
C42	FJB	561668	male	C72	FJB	561645	female
C42	FJB	561551	female	C74	FJB	561645	female
C44_plug	FJB	561577	male	C74	FJB	561646	male
C44_socket	FJB	561605	female	C81	1st_Lugg_Cmpt	562477	male
C45	FJB	561643	male	C81	1st_Lugg_Cmpt	562479	female
C45	FJB	561642	female	C83	2nd_Lugg_Cmpt	562477	male
C46	WCLCmpt.	564228	male	C83	2nd_Lugg_Cmpt	562479	female
C46	WCLCmpt.	564229	female	C84	2nd_Lugg_Cmpt	562477	male
C49	FJB	562005	male	C84	2nd_Lugg_Cmpt	562479	female
C49	FJB	561714	female	C85	4thlugg.cmpt.	562477	male
C50	RJB	563226	male	C85	4thlugg.cmpt.	562479	female
C50	RJB	563613	female	C86	4thlugg.cmpt.	563618	male
C51	Enginecmpt.	564034	male	C86	4thlugg.cmpt.	563616	female
C51	Enginecmpt.	560034	female	C87	Engine_Cmpt	562485	male
C52	Evaporatorcmt.	563618	male	C87	Engine_Cmpt	562486	female
C52	Evaporatorcmt.	563616	female	C88	FJB	563618	male
C54	Enginecmpt.	563226	male	C88	FJB	563616	female
C54	Enginecmpt.	563613	female	C91	RJB	562285	male
C54A	Ureacmpt.	568110	male	C91	RJB	562282	female

# CONNECTORS LIST

No	Location	Part #	Gender	No	Location	Part #	Gender
C92A	Enginecmpt.	563226	male	C144	RJB	560851	female
C92A	Enginecmpt.	563613	female	C152	Cond_Cmpt	561611	male
C92C	Enginecmpt.	562581	male	C152	Cond_Cmpt	561610	female
C92C	Enginecmpt.	562583	female	C158	Condensorcmpt.	562477	male
C94_plug	FJB	563589	male	C158	Condensorcmpt.	562479	female
C94_socket	FJB	563590	female	C170	LH_Console	561637	male
C96	FJB	561643	male	C170	LH_Console	561636	female
C96	FJB	561642	female	C171	LH_Console	561646	male
C97	FJB	561643	male	C171	LH_Console	561645	female
C97	FJB	561642	female	C193_plug	RJB	563589	male
C100	Evaporatorcmpt.	562477	male	C193_socket	RJB	563590	female
C100	Evaporatorcmpt.	562479	female	C194	FJB	563589	male
C100S	EvaporatorCmpt.	562477	male	C194	FJB	563590	female
C100S	EvaporatorCmpt.	562479	female	C206	Parcel_Rack_RH	562503	male
C101	Service_Cmpt	561690	male	C206	Parcel_Rack_RH	562507	female
C101	Service_Cmpt	561566	female	C207	Parcel_Rack_LH	562503	male
C102A	Condensorcmpt.	563226	male	C207	Parcel_Rack_LH	562507	female
C102A	Condensorcmpt.	563613	female	C212	WCLArea	561515	male
C103_plug	FJB	562485	male	C212	WCLArea	561552	female
C103_socket	FJB	562486	female	C213	Parcel_Rack_LH	561515	male
C105_plug	FJB	562581	male	C213	Parcel_Rack_LH	561552	female
C105_socket	FJB	562583	female	C222	FJB	562477	male
C106_plug	FJB	562581	male	C222	FJB	562479	female
C106_socket	FJB	562583	female	C223	FJB	563227	male
C107A	Enginecmpt.	562885	female	C223	FJB	563614	female
C107A	Enginecmpt.	562884	female	C224	FJB	561637	male
C107B	Enginecmpt.	562885	female	C224	FJB	561636	female
C107B	Enginecmpt.	562884	female	C225	FJB	562650	male
C107C	Enginecmpt.	562885	female	C225	FJB	562649	female
C107C	Enginecmpt.	562884	female	C226	FJB	562650	male
C110	Pneumatic Panel	568110	male	C226	FJB	562649	female
C110	Pneumatic Panel	568109	female	C242	Service_Cmpt	562789	male
C119A	Rearenginedoor	568110	male	C242	Service_Cmpt	565131	female
C119A	Rearenginedoor	568109	female	C243	FrontVehicle	563347	male
C121	Rearenginedoor	562566	male	C243	FrontVehicle	563180	female
C121	Rearenginedoor	562565	female	C266	Parcelrack	561782	male
C122	Rearenginedoor	562566	male	C266	Parcelrack	561781	female
C122	Rearenginedoor	562565	female	C267	Parcelrack	561782	male
C131A	Engine_Cmpt	561782	male	C267	Parcelrack	561781	female
C131A	Engine_Cmpt	561781	female	C279	Service_Cmpt	562477	male
C131B	Engine_Cmpt	561782	male	C279	Service_Cmpt	562479	female
C131B	Engine_Cmpt	561781	female	C284	Parcelrack	561782	male
C144	RJB	560852	male	C284	Parcelrack	561781	female

# CONNECTORS LIST

No	Location	Part #	Gender	No	Location	Part #	Gender
C284_1	Parcelrack	561782	male	C542	Parcelrack	561550	male
C284_1	Parcelrack	561781	female	C542	Parcelrack	561667	female
C284_2	Parcelrack	561782	male	C558	Parcelrack	562503	male
C284_2	Parcelrack	561781	female	C558	Parcelrack	562507	female
C284_3	Parcelrack	561782	male	C564	Parcelrack	562503	male
C284_3	Parcelrack	561781	female	C564	Parcelrack	562507	female
C284_4	Parcelrack	561782	male	C566	Parcelrack	562503	male
C284_4	Parcelrack	561781	female	C566	Parcelrack	562507	female
C284_5	Parcelrack	561782	male	C567	Parcelrack	562503	male
C284_5	Parcelrack	561781	female	C567	Parcelrack	562507	female
C290	Rear_Vehicle	562477	male	C575	Parcel_Rack_RH	562503	male
C290	Rear_Vehicle	562479	female	C575	Parcel_Rack_RH	562507	female
C298	Parcelrack	561782	male	C576B	Parcel_Rack_RH	562006	male
C298	Parcelrack	561781	female	C576B	Parcel_Rack_RH	560908	female
C355	RJB	563582	male	C576BB	Parcelrack	562006	male
C355	RJB	563583	female	C576BB	Parcelrack	560908	female
C356	Parcelrack	561710	male	C577A	Parcel_Rack	562006	male
C356	Parcelrack	561709	female	C577A	Parcel_Rack	560908	female
C357	Parcelrack	561847	male	C577AA	Parcelrack	562006	male
C357	Parcelrack	561862	female	C577AA	Parcelrack	560908	female
C380A	Dash	564222	male	C578	Parcel_Rack_LH	562503	male
C380A	Dash	564224	female	C578	Parcel_Rack_LH	562507	female
C381	Parcel_Rack	561847	male	C582	FJB	561690	female
C381	Parcel_Rack	561862	female	C582	FJB	561566	female
C382	Under_Seat	561580	male	C601	LHRoofWinAjar	561476	male
C382	Under_Seat	561582	female	C601	LHRoofWinAjar	561477	female
C397	RJB	562285	male	C603	RHRoofWinAjar	561476	male
C397	RJB	562282	female	C603	RHRoofWinAjar	561477	female
C430	LH_Console	562363	male	C614	Passenger_Area	563071	male
C430	LH_Console	561188	female	C614	Passenger_Area	563040	female
C452	Dash	561669	male	C615	Passenger_Area	563071	male
C452	Dash	561670	female	C615	Passenger_Area	563040	female
C463	Rearaxlecmpt.	568111	male	C617	Mirror_LH	563801	male
C463	Rearaxlecmpt.	568112	female	C617	Mirror_LH	563800	female
C464	FJB	564222	male	C618	Mirror_RH	563801	male
C464	FJB	564224	female	C618	Mirror_RH	563800	female
C465	Parcelrack	562581	male	C752	Parcelrack	901283	female
C465	Parcelrack	562583	female	C753	Parcelrack	901283	female
C506	FJB	561687	male	C766	Parcelrack	561662	male
C506	FJB	561685	female	C766	Parcelrack	561661	female
C506spA	FJB	561687	male	C768	Parcelrack	901283	female
C506spA	FJB	561685	female	C769	Parcelrack	901283	female
C506spB	FJB	561687	male	C777	Dash	562477	male

# CONNECTORS LIST

No	Location	Part #	Gender	No	Location	Part #	Gender
C777	Dash	562479	female	CL142	Lavatory	560908	female
C_A60DB	Parcelrack	563071	male	CL142A	Lavatory	562006	male
C_A60DB	Parcelrack	563040	female	CL142A	Lavatory	560908	female
C_ALT	Enginectmpt.	562581	male	CP1	Passenger_Area	561782	male
C_ALT	Enginectmpt.	562583	female	CP1	Passenger_Area	561781	female
C_ALT3	Enginectmpt.	562477	male	CP2	Passenger_Area	561782	male
C_ALT3	Enginectmpt.	562479	female	CP2	Passenger_Area	561781	female
C_AUDIO	Parcelrack	562557	male	CP3	Passengersarea	561782	male
C_AUDIO	Parcelrack	562558	female	CP3	Passengersarea	561781	female
C_AUX	Parcelrack	563071	male	CP4	Passenger_Area	561782	male
C_AUX	Parcelrack	563040	female	CP4	Passenger_Area	561781	female
C_INV1	Parcelrack	562337	male	CP5	Passenger_Area	561782	male
C_INV1	Parcelrack	562338	male	CP5	Passenger_Area	561781	female
C_INV2	Parcelrack	562337	male	CP6	Passengersarea	562337	male
C_INV2	Parcelrack	562338	male	CP6	Passengersarea	562338	male
C_LineOut	Parcelrack	563962	male	CSe80	RJB	562477	male
C_LineOut	Parcelrack	564489	female	CSe80	RJB	562479	female
C_Mo9	Evap_Cmpt	561577	male	CSw102	EngineCmpt.	562549	male
C_Mo9	Evap_Cmpt	561605	female	CSw102	EngineCmpt.	562550	female
C_USB	Parcelrack	562069	male	CSX1	Engine_Cmpt	563135	male
C_USB	Parcelrack	562070	female	CSX1	Engine_Cmpt	563134	female
CCAN1	FJB	562650	male	CSX3	Engine_Cmpt	563135	male
CCAN1	FJB	562649	female	CSX3	Engine_Cmpt	563134	female
CCAN2	FJB	562650	male	CXC1	Service_Cmpt	562477	male
CCAN2	FJB	562649	female	CXC1	Service_Cmpt	562479	female
CCAN3	FJB	562650	male	D92	Parcelrack	564496	male
CCAN3	FJB	562649	female	EI	Enginectmpt.	563739	male
CCAN4	FJB	562650	male	L1A	Enginectmpt.	564045	female
CCAN4	FJB	562649	female	L16.A	Frontroof	562615	female
CCust	Parcel_Rack_Fr_WCL	562477	male	L16.B	Frontroof	562615	female
CCust	RJB	562479	female	L17.A	Frontroof	562615	female
CFHPR1	Parcelrack	564560	male	L17.B	Frontroof	562615	female
CIND-1.A	Parcelrack	560908	female	L18	Entrance_Door	562549	male
CIND-1.B	Parcelrack	560908	female	L19	Entracedoor	562549	male
CIND-2.A	Parcelrack	560908	female	L20	Entracedoorstep	562549	male
CIND-2.B	Parcelrack	560908	female	L28	Parcelrack	560898	male
CIND-11.A	Parcelrack	560908	female	L29	Parcelrack	560898	male
CIND-11.B	Parcelrack	560908	female	L30	Parcelrack	560898	male
CINDWC-1	Parcelrack	560908	female	L30A.A	Parcelrack	560898	male
CINDWC-1	Parcelrack	560908	female	L30B.A	Parcelrack	560898	male
CL1	Service_Cmpt	562485	male	L31	Parcelrack	560898	male
CL1	Service_Cmpt	562486	female	L32	Parcelrack	560898	male
CL142	Lavatory	562006	male	L33	Parcelrack	560898	male

# CONNECTORS LIST

No	Location	Part #	Gender	No	Location	Part #	Gender
L34	Parcelrack	560898	male	L60A	OutsideFrontLH	563366	male
L35	Parcelrack	560898	male	L60B	Out_Side_Front_LH	562623	male
L36	Parcelrack	560898	male	L61	Out_Side_Front_RH	562601	male
L37	Parcelrack	560898	male	L62	Out_Side_Front_LH	562601	male
L38	Parcelrack	560898	male	L63	Front_Side_LH	562155	male
L39	Parcelrack	560898	male	L64	Outside_Front_RH	562155	male
L40	Parcelrack	560898	male	L65	Outside_Front_LH	562155	male
L41	Parcelrack	560898	male	L66	Out_Side_Front_LH	562155	male
L42	Parcelrack	560898	male	L67	4th_Lugg_Cmpt	562155	male
L43	Parcelrack	560898	male	L68	4th_Lugg_Cmpt	562155	male
L44	Parcelrack	560898	male	L69	4th_Lugg_Cmpt	562155	male
L45	Parcelrack	560898	male	L70	4th_Lugg_Cmpt	562155	male
L46	Parcelrack	560898	male	L71A	Rearenginedoor	562601	male
L47	Parcelrack	560898	male	L72	Rear_Vehicle	562155	male
L48	Parcelrack	560898	male	L73A	Rearenginedoor	562601	male
L49	Parcelrack	560898	male	L74	RearVehicle	562155	male
L50	Parcelrack	560898	male	L75	Rearenginedoor	562155	male
L51	Parcelrack	560898	male	L76	RearVehicle	562155	male
L52	Parcelrack	560898	male	L77A	Rearvehicule	562601	male
L52	Parcelrack	560900	female	L78A	Rearvehicule	562601	male
L52A	Parcelrack	560898	male	L79A	Rearvehicule	562601	male
L53	Parcelrack	560898	male	L80A	Rearvehicule	562601	male
L53	Parcelrack	560900	female	L81.A	Rear_Vehicle	562835	female
L53A	Parcelrack	560898	male	L81.B	Rear_Vehicle	562834	male
L54	Parcelrack	560898	male	L82A	Rearvehicule	562348	female
L54	Parcelrack	560900	female	L83A	Rearvehicule	562348	female
L54A	Parcelrack	560898	male	L84	FrontVehicle	562486	female
L55	Parcelrack	560898	male	L85	RearVehicle	562486	female
L55	Parcelrack	560900	female	L86	RearVehicle	562486	female
L55A	Parcelrack	560898	male	L87	RearVehicle	562486	female
L56	Parcelrack	560898	male	L88	RearVehicle	562486	female
L56	Parcelrack	560900	female	L89	RearVehicle	562486	female
L56A	Parcelrack	560898	male	L90	RearVehicle	562486	female
L57	Parcelrack	560898	male	L91A	Rearvehicule	562601	male
L57	Parcelrack	560900	female	L92A	Rearvehicule	562601	male
L57A	Parcelrack	560898	male	L95	Outside_Front_LH	562902	female
L58	Parcelrack	560898	male	L96	Outside_Front_RH	562902	female
L58	Parcelrack	560900	female	L97.A	Outside_Front_LH	563069	female
L58A	Parcelrack	560898	male	L97.B	Outside_Front_LH	563069	female
L59	Out_Side_Front_RH	562623	male	L98.A	Entrance_Door	563069	female
L59A	OutsideFrontRH	563366	male	L98.B	Outside_Front_RH	563069	female
L59B	Out_Side_Front_RH	562623	male	L140	Lavatory	561247	male
L60	OutsideFrontLH	562623	male	L142	Lavatory	562006	male



# CONNECTORS LIST

No	Location	Part #	Gender	No	Location	Part #	Gender
L142B	Lavatory	562006	male	L205	Enginectpt.	562485	male
L143	Parcelrack	561186	male	L206	Parcel_Rack_RH	562803	male
L144	Parcelrack	561186	male	L207.A	WCLCmpt.	561699	female
L145	Parcelrack	561186	male	L207.B	WCLCmpt.	561701	female
L146	Parcelrack	561186	male	L207.C	WCLCmpt.	561701	female
L147	Parcelrack	561186	male	L207.D	WCLCmpt.	561699	female
L148	Parcelrack	561186	male	L207.E	WCLCmpt.	561701	female
L149	Parcelrack	561186	male	L207.F	WCLCmpt.	561699	female
L150	Parcelrack	561186	male	L207.G	WCLCmpt.	561699	female
L151	Parcelrack	561186	male	L207.H	WCLCmpt.	563536	female
L152	Parcelrack	561186	male	L207.I	WCLCmpt.	563536	female
L153	Parcelrack	561186	male	L243	Parcelrack	561186	male
L154	Parcelrack	561186	male	L244	Parcelrack	561186	male
L155	Parcelrack	561186	male	L245	Parcelrack	561186	male
L156	Parcelrack	561186	male	L246	Parcelrack	561186	male
L157	Parcelrack	561186	male	L247	Parcelrack	561186	male
L158	Parcelrack	561186	male	L250	Parcelrack	561186	male
L173	Parcelrack	563590	female	L252	Parcelrack	561186	male
L174A	Parcelrack	563590	female	L254	Parcelrack	561186	male
L176	3rd_Lugg_Cmpt	561247	male	L256	Parcelrack	561186	male
L177	3rd_Lugg_Cmpt	561247	male	L257	Parcelrack	561186	male
L177A	3rdlugg.cmpt.	561690	male	L282	Engine_Cmpt	561690	male
L177B	3rdlugg.cmpt.	561690	male	L283	Service_Cmpt	562485	male
L180	2nd_Lugg_Cmpt	561247	male	L285.A	Rear_Vehicle	562835	female
L181	2nd_Lugg_Cmpt	561247	male	L285.B	Rear_Vehicle	562834	male
L182	1st_Lugg_Cmpt	561247	male	L286.A	Rear_Vehicle	562835	female
L183	1st_Lugg_Cmpt	561247	male	L286.B	Rear_Vehicle	562834	male
L184	Servicecmpt.	561247	male	L296	Refrigerator	561248	female
L185.A	Servicecmpt.	561539	male	L298A	Enginectpt.	563590	female
L185.B	Servicecmpt.	561539	male	L306	RJBcmpt.	561247	male
L186.A	Dash	561539	male	L313	Rr_Roof	562549	male
L186.B	Dash	561539	male	Mo3	Dash	561667	female
L187	Engine_Cmpt	561690	male	Mo4	Dash	562076	male
L188	Service_Cmpt	562486	female	Mo5	Front_Roof	561515	male
L193.A	Dash	560488	female	Mo7	Cond_Cmpt	563691	male
L193.B	Dash	560488	female	Mo8	Cond_Cmpt	563691	male
L194.A	Dash	562019	female	Mo12	Engine_Cmpt	561690	male
L194.B	Dash	560488	female	Mo13	Engine_Cmpt	561690	female
L195.A	Dash	560488	female	Mo14	Engine_Cmpt	561566	female
L195.B	Dash	560488	female	Mo15	Front_Ceiling	560900	female
L199	Enginectpt.	562848	male	Mo16	Front_Ceiling	560900	female
L203	RH_Console	561690	male	Mo17	RH_Console	563626	male
L204	Parcel_Rack_RH	562803	male	Mo19	Fr_Service_Door	562474	male

# CONNECTORS LIST

No	Location	Part #	Gender	No	Location	Part #	Gender
Mo20	Fr_Service_Door	562474	male	PR1	Passenger_Area	561781	female
Mo22	RH_Console	561186	male	R3	RJB	563409	male
Mo24	RH_Console	562348	female	R4	FJB	564496	male
Mo25	RH_Console	562348	female	R5	RJB	564496	male
Mo27	Cond_Cmpt	563691	male	R12	Evap_Cmpt	563409	male
Mo28	Cond_Cmpt	563691	male	R20	RJB	564496	male
Mo29	RJBcmpt.	563590	female	R21	FJB	560525	male
Mo30	Compr_Door	564161	male	R26	Evap_Cmpt	564496	male
Mo31	Parcelrack	564161	male	R27	Dash	564496	male
Mo32	Parcelrack	564161	male	R29	RJB	563409	male
Mo33	Parcelrack	564161	male	R30	FJB	564496	male
Mo34	Parcelrack	564161	male	R31	FJB	564496	male
Mo35	3rd_Lugg_Door	564161	male	R34	RJB	564210	male
Mo36	Parcelrack	564161	male	R36	Dash	564496	male
Mo54	Service_Cmpt	562474	male	R37	Dash	564496	male
Mo65	Enginectmpt.	568089	male	R38	FJB	564496	male
Mo67	Enginectmpt.	568089	male	R40	RJB	564496	male
Mo68	Enginectmpt.	568089	male	R47	Parcelrack	564496	male
Mo69	Enginectmpt.	568089	male	R210	Parcelrack	560525	male
Mo70	Enginectmpt.	568089	male	R_12VISS	Parcelrack	564496	male
Mo71	Enginectmpt.	568089	male	RadioVolvo	Parcelrack	563960	male
Mo72	Enginectmpt.	568089	male	RadioVolvo	Parcelrack	563962	male
Mo73	Enginectmpt.	568089	male	RadioVolvo	Parcelrack	563956	male
P_In1	Passenger_Area	561782	male	RadioVolvo	Parcelrack	563957	male
P_In1	Passenger_Area	561781	female	RadioVolvo	Parcelrack	563958	male
P_Out1	Passenger_Area	561782	male	Res3.A	RJB	563590	female
P_Out1	Passenger_Area	561781	female	Res4	FJB	563590	female
P_Out2	Passenger_Area	561782	male	Res6	FJB	563590	female
P_Out2	Passenger_Area	561781	female	Res15	Engine_Cmpt	561782	male
P_Out3	Passenger_Area	561782	male	Res20	FJB	563590	female
P_Out3	Passenger_Area	561781	female	Res31	Ureacmpt.	562350	male
PC1	FJB	562650	male	Res32	Ureacmpt.	563764	female
PC1	FJB	562649	female	Se4	Window_RH	561477	female
PF	FJB	561782	male	Se5	Window_RH	561477	female
PF	FJB	561781	female	Se6	Window_RH	561477	female
PF1	Passenger_Area	561782	male	Se7	Window_LH	561477	female
PF1	Passenger_Area	561781	female	Se8	Window_LH	561477	female
Pot1.A	Dash	560488	female	Se9	Window_LH	561477	female
Pot1.B	Dash	560488	female	Se10	FJB	561477	female
Pot1.C	Dash	560488	female	Se11.A	Cond_Cmpt	560082	female
PR	Parcelrack	561782	male	Se11.B	Cond_Cmpt	560082	female
PR	Parcelrack	561781	female	Se11.C	Cond_Cmpt	560082	female
PR1	Passenger_Area	561782	male	Se13	Engine_Cmpt	562350	male

# CONNECTORS LIST

No	Location	Part #	Gender	No	Location	Part #	Gender
Se14.A	Driver_Area	561782	male	Se80	Rear_Axle	563159	female
Se14.B	Driver_Area	561781	female	Se100	WCLdoor	562479	female
Se15	RH_Console	560898	male	So3	RH_Console	641385	male
Se17	RH_Console	560900	female	So4	RH_Console	641385	male
Se18	Servicecmpt.	561566	female	So5	RH_Console	641385	male
Se19_P	Service_Cmpt	563677	male	So6	RH_Console	641385	male
Se19_S	Service_Cmpt	563677	male	So7	Service_Cmpt	561566	female
Se20	Evap_Cmpt	562426	male	So8	Servicecmpt.	641385	male
Se21	Dash	561248	female	So9	Enginecmpt.	560016	female
Se23	Engine_Cmpt	563159	male	So10.A	Condensorcmt.	562485	male
Se24	EvaporatorCmpt.	563758	female	So11	Cond_Cmpt	561566	female
Se25	Passenger_Area	561248	female	So13	Evap_Cmpt	563204	female
Se29	Engine_Cmpt	561566	female	So14	Servicecmpt.	641385	male
Se30	Enginedoor	562877	female	So15	Servicecmpt.	641385	male
Se31	Enginedoor	562877	female	So16	Servicecmpt.	641385	male
Se32	Rear_Axle_Cmpt	562426	male	So17	Servicecmpt.	562848	male
Se33	Rear_Axle_Cmpt	562856	male	So20	Servicecmpt.	641385	male
Se34	Rear_Axle_Cmpt	562426	male	So21	Front_Axle_Cmpt	564046	female
Se35	Rear_Axle_Cmpt	562426	male	So22	Front_Axle_Cmpt	564046	female
Se36	Rear_Axle_Cmpt	562427	male	So23	Rear_Axle_Cmpt	564046	female
Se37	Front_Axle_LH	641132	female	So24	Rear_Axle_Cmpt	564046	female
Se38	Front_Axle_RH	641132	female	So27	Rearaxlecmpt.	564045	female
Se39	Rear_Axle_LH	641132	female	So29	Parcelrack	641385	male
Se40	Rear_Axle_LH	641132	female	So50	Rearaxlecmpt.	564046	female
Se45	Servicecmpt.	563409	male	So52	Rearaxlecmpt.	564045	female
Se46	Rearaxlecmpt.	562348	female	So53	Rear_Axle_Cmpt	641385	male
Se53	Service_Cmpt	563159	female	So54	Enginecmpt.	564045	female
Se54	Service_Cmpt	563159	female	So55	Pneumaticplate	562848	male
Se55	Service_Cmpt	563159	female	So56	Rear_Axle_Cmpt	562350	male
Se56	WCLCmpt.	562884	female	So57	Engine_Cmpt	562350	male
Se60	Service_Cmpt	563409	male	spBar4	Enginecmpt.	564135	male
Se62	WCL_System	561690	male	spBar5	Enginecmpt.	564135	male
Se63	Rearaxlecmpt.	641132	female	spBar6	Enginecmpt.	564135	male
Se64	Rearaxlecmpt.	641132	female	spBar7	Enginecmpt.	564135	male
Se65	Dash	564042	female	spBar11	Rearvehicule	564135	male
Se66	FJB	564039	female	spBar12	Rearvehicule	564135	male
Se67	Frontaxlecmpt.	563159	female	spBar13	Enginecmpt.	564135	male
Se69	Frontaxlecmpt.	563159	female	spBar14	Enginecmpt.	564135	male
Se74	Rear_Axle_Cmpt	563340	male	spBar15	Enginecmpt.	564135	male
Se75	Service_Cmpt	563159	female	spBar16	Enginecmpt.	564135	male
Se77	FJB	563159	female	spBar19	Condensorcmt.	564135	male
Se78	Pneumaticplate	563159	female	spBar20	Condensorcmt.	564135	male
Se79	Front_Axle	563340	male	spBar21	Condensorcmt.	564135	male

# CONNECTORS LIST

No	Location	Part #	Gender	No	Location	Part #	Gender
spBar22	Enginectpt.	564135	male	Sw4	Dash	562763	male
spBar23	Enginectpt.	564135	male	Sw6	Dash	562763	male
spBar24	Enginectpt.	564135	male	Sw10A	LH_Console	562763	male
Spk1_L	Parcel_Rack_LH	563994	male	Sw12	Dash	562763	male
Spk1_R	Parcel_Rack_RH	563994	male	Sw14	Dash	562763	male
Spk2_L	Parcel_Rack_LH	563994	male	Sw16	Dash	562763	male
Spk2_R	Parcel_Rack_RH	563994	male	Sw17	Dash	562763	male
Spk3_L	Parcel_Rack_LH	563994	male	Sw18A	LH_Console	562763	male
Spk3_R	Parcel_Rack_RH	563994	male	Sw20	Dash	562763	male
Spk4_L	Parcel_Rack_LH	563994	male	Sw21	Dash	562763	male
Spk4_R	Parcel_Rack_RH	563994	male	Sw24	Dash	562763	male
Spk5_L	Parcel_Rack_LH	563994	male	Sw25	Dash	562763	male
Spk5_R	Parcel_Rack_RH	563994	male	Sw26	Dash	562763	male
Spk6_L	Parcel_Rack_LH	563994	male	Sw27	Dash	562763	male
Spk6_R	Parcel_Rack_RH	563994	male	Sw29	Dash	562763	male
Spk7_L	Parcel_Rack_LH	563994	male	Sw30	RJB	563135	male
Spk7_R	Parcel_Rack_RH	563994	male	Sw31.A	WCLdoor	563543	male
Spk8_L	Parcel_Rack_LH	563994	male	Sw24A	Dash	562763	male
Spk8_R	Parcel_Rack_RH	563994	male	Sw32	Dash	561477	female
Spk9_L	Parcel_Rack_LH	563994	male	Sw33	Dash	561476	male
Spk9_R	Parcel_Rack_RH	563994	male	Sw34	Outside_Front_RH	562477	male
Spk10_L	Parcel_Rack_LH	563994	male	Sw35	Console	562763	male
Spk10_R	Parcel_Rack_RH	563994	male	Sw38	LH_Console	562763	male
Spk11_L	Parcel_Rack_LH	563994	male	Sw40	LH_Console	561690	male
Spk11_R	Parcel_Rack_RH	563994	male	Sw41	LH_Console	562749	male
Spk12_L	Parcel_Rack_LH	563994	male	Sw42	WCLCmpt.	561635	female
Spk12_R	Parcel_Rack_RH	563994	male	Sw43	LH_Console	561690	male
Spk13_L	Parcel_Rack_LH	563994	male	Sw44.A	Servicecmpt.	562403	female
Spk13_R	Parcel_Rack_RH	563994	male	Sw45.A	3rd_Lugg_Cmpt	562403	female
Spk14_L	Parcel_Rack_LH	563994	male	Sw46.A	3rd_Lugg_Cmpt	562403	female
Spk14_R	Parcel_Rack_RH	563994	male	Sw46A.A	3rdlugg.cmpt.	562403	female
Spk15_L	Parcel_Rack_LH	563994	male	Sw49.A	2nd_Lugg_Cmpt	562403	female
Spk15_R	Parcel_Rack_RH	563994	male	Sw50.A	2nd_Lugg_Cmpt	562403	female
Spk16_L	Parcel_Rack_LH	563994	male	Sw51.A	1st_Lugg_Cmpt	562403	female
Spk16_R	Parcel_Rack_RH	563994	male	Sw52.A	1st_Lugg_Cmpt	562403	female
SpkDr_L	Parcelrack	563994	male	Sw55.A	Lavatory	560488	female
SpkDr_R	Parcelrack	563994	male	Sw55.B	Lavatory	560488	female
Sub1.A	Passenger_Area	564004	female	Sw56.A	Lavatory	560488	female
Sub2.A	Passenger_Area	564004	female	Sw56.B	Lavatory	560488	female
Sw1.C258	Driver_Area	561188	female	Sw57	WCL_Door	563543	male
Sw1.C259	Driver_Area	561186	male	Sw58	EngineCmpt.	563135	male
Sw2	Dash	562763	male	Sw59	Enginectpt.	563135	male
Sw3	Dash	562763	male	Sw63A	LHConsole	562763	male

# CONNECTORS LIST

No	Location	Part #	Gender	No	Location	Part #	Gender
Sw64.A	Service_Cmpt	560815	female	Sw135.B	WCLdoor	562119	female
Sw64.B	Service_Cmpt	560815	female	Sw135.C	WCLdoor	562119	female
Sw82	RJB	563135	male	Sw137	Dash	562763	male
Sw83.A	Dash	560082	female	Sw140	FJB	561566	female
Sw83.B	Dash	560815	female	Sw142	LHConsole	562763	male
Sw83.C	Dash	560082	female	Sw153	Dash	562763	male
Sw83.D	Dash	560815	female	Sw156	LH_Console	562763	male
Sw85	LH_Console	562749	male	Sw157	Dash	562763	male
Sw94.A	WCL_Door	562403	female	Sw158	Dash	562763	male
Sw94.B	WCLdoor	562403	female	Sw313.A	Lavatory	562615	female
Sw95.A	WCLdoor	562615	female	Sw313.B	Lavatory	562615	female
Sw95.B	WCLdoor	562615	female	Sw313.C	Lavatory	562615	female
Sw95.C	WCLdoor	562615	female	T0SS	Parcel_Rack_LH	560104	N/A
Sw96.A	WCL_Door	562615	female	T0SS1	Parcel_Rack_LH	560103	N/A
Sw96.B	WCL_Door	562615	female	tab69	Parcelrack	561626	N/A
Sw96.C	WCLdoor	562615	female	Tab70a	Parcelrack	561626	N/A
Sw97.A	WCLsystem	562615	female	Tab70b	Parcelrack	561626	N/A
Sw97.B	WCLsystem	562615	female	tab71a	Parcelrack	561626	N/A
Sw97.C	WCLsystem	562615	female	TBat9	RJB	560895	N/A
Sw98.A	WCLsystem	562615	female	TBat10	RJB	560895	N/A
Sw98.B	WCLsystem	562615	female	TBat11	RJB	560895	N/A
Sw98.C	WCLsystem	562615	female	TBat12	RJB	560895	N/A
Sw100A	Dash	562763	male	TBat13	RJB	560111	N/A
Sw109.A	1st_Lugg_LH	560079	female	TBat15	RJB	565164	N/A
Sw109.B	1st_Lugg_LH	560079	female	TBat20	RJB	560891	N/A
Sw110.A	1st_Lugg_RH	560079	female	TBat21	RJB	560891	N/A
Sw110.B	1st_Lugg_RH	560079	female	TBat22	RJB	560891	N/A
Sw111.A	2ndlugg.cmpt.	560079	female	TBat23	RJB	560891	N/A
Sw111.B	2ndlugg.cmpt.	560079	female	TBat24	RJB	560895	N/A
Sw112.A	2ndlugg.cmpt.	560079	female	TBat25	RJBMasterRelay	562880	N/A
Sw112.B	2ndlugg.cmpt.	560079	female	TBat39	RJB	562880	N/A
Sw113.A	2ndlugg.cmpt.	560079	female	TBat40	RJB	564166	N/A
Sw113.B	2ndlugg.cmpt.	560079	female	TBat_12V_E	RJB	563538	N/A
Sw114.A	3rd_Lugg_RH	560079	female	TBat_24V_E	RJB	563538	N/A
Sw114.B	3rd_Lugg_RH	560079	female	TBat_GND_E	RJB	563538	N/A
Sw115.A	Compr_Door	560079	female	Term0A	FJBGndStud	560587	N/A
Sw115.B	Compr_Door	560079	female	Term00A	FJB	560928	N/A
Sw125.A	Service_Cmpt	561457	female	Term00A1	FJB	560928	N/A
Sw125.B	Service_Cmpt	561457	female	Term00A2	FJB	560928	N/A
Sw134.A	WCLArea	562615	female	Term0EV1	EvapCmpt.ChassisGndStud	560926	N/A
Sw134.B	WCLArea	562615	female	Term0EV2	EvapCmpt.ChassisGndStud	560587	N/A
Sw134.C	WCLArea	562615	female	Term0F	FJBGndStud	560587	N/A
Sw135.A	WCLdoor	562119	female	Term00F	RJB	560086	N/A

# CONNECTORS LIST

No	Location	Part #	Gender	No	Location	Part #	Gender
Term00F1	FJB	563354	N/A	Term149A	UreaCmpt.	560096	N/A
Term00F2	FJB	563354	N/A	Term151	RJBBreakersPanel	560105	N/A
Term00F3	FJB	560928	N/A	Term151a	Parcel_Rack_LH	562286	N/A
Term00F5	FJB	560086	N/A	Term151b	Parcel_Rack_LH	562286	N/A
Term0FH	FJBGndStud	560587	N/A	Term151c	Parcel_Rack_LH	562286	N/A
Term00FH	FJB	560928	N/A	Term151d	Parcel_Rack_LH	562286	N/A
Term00FH1	FJB	560086	N/A	Term151e	RJBBreakersPanel	560105	N/A
Term00FH2	FJB	563354	N/A	Term152	RJBBreakersPanel	560105	N/A
Term0R1	RJBChassisGndStud	560587	N/A	Term152B	5thLuggageCmpt	561696	N/A
Term00R1	RJB	560086	N/A	Term153	RJBBreakersPanel	561696	N/A
Term00R2	RJB	563354	N/A	Term153A	RJBBreakersPanel	561696	N/A
Term00R3	RJB	563354	N/A	Term154	EvapCmpt.ChassisGndStud	560587	N/A
Term00R4	RJB	563354	N/A	Term154A	EvapCmpt.ChassisGndStud	561696	N/A
Term00R5	RJB	563354	N/A	Term155	Parcel_Rack_LH	560587	N/A
TermORFG	RJBChassisGndStud	561246	N/A	Term156	Fr_L_P_Rack	560094	N/A
TERMOSS1A	Parcel_Rack_LH	560086	N/A	Term157	Fr_L_P_Rack	560094	N/A
Term3	RJBChassisGndStud	560105	N/A	Term158	Fr_L_P_Rack	560094	N/A
Term4	RJB(RelayR3)	563538	N/A	Term159	Fr_L_P_Rack	560094	N/A
Term12VD4	RJBMasterRelay	561964	N/A	Term160	Fr_L_P_Rack	560094	N/A
Term20	RJB(RelayR3)	563538	N/A	Term161	Fr_L_P_Rack	560094	N/A
Term24V_Inv	Rear_Seat	561696	N/A	Term163A	Fr_L_P_Rack	560094	N/A
Term28	Evap_Cmpt	560587	N/A	Term163B	Fr_L_P_Rack	560094	N/A
Term36	FJBGndStud	560895	N/A	Term163C	Fr_L_P_Rack	560094	N/A
Term37	FJBGndStud	560894	N/A	Term164A	Fr_L_P_Rack	560094	N/A
Term43	FJBGndStud	563662	N/A	Term164B	Fr_L_P_Rack	560094	N/A
Term47	RJB	561560	N/A	Term164C	Fr_L_P_Rack	560094	N/A
Term50	RJB	561626	N/A	Term165A	Fr_L_P_Rack	560094	N/A
Term59	EvapCmpt.ChassisGndStud	560108	N/A	Term165B	Fr_L_P_Rack	560094	N/A
Term64	Evap_Cmpt	560108	N/A	Term165C	Fr_L_P_Rack	560094	N/A
Term75	Engine_Cmpt	564115	N/A	Term166	Fr_RL_1_Lugg	560094	N/A
Term76	Engine_Cmpt	565165	N/A	Term167	Fr_RL_1_Lugg	560094	N/A
Term103-A	Engine_Cmpt	568125	N/A	Term168	Fr_RL_1_Lugg	560094	N/A
Term103-B	Engine_Cmpt	564026	N/A	Term169A	Fr_L_P_Rack	560094	N/A
Term106	RJB	565166	N/A	Term169B	Fr_L_P_Rack	560094	N/A
Term107	EvapCmpt.ChassisGndStud	564203	N/A	Term169C	Fr_L_P_Rack	560094	N/A
Term116	Engine_Cmpt	563538	N/A	Term170A	Fr_L_P_Rack	560094	N/A
Term117	Engine_Cmpt	563538	N/A	Term170B	Fr_L_P_Rack	560094	N/A
Term130	RJB	560894	N/A	Term170C	Fr_L_P_Rack	560094	N/A
Term131	FJBGndStud	561696	N/A	Term180	Engine_Cmpt	560894	N/A
Term132	FJBGndStud	560895	N/A	Term200	Engine_Cmpt	560027	N/A
Term139	EvaporatorCmpt.	560104	N/A	Term201	FJBGndStud	564116	N/A
Term141	Engine_Cmpt	565166	N/A	Term230	RJB	560895	N/A
Term149	UreaCmpt.	560096	N/A	Term_12V_Bloc	RJB	564026	N/A

# CONNECTORS LIST

No	Location	Part #	Gender	No	Location	Part #	Gender
Term_12V_ECU	RJB	560926	N/A	TermA85	RJB	561725	N/A
Term_24V_Block	RJBBreakersPanel	563538	N/A	TermAFSS	Luggage_Cmpt	560076	N/A
Term_CB1	RJBBreakersPanel	564025	N/A	TermCB13	Rear_Seat	564071	N/A
Term_CB2	RJB	564024	N/A	TermF1	3rd_LH_Lugg_Cmpt	560264	N/A
Term_CB2A	RJBBreakersPanel	561560	N/A	TermF1A	3rd_LH_Lugg_Cmpt	560264	N/A
Term_CB3	RJBBreakersPanel	564025	N/A	TermF102	RJBBreakersPanel	562880	N/A
Term_CB5	RJBBreakersPanel	564025	N/A	TermF103	3rd_LH_Lugg_Cmpt	560268	N/A
Term_CB6	RJB	564024	N/A	TermF103A	3rd_LH_Lugg_Cmpt	560268	N/A
Term_CB6A	RJBBreakersPanel	561560	N/A	TermF116	RJB	561246	N/A
Term_CB8	RJBBreakersPanel	564025	N/A	TermF117	RJB	561246	N/A
Term_CB9	RJBBreakersPanel	564024	N/A	TermGal3	5thLuggageCmpt	561955	N/A
Term_CB10	RJBBreakersPanel	564026	N/A	TermGND_Inv	Rear_Seat	560895	N/A
Term_CB11	RJBBreakersPanel	564024	N/A	TermNeg	Engine_Cmpt	560086	N/A
Term_CB13	RJBBreakersPanel	561696	N/A	TermPos	Engine_Cmpt	560086	N/A
Term_CB13A1	Rear_Seat	561696	N/A	TermR12-5	Evap_Cmpt	561788	N/A
Term_CB13A2	Rear_Seat	564023	N/A	TermR21-A	FJB	560076	N/A
Term_CB13B1	Rear_Seat	564023	N/A	TermR21-B	FJB	560076	N/A
Term_CB15	RJB	561696	N/A	TermR28-3	Rear_Seat	561789	N/A
Term_CB15A	RJB	561560	N/A	TermR38-3	Rear_Seat	561789	N/A
Term_Evap_Fan	Evap_Cmpt	560108	N/A	TermR72-3	Rear_Seat	561789	N/A
Term_Evap_Relay	Evap_Cmpt	561788	N/A	TermR73-2	5thLuggageCmpt(R73)	563123	N/A
Term_FJB_GND_Jun	FJB	561458	N/A	TermR210-A	Parcelrack	560076	N/A
Term_GND_RJB_Blo	RJB	561789	N/A	TermR210-B	Parcelrack	560076	N/A
Term_Inv_24V_Stud	RJBBreakersPanel	561696	N/A	TermR_Inv	Rear_Seat	561789	N/A
Term_PH_Heater	RJB(RelayR3)	563538	N/A	TermRad1	FJBGndStud	561955	N/A
Term_PH_Rly	RJB(RelayR3)	561789	N/A	TermRad2	FJBGndStud	561955	N/A
Term_R_Melco_Bloc	RJBBreakersPanel	560104	N/A	TGND_TR	RJBChassisGndStud	560083	N/A
Term_R_Melco_Star	Engine_Cmpt	560103	N/A	TGNDR4	RJB	561458	N/A
Term_R_Starter	Engine_Cmpt	560103	N/A	VECF1	FJB	563186	male
Term_RJB_Ctrl_12V	RJBMasterRelay	563536	N/A	VECF2	FJB	563183	male
Term_RJB_Ctrl_Rly+	RJBMasterRelay	560815	N/A	VECF3	FJB	563185	male
Term_RJB_Ctrl_Rly-	RJBMasterRelay	560815	N/A	VECF4	FJB	563182	male
Term_RJB_Ctrl_Star	RJB	560587	N/A	VECF9	FJB	563448	male
Term_RJB_GND_Jun	RJB	561458	N/A	VECF10	FJB	563181	male
Term_So2_Starter	Engine_Cmpt	564573	N/A	VECF11	FJB	563184	male
Term_Start_Bat_Blo	RJB	562880	N/A	VECF12	FJB	563187	male
Term_Start_Bat_Sta	Engine_Cmpt	564280	N/A	VECR1	RJB	563186	male
Term_VECF_12VD	FJB	560104	N/A	VECR2	RJB	563183	male
Term_VECF_12WUP	FJB	563538	N/A	VECR3	RJB	563185	male
Term_VECF_24WUP	FJB	563537	N/A	VECR4	RJB	563182	male
Term_VECR_12WUP	RJB	564025	N/A	VECR9	RJB	563448	male
Term_VECR_24VD	RJB	564024	N/A	VECR10	RJB	563181	male
Term_VECR_24WUP	RJB	564025	N/A	VECR11	RJB	563184	male

# CONNECTORS LIST

No	Location	Part #	Gender	No	Location	Part #	Gender
VECR12	RJB	563187	male				
VECT2_plug	RearVehicle	563716	male				
VECT3	RearVehicle	563718	male				
VECT4	RearVehicle	563714	male				
Y80	Engine_Cmpt	563789	male				
Y81	Cond_Cmpt	563793	male				