


A947A	SCREEN TFT	LE 1 C
A947A1	FIXED SCREEN	LF 2 C
A947B	SCREEN TFT	LE 2 C
A947B1	FIXED SCREEN	LF 2 C
A947C	SCREEN TFT	LE 2 C
A947C1	FIXED SCREEN	LF 1 D
A947D	SCREEN TFT	LE 1 E
A947D1	FIXED SCREEN	LF 3 D
A947E	SCREEN TFT	LE 2 E
A952	WEBASTO TIMER	ND 4 C
A953	Cooper Electric Center.	BE 3 B
A955	CSDD DISPLAY	NE 0 A
A7001	AC UNIT	NB 0 C
A9066	CONTROL UNIT I/O-A CLIMATE CONTROL	BB 2 A
A9067	CONTROL UNIT I/O-B ROOF LEFT	BC 3 B
A9068	CONTROL UNIT I/O-B TOILET	BE 1 C
A9069	CONTROL UNIT I/O-B KITCHEN	BE 1 A
A9071	CONTROL UNIT I/O-B FLOOR	BF 1 A
A9072	CONTROL UNIT I/O-A DASHBOARD	BB 1 C
A9073	CONTROL UNIT I/O-A CLIMATE CONTROL	BF 1 C
A9077	CONTROL UNIT MASTER ID	Wrong world, out of range.
A9078	CONTROL UNIT, CLIMATE DISPLAY	NA 0 A
A9080	CONTROL UNIT I/O-B LEFT TOILET	BG 1 A
AC+	AC HEAT	AD 4 C
B21	Sensor,coolant temperature	ND 1 C
B22	SENSOR, OUTDOOR TEMPERATURE	ND 1 C
B958M	Sensor, Principal Tank Middle Toilet	EC 2 D
B959M	Sensor, Soil Tank Middle Toilet	EC 3 D
B961A	SENSOR EMERGENCY WINDOWS	JC 1 B
B961B	SENSOR EMERGENCY WINDOWS	JC 2 B
B961C	SENSOR EMERGENCY WINDOWS	JC 3 B
B961D	SENSOR EMERGENCY WINDOWS	JC 3 B
B961E	SENSOR EMERGENCY WINDOWS	JC 0 B
B961F	SENSOR EMERGENCY WINDOWS	JC 0 B
B961G	SENSOR EMERGENCY WINDOWS	JC 1 B
B962	SENSOR, OPTICAL FIRE DETECTOR	ID 0 D
B963	SENSOR, OUTDOOR TEMPERATURE	GC 2 C
B7070	INDUCTIVE SENSOR, ENGINE HATCH OPEN	OB 3 B
B7072	DEFROSTER TEMP. SENSOR	NA 1 E

 <b>Volvo Bus Corporation</b>	Document Title <b>WIRING DIAGRAM</b>			
	Document Type <b>PRODUCT SCHEMATIC</b>			
	Document No <b>22600119</b>	Issue Index <b>04</b>	Volume No <b>02</b>	Page No <b>4(18)</b>