


12-24V Power distribution FJB  
Customer adaptation option RH console switch



Refer to page 4.1 for complete details