

## Wiring diagram pages list

Wiring diagram pages		D	I	S			
Multiplex outputs list	<b>B1</b>	Dash backlighting	19.1	Ignition	3.2	Slide out front left	20.1
Multiplex inputs list	<b>B2</b>	Driver's lights	19.1			Slide out rear left	20.2
Multiplex error messages	<b>B3</b>	Driver window	30.1	<b>K</b>		Spares wires	8.1
Layout vehicule - harness	<b>C1</b>	Driver assist	16.2	Keyless entry system	29.1	Stop lights	26.2
Sound system	<b>C2</b>	Driver seat	17.1			Steering control ZF	37.2
Pins configuration	<b>D</b>	Docking lights	26.5	<b>L</b>		Steering multifunctions	41.1
Circuits list	<b>E</b>			Level low	32.1	Step lights	29.1
Circuit breakers list	<b>F</b>	ELD/ITS Gateway	42.4	Line departure warning	16.2	Sun visor	41.1
Connectors list	<b>G</b>	Engine ECU	14.1	Luggage doors lock/unlock	33.1 - 33.2		
Diodes list	<b>H</b>	Engine heater	14.1	Luggage cmpt. lighting	25.1		
Resistors list	<b>J</b>	Engine start	3.2				
Relays list	<b>K</b>	Engine & RJB cmpt. Light	25.1	<b>M</b>			
Fuses list	<b>L</b>	Entrance door light	29.1	Main dist. ignition & batt.	3.1		
Wire identification chart	<b>M</b>	ESP	16.1	Markers lights	26.1 - 26.2	<b>T</b>	
		Engine brake	12.1	Mirrors	31.1	Tag	32.1
<b>A</b>				Multiplex power distribution	7.1	Tail & licence lights	26.2
		<b>F</b>		Multiplex network	6.1 - 6.2	Tire pressure monitor	39.1
Air dryer	37.1	Fast idle	14.1			Trailer package	26.4
Alternators	1.1	Fans radiator	13.1			Trailer park brake	12.2
		Fire alarm	38.1	<b>P</b>		Transmission ECU	15.1
		Fire suppression system	38.1	Park brake sensor	12.1		
<b>B</b>		Flashers	26.1-26.2	Park brake trailer sensor	12.2	<b>U</b>	
Back-up warnings	26.3	Fog lights	26.5	Power distribution FJB 12V	4.1	Urea system	14.2
Batteries & Equalizer	1.1	Fuel gauge	10.1	Power distribution FJB 24V	4.2		
Brake pedal sensor	12.1			Pwr dist. RJB 12V & 24V	5.1		
		<b>G</b>		Power outlets 12V	30.2	<b>V</b>	
		Grounds electronic	2.1			Volvo link TGW	37.1
<b>C</b>		Grounds chassis	2.2				
Cigar lighter	30.2			<b>R</b>		<b>W</b>	
Clearance lights	26.1-26.2	<b>H</b>		Retarder	12.1 - 15.1	Windows ajar	27.1
Cluster	10.1	Hazard	26.1	RJB fan	1.1	Wipers & washer	34.1
Cornering lights	26.5	Head lights	26.1			Wheelchair Lift	36.1
Cruise control	14.1	Horn	9.1				
Converter interface	21.1	Hvac defroster	18.1				
Charging system	3.2	Hvac passenger full	18.2				
		Hvac passenger small	18.3				