

FUSES CODE

No.	PAGE	AMP.	#PREV.	LOCATION	FUNCTION
F 1	6	10A	562407	RR. JCT. BOX	WORLD TRANSMISSION 12V BATTERY
F 2	6	10A	562407	RR. JCT. BOX	WORLD TRANSMISSION 12V IGNITION
F 3	7	20A	562605	FR. JCT. BOX	ELECTRICAL HORNS
F 4	7	5A	562259	FR. JCT. BOX	FIRE ALARM
F 5	8	10A	562407	RR. JCT. BOX	AIR DRYER
F 6	8	5A	562602	FR. JCT. BOX	ETHER COLD START & CRUISE DECEL SW.
F 7	8	5A	562602	FR. JCT. BOX	PARKING BRAKE PRESSURE SW.
F 8	9.2	10A	562407	FR. JCT. BOX	CORNERING LTS
F 9	9.3	15A	562604	RR. JCT. BOX	DOCKING LTS
F 10	9.3	15A	562604	FR. JCT. BOX	FOG LTS
F 11	11.1	5A	562259	FR. JCT. BOX	FRONT SERVICE CPT LTS
F 14	11.2	7.5A	562602	FR. JCT. BOX	DRIVER'S LTS
F 21	14.2	10A	560061	RR. JCT. BOX	FUEL PRIME PUMP
F 23	19	15A	562604	FR. JCT. BOX	DRIVER'S WINDOW LIFTER
F 24	19	10A	562407	FR. JCT. BOX	CIGAR LIGHTER
F 25	19	3A	562599	FR. JCT. BOX	SUN VISOR
F 26	14	5A	562259	FR. JCT. BOX	WATER HTR TIMER
F 32	13	5A	562259	FR. JCT. BOX	DRIVER'S SEAT HEATER
F 40	13	20A	562605	FR. JCT. BOX	HEATED WINDSCHIELD LH
F 41	13	20A	562605	FR. JCT. BOX	HEATED WINDSCHIELD RH
F 46	16.1	7.5A	562602	FR. JCT. BOX	MIRROR ADJUST & HEATED 24V SPARTAN
F 47	16.2 16.3	7.5A	562602	FR. JCT. BOX	MIRROR ADJUST & HEATED 12V RAMCO
F 49	14	20A	562605	RR. JCT. BOX	PRE-HEAT WATER HEATER
F 50	14	20A	562605	RR. JCT. BOX	PRE-HEAT WATER HEATER WEBASTO
F 52	13	5A	562259	FR. JCT. BOX	CO-PILOT SEAT HEATER
F 53	20	3A	560893	RR. JCT. BOX	BACK-UP MONITOR DOOR SOLENOID
F 55	20	7.5A	562602	RR. JCT. BOX	BACK-UP MONITOR CAMERA HEATER
F 56	20	7.5A	562602	RR. JCT. BOX	BACK-UP MONITOR CAMERA
F 57	4	1A	560893	RR. JCT. BOX	GENERATOR RUN RELAY