

# INDEX

A	A/C AND HEAT SYSTEM	P. 18	E	ENGINE BLOCK HEATER	P. 17	P	PARKING BRAKE ALARM	P. 7
	AIR DRYER	P. 8		ENGINE BRAKE SYSTEM	P. 25		PARKING BRAKE SWITCH	P. 8
	ALARM AND SIGNAL	P. 7		ENGINE CONTROL	P. 4		*PRODRIVER	P. 8
	ABS	P. 27		ETHER COLD START	P. 8		PYROMETER	P. 23
	ARRANGEMENT - CABLE	P. B		EXTERIOR LIGHTING	P. 9	R	RETARDER	P. 25
	ARRANGEMENT - HARNESS	P. C	F	FAN CLUTCH-RADIATOR	P. 8	S	SPEEDOMETER (VDO)	P. 21
	ARRANGEMENT - SPARE WIRE	P. D		FAST IDLE	P. 5		SUN VISOR	P. 23
B	BACK-UP ALARM	P. 11		FUEL (LO) WARNING LT.	P. 8	T	TACHOMETER (VDO)	P. 21
	BACK-UP MONITOR	P. 24		FUEL WATER FILTER	P. 8		THERMOMETER-DIGITAL	P. 24
C	CHARGING SYSTEM	P. 4	G	GROUND SYSTEM	P. 3		TRANSMISSION WORLD	P. 6
	CIGAR LIGHTER	P. 23	I	INTERIOR LIGHTING	P. 13	W	WATER HEATER PRE-HEAT	P. 17
	CODE - CIRCUIT NUMBER	P. E	K	KEYLESS ENTRY SYSTEM	P. 15		WINDOW AJAR	P. 23
	CODE - CIRCUIT BREAKER	P. F	L	LEVEL LOW SYSTEM	P. 22		WINDSHIELD(UP)-HEATED	P. 16
	CODE - CONNECTOR	P. G		LUGGAGE DOOR LOCK	P. 16		WIPER & WASHER	P. 12
	CODE - DIODE	P. H	M	MIRROR-RR VIEW ADJUST. & HEATED	P. 20			
	CODE - RELAY	P. I						
	CODE - RESISTOR	P. J						
	CODE - WIRING KEY	P. K						
	CRUISE CONTROL - D.D.E.C.	P. 5						
D	D.D.E.C. III	P. 5						
	DIFFERENTIAL OIL TEMP.	P. 8						
	DISTRIBUTION 12V	P. 2						
	DISTRIBUTION 24V	P. 1						
	DRIVER'S WINDOW LIFTER	P. 23						
	DRIVER'S SEAT-ELECT. ADJ.	P. 16						
	DRIVER'S SEAT-HEATER	P. 16						