

Relays list

Relay ID	Location	Part No	Function	Page
R1	RJB	562364	Master Relay	3.1 Main Disti 2 A
R3	RJB	563348	12v Ignition & Accessories	3.1 Main Disti 2 B
R4	FJB	563332	Cut off water preheater	38.1 Fire Supp 3 B
R5	RJB	563332	Batteries Charging Optionnal	17.1 Pre Heat 3 C
R12	Evap cmpt.	563348	Evaporator	18.2 HvacPass 4 C
R20	RJB	563332	Water Pump	17.1 Pre Heat 3 B
R21	FJB	560493	Emergency cutout	4.1 Dist 12V FJB 1 B
R22	FJB VECF	563269	Ecu Ignition	4.1 Dist 12V FJB 1 C
R23	FJB VECF	563269	Shutdown	4.1 Dist 12V FJB 1 D
R24	FJB VECF	563269	Ecu IShift	4.1 Dist 12V FJB 1 D
R25	FJB VECF	563269	24V Ignition	4.2 Dist 24V FJB 1 C
R26	Evap Cmpt	563332	Pre-Heat	18.2 HvacPass 3 B
R27	RH Console	563332	Lower wipers	34.1 wiper washer 3 D
R28	RH Console	563332	Upper wipers	34.1 wiper washer 4 A
R29	RJB	563348	Preheater Volvo	14.1 Engine Ecu 2 E
R30	RJB	563269	12v Engine running	4.1 Dist 12V FJB 4 A
R31	RJB	563269	12v Ignition	4.1 Dist 12V FJB 4 B
R34	RJB	564218	12v Rr Engine Ecu	3.2 Ign Start 3 D
R36	RJB	563269	Fire Extinguisher	9.1 Horn 1 A
R37	RJB	563269	Electric horn	9.1 Horn 2 B
R38	RJB	563269	Cigar lighter / 12V Outlet	30.2 Outlet 12v 1 B
R40	RJB	563332	Transmission IShift	15.2 Trans IShift 1 D
R47	WCL Pump	563332	WCL Door Open Option	36.1 WCL Ricon 6 C
R52	RJB VECT	563270	Clearance lights & side markers	26.4 Trailer 2 B
R53	RJB VECT	563270	Flashers left side	26.4 Trailer 2 B
R54	RJB VECT	563270	Brake lights	26.4 Trailer 2 C
R55	RJB VECT	563270	Flashers right side	26.4 Trailer 2 C
R56	RJB VECT	563270	Tail & licence lights	26.4 Trailer 2 D
R72	5th Bay	563348	Inverter 1	40.1 Inverters 3 C
R73	5th Bay	563348	Inverter 2	40.1 Inverters 3 C
R 12VISS	Parcel Rack LH 1st Cmpt	563337	Sound System	35.6 VSS HDMI 6 G
R Starter	RJB	564095	Starter Relay Control	3.2 Ign Start 3 D