

| No.  | LOCATION                          | (NB)<br>TYPE | *PIN<br>CAVITY | *SOCKET<br>HOUSING | HOUSING |
|------|-----------------------------------|--------------|----------------|--------------------|---------|
| C3   | UNDER DASH-LH                     | AMP CPC      | 37             | 561645             | 561646  |
| C7   | FR SERVICE COMPT.-CLUTCH SW       | ITT SS       | 3              | 561111             | 561080  |
| C8   | FR JCT PANEL VCR FEED             | AMP MNL      | 2              | 561248             | 561247  |
| C11  | LH CONSOLE SW-MIRROR              | AMP MNL      | 3              | 561667             | 561550  |
| C12  | LH CONSOLE SW-MIRROR HTR          | AMP MNL      | 2              | 561248             | 561247  |
| C13  | LH CONSOLE SW-MIRROR              | AMP MNL      | 6              | 561552             | 561515  |
| C14  | UNDER DASH LH-MIRROR              | AMP MNL      | 9              | 561670             | 561669  |
| C15  | UNDER DASH RH-MIRROR              | AMP MNL      | 9              | 561670             | 561669  |
| C18  | UNDER DASH-FIRE ALARM             | AMP MNL      | 2              | 560900             | 560898  |
| C19  | UNDER DASH-A/C & HEAT SYST. TC    | AMP MNL      | 10             | 561072             | 561110  |
| C20  | RR JCT BOX DIODES                 | AMP MNL      | 9              | 561670             | 561669  |
| C21  | LUGGAGE COMPT.-LOCK DOOR MOT. PED | AMP MNL      | 2              | 561072             | 562076  |
| C22  | ENGINE COMPT.-CYCLOP LT           | AMP MNL      | 2              | 561566             | 561690  |
| C26  | UNDER INSTRUMENT.-PANEL RHEO. TC  | AMP MNL      | 2              | 561030             | 560997  |
| C29  | FR SERVICE COMPT.-VIM FEED        | AMP MNL      | 3              | 561781             | 561782  |
| C32  | RH CONSOLE-DRV TEMP SENSOR        | BURNDY       | 3              | 561044             | 561104  |
| C33  | FRSERVICE COMPT. DDEC VSS         | AMP MNL      | 2              | 561566             | 561690  |
| C34  | RH CONSOLE-DRV TEMP CTRL          | BURNDY       | 6              | 561044             | 561104  |
| C35  | RECIRCULATED AIR GRIL.-SENSOR     | BURNDY       | 3              | 561044             | 561104  |
| C36  | LH CONSOLE SW-CRUISE ON/OFF       | SWF          | 8              | 561072             | 561107  |
| C37  | LH CONSOLE SW-CRUISE SET          | SWF          | 8              | 561072             | 561107  |
| C38  | LH CONSOLE SW-CRUISE RESUME       | SWF          | 8              | 561072             | 561107  |
| C41  | UNDER DASH-FLASHER UNIT           | TC           | 2              | 561940             | 561940  |
| C49  | LAVATORY NIGHT LTS                | AMP MNL      | 2              | 560900             | 560898  |
| C50  | RH CONSOLE-PAS. TEMP CTRL         | BURNDY       | 6              | 561044             | 561104  |
| C51  | RH CONSOLE SW-A/C & HEAT          | SWF          | 8              | 561072             | 561107  |
| C52  | ENGINE COMPT.-COMPRESSOR OSC      | AMP MNL      | 2              | 561566             | 561690  |
| C53  | ENGINE COMPT.-COMPRESSOR OSC      | AMP MNL      | 2              | 561566             | 561690  |
| C54  | ENGINE COMPT.-COMPRESSOR OSC      | AMP MNL      | 1              | 560908             | 560697  |
| C61  | ENGINE COMPT.-FUEL FILTER         | AMP MNL      | 2              | 561566             | 561690  |
| C67  | LH UNDER DASH-AMPLIF. RH SPK      | BLAUPUNKT    | 2              | 561988             | 561988  |
| C68  | LH UNDER DASH-AMPLIF. RH SPK      | BLAUPUNKT    | 2              | 561988             | 561988  |
| C73  | LH SW PANEL-MULTIFUNC. LEV.       | AMP FF       | 8              | 561188             | 561188  |
| C74  | LH SW PANEL-MULTIFUNC. LEV.       | AMP FF       | 6              | 561044             | 561104  |
| C78  | LUGGAGE COMPT.-DOOR LOCK 4 LH     | AMP MNL      | 4              | 560851             | 560852  |
| C79  | LUGGAGE COMPT.-DOOR LOCK 4 RH     | AMP MNL      | 4              | 560851             | 560852  |
| C80  | FR JCT PANEL-LUG. DOOR LOCK       | AMP MNL      | 6              | 561552             | 561515  |
| C81  | LUGGAGE COMPT.-DOOR LOCK 1 LH     | AMP MNL      | 4              | 560851             | 560852  |
| C82  | LUGGAGE COMPT.-DOOR LOCK 1 RH     | AMP MNL      | 4              | 560851             | 560852  |
| C83  | UNDER DASH-FLASHER MODULE         | TC           | 10             | 561072             | 561110  |
| C84  | UNDER DASH-A/C SYSTEM             | TC           | 3              | 561091             | 561071  |
| C85  | LUGGAGE COMPT.-DOOR LOCK 3 RH     | AMP MNL      | 4              | 560851             | 560852  |
| C86  | LUGGAGE COMPT.-DOOR LOCK 3 LH     | AMP MNL      | 4              | 560851             | 560852  |
| C88  | RR END ROOF-CLEARANCE LTS         | AMP MNL      | 2              | 560900             | 560898  |
| C90  | RR ROOF AUX. A/C THERMOST.        | BURNDY       | 6              | 561044             | 561104  |
| C91  | RR ROOF AUX. A/C TMP SENSOR       | BURNDY       | 6              | 561044             | 561104  |
| C92  | RR ROOF AUX. A/C FAN RH           | TC           | 2              | 561030             | 560997  |
| C93  | RR ROOF AUX. A/C FAN LH           | TC           | 2              | 561030             | 560997  |
| C94  | RR ROOF AUX. A/C FAN RES LH       | AMP MNL      | 2              | 560900             | 560898  |
| C95  | RR ROOF AUX. A/C FAN RES RH       | AMP MNL      | 2              | 560900             | 560898  |
| C96  | RR ROOF AUX. A/C LIQ SOL VAL      | TC           | 2              | 561030             | 560997  |
| C97  | RR ROOF AUX. A/C SHUT SOL VAL     | AMPHENOL     | 2              | 560412             | 560412  |
| C105 | UNDER DASH RH-DRV LIQ SOL VL      | TC           | 2              | 561030             | 560997  |
| C106 | UNDER DASH RH-DRV WTR VALVE       | TC           | 2              | 561030             | 560997  |
| C107 | UNDER DASH RH-DRV HTR RH FAN      | TC           | 2              | 561030             | 560997  |
| C108 | UNDER DASH RH-DRV HTR LH FAN      | TC           | 2              | 561030             | 560997  |
| C111 | LH CONSOLE SW-DRIVER/LTS          | SWF          | 8              | 561072             | 561107  |

| No.  | LOCATION                      | (NB)<br>TYPE | *PIN<br>CAVITY | *SOCKET<br>HOUSING | HOUSING |
|------|-------------------------------|--------------|----------------|--------------------|---------|
| C112 | LH CONSOLE SW-GENERAL LTS     | SWF          | 8              | 561072             | 561107  |
| C114 | ENGINE DDEC-SPEED SIGNAL      | AMP MNL      | 2              | 561566             | 561590  |
| C115 | RR JCT BOX-ENGINE ACCE.       | DEUTSCH      | 40             | 562281             | 562284  |
| C116 | DRIVE AXLE COMPT.-AIR DRYER   | AMP MNL      | 2              | 561072             | 562251  |
| C119 | ENGINE COMPT.-LH LOWER LAMP   | AMP MNL      | 6              | 561606             | 561607  |
| C120 | ENGINE COMPT.-LH LOWER LAMP   | AMP MNL      | 6              | 561606             | 561607  |
| C123 | HAT RACK-BALLAST RH           | AMP MNL      | 6              | 561552             | 561515  |
| C123 | HAT RACK-BALLAST RH           | AMP MNL      | 6              | 561552             | 561515  |
| C124 | HAT RACK-FLUORESCENT          | AMP MNL      | 4              | 561551             | 561668  |
| C125 | HAT RACK-FLUORESCENT          | AMP MNL      | 4              | 561551             | 561668  |
| C126 | HAT RACK-READING LTS          | AMP MNL      | 2              | 560900             | 560898  |
| C130 | LH CONSOLE SW-READING LTS     | SWF          | 8              | 561072             | 561107  |
| C131 | LH CONSOLE SW-LUG-DOOR LOCK   | SWF          | 6              | 561072             | 561107  |
| C132 | LH CONSOLE SW-PAS & HOS CHIME | SWF          | 8              | 561072             | 561107  |
| C133 | LH CONSOLE SW-JACOB OR RET.   | SWF          | 8              | 561072             | 561107  |
| C134 | LH CONSOLE SW-GALLEY          | SWF          | 8              | 561072             | 561107  |
| C135 | LH SW PANEL-ETHER             | SWF          | 8              | 561072             | 561107  |
| C136 | LH CONSOLE SW-MIRROR HTR      | SWF          | 8              | 561072             | 561107  |
| C137 | RH SW PANEL-HEAD LAMP         | SWF          | 8              | 561072             | 561107  |
| C138 | RH SW PANEL-SPARE             | SWF          | 8              | 561072             | 561107  |
| C139 | RH SW PANEL-FOG LAMP          | SWF          | 8              | 561072             | 561107  |
| C140 | FR JCT PANEL-BAT. H/LO        | AMP MNL      | 2              | 560900             | 560898  |
| C141 | ENGINE COMPT.-B/UP ALARM      | AMP MNL      | 2              | 561566             | 561590  |
| C142 | FR SERVICE CPT-LH MARKER LTS  | ITT SS       | 3              | 561111             | 561080  |
| C143 | RR LH HAT RACK-FEEDING        | AMP MNL      | 9              | 561661             | 561662  |
| C144 | RR RH HAT RACK-FEEDING        | AMP MNL      | 9              | 561661             | 561662  |
| C145 | RH HAT RACK-BALLAST           | AMP MNL      | 4              | 560851             | 560852  |
| C146 | FR SERVICE CPT-RH MARKER LTS  | ITT SS       | 3              | 561111             | 561080  |
| C147 | RR ROOF LH-EMERGENCY EXIT LTS | AMP MNL      | 2              | 560900             | 560898  |
| C148 | RR ROOF RH-EMERGENCY EXIT LTS | AMP MNL      | 2              | 560900             | 560898  |
| C149 | LH HAT RACK-BALLAST           | AMP MNL      | 4              | 560851             | 560852  |
| C150 | FR RH HAT RACK-110V FLUOR     | AMP MNL      | 2              | 561248             | 561247  |
| C151 | FR LH HAT RACK-110V FLUOR     | AMP MNL      | 2              | 561248             | 561247  |
| C152 | LH HAT RACK-GENERAL LTS       | AMP MNL      | 3              | 561667             | 561550  |
| C153 | RH HAT RACK-GENERAL LTS       | AMP MNL      | 3              | 561667             | 561550  |
| C154 | RH SW PANEL-HAZARD            | SWF          | 8              | 561072             | 561107  |
| C155 | LH SW PANEL-FAST IDLE         | SWF          | 8              | 561072             | 561107  |
| C156 | LH SW PANEL-STP ENG. OVER.    | SWF          | 8              | 561072             | 561107  |
| C158 | RR ROOF AUX. A/C FEEDING      | AMP MNL      | 3              | 561667             | 561550  |
| C160 | FR SERVICE CPT-INTERFACE      | AMP CPC      | 37             | 561644             | 561646  |
| C161 | ENGINE DDEC III-ECM           | PED          | 30             | 561600             | 561600  |
| C162 | ENGINE DDEC III-ACCESSORIES   | PED WP       | 4              | 561610             | 561611  |
| C163 | ENGINE CPT-COOLANT PROBE      | PED MP       | 2              | 562350             | 562350  |
| C164 | FR SERVICE JCT BOX            | AMP CPC      | 22             | 561709             | 561710  |
| C165 | FR SERVICE JCT BOX            | AMP CPC      | 16             | 561693             | 561695  |
| C166 | UNDER INSTRUMENT PANEL        | AMP CPC      | 16             | 561639             | 561640  |
| C167 | FR SERVICE CPT-EL. FOOT PEDAL | PED WP       | 3              | 561781             | 561782  |
| C168 | FR SERVICE CPT-DDR            | DEUTSCH      | 6              | 562360             | 562360  |
| C169 | FR SERVICE CPT-WORLD TR. VIM  | AMP CPC      | 16             | 561638             | 561640  |
| C172 | ENGINE COMPT-WATER TANK HEAT. | PED WP       | 2              | 561566             | 561690  |
| C173 | LAV.POTABLE-WATER TANK HEAT.  | AMP MNL      | 2              | 560900             | 560898  |
| C175 | FR SERV CPT-KNEELING FEEDING  | PED WP       | 3              | 561781             | 561782  |
| C177 | GALLEY-REFRIGERATOR           | AMP MNL      | 2              | 561248             | 561247  |
| C179 | RH HAT RACK-110V MONITOR      | MOLEX        | 4              | 561477             | 561476  |
| C181 | FR SERV CPT-KNEELING MODULE   | AMP MNL      | 12             | 561735             | 561734  |
| C182 | FR SERVICE CPT-SPEED SW       | AMP HDP      | 15             | 562012             | 562012  |
| C184 | FR SERV CPT-KNEEL. MOD. CTRL  | AMP MNL      | 3              | 561550             | 561550  |
| C184 | FR AXLE-KNEELING PROXIMITY SW | AMP MNL      | 3              | 561667             | 561550  |
| C185 | FR SERV CPT-KNEEL. MOD. EXH.  | AMP MNL      | 3              | 561550             | 561550  |

PREVOST CAR inc.

WIRING DIAGRAM

NO: D060871

P. G 1/2

REVISION  
000

| No.  | LOCATION                      | (NB)<br>TYPE | *PIN<br>CAVITY | *SOCKET<br>HOUSING | HOUSING |
|------|-------------------------------|--------------|----------------|--------------------|---------|
| C187 | FR SERV CPT-KNEEL. MOD. BRK   | AMP MNL      | 3              | 561550             | 561550  |
| C187 | FR SERVICE JCT BOX-RESISTORS  | AMP MNL      | 6              | 561552             | 561515  |
| C188 | LH CONSOLE SW-KNEELING        | SWF          | 8              | 561072             | 561107  |
| C190 | FR SERVICE CPT.-WORLD TR VIM  | AMP MNL      | 30             | 561600             | 561600  |
| C192 | GALLEY-FEEDING                | AMP CPC      | 3              | 561862             | 561847  |
| C194 | GALLEY SW-CONTAINER RH        | SWF          | 8              | 561072             | 561107  |
| C195 | GALLEY SW-CONTAINER LH        | SWF          | 8              | 561072             | 561107  |
| C199 | FR SERV. JCT BOX-SERVICE BRK  | AMP MNL      | 3              | 561667             | 561550  |
| C200 | LH CONSOLE SW-24V FLUOR       | SWF          | 8              | 561072             | 561107  |
| C201 | UNDER INSTRUMENT PANEL        | AMP MNL      | 2              | 560900             | 560898  |
| C202 | UNDER INSTRUMENT PANEL        | AMP CPC      | 9              | 561636             | 561637  |
| C205 | LH UNDER DASH-AMPLIF. LH SPK  | BLAUPUNKT    | 2              | 561988             | 561988  |
| C206 | RH CONSOLE-FR DEFROSTER       | TC           | 2              | 561030             | 560997  |
| C207 | RH CONSOLE-DRV RHEOSTAT       | AMP MNL      | 6              | 561552             | 561515  |
| C208 | UNDER DASH-DRV HTR MODULE     | AMP MNL      | 9              | 561670             | 561669  |
| C209 | UNDER DASH-DRV HTR MODULE     | AMP MNL      | 9              | 561670             | 561669  |
| C210 | LH UNDER DASH-AMPLIF. LH SPK  | BLAUPUNKT    | 2              | 561988             | 561988  |
| C211 | RH CONSOLE-VCR VOLUME         | AMP MNL      | 4              | 561551             | 561668  |
| C212 | LH CONSOLE SW-VCR VIDEO       | SWF          | 8              | 561072             | 561107  |
| C213 | FR ROOF-CLEARANCE LT          | AMP MNL      | 2              | 560900             | 560898  |
| C214 | UNDER DASH PANEL-TACHOGRAPH   | V.D.O.       | 8              | 562041             | 562041  |
| C215 | UNDER DASH PANEL-TACHOGRAPH   | V.D.O.       | 8              | 562043             | 562043  |
| C216 | UNDER DASH PANEL-TACHOGRAPH   | AMP MNL      | 4              | 560851             | 560852  |
| C217 | FR LH HAT RACK-SPEAKER        | AMP MNL      | 4              | 561659             | 561660  |
| C218 | FR RH HAT RACK-SPEAKER        | AMP MNL      | 4              | 561659             | 561660  |
| C219 | DASH RHEOSTAT-P.A. VOLUME     | MOLEX        | 4              | 561477             | 561476  |
| C220 | LH UNDER DASH-P.A. VOLUME     | AMP MNL      | 3              | 561667             | 561550  |
| C221 | LH UNDER DASH-AMPLIFIER FEED  | AMP MNL      | 3              | 561550             | 561667  |
| C222 | LH UNDER DASH-P.A. RADIO      | AMP MNL      | 9              | 561670             | 561669  |
| C223 | LH UNDER DASH-P.A. RADIO      | AMP MNL      | 9              | 561670             | 561669  |
| C224 | LH UNDER DASH-PA & RADIO FEED | AMP MNL      | 6              | 561552             | 561515  |
| C225 | LH UNDER DASH-PA MICRO OUTLET | AMP MNL      | 3              | 561667             | 561550  |
| C226 | LH UNDER DASH-PA MICRO OUTLET | AMP MNL      | 3              | 561667             | 561550  |
| C227 | RH CONSOLE-SPEAKER CONTROL SW | SWF          | 8              | 561072             | 561107  |
| C229 | LH UNDER DASH-PA DRV SPEAKERS | AMP MNL      | 4              | 561551             | 561668  |
| C230 | ENG.CPT.-FUEL PRIME PUMP SW.  | PED WP       | 2              | 561566             | 561690  |
| C231 | ENG.CPT.-FUEL PRIME PUMP      | PED WP       | 2              | 561566             | 561690  |
| C232 | LAST LUGGAGE-INVERTER         | AMP MNL      | 4              | 561551             | 561668  |
| C233 | MICRO OUTLET SOCKET           | MOLEX        | 4              | 561477             | 561476  |
| C234 | UNDER INSTRUMENT PANEL-VDO    | AMP MNL      | 4              | 560851             | 560852  |
| C235 | UNDER INSTRUMENT PANEL-VDO    | AMP MNL      | 4              | 560851             | 560852  |
| C236 | FR SERVICE CPT CENTER-ABS     | AMP CPC      | 14             | 561585             | 561583  |
| C237 | FR AXLE CPT-ABS RH SENSOR     | WABCO        | 2              | 641132             | 641098  |
| C238 | FR AXLE CPT-ABS RH VALVE      | WABCO        | 3              | 641098             | 641098  |
| C239 | FR AXLE CPT-ABS LH VALVE      | WABCO        | 3              | 641098             | 641098  |
| C240 | FR AXLE CPT-ABS LH SENSOR     | WABCO        | 2              | 641132             | 641098  |
| C241 | DRIVE AXLE CPT-ABS            | PED WP       | 6              | 561606             | 561607  |
| C242 | DRIVE AXLE CPT-ABS LH SENSOR  | DEUTSCH      | 2              | 562486             | 562485  |
| C243 | DRIVE AXLE CPT-ABS LH VALVE   | WABCO        | 3              | 641098             | 641098  |
| C244 | DRIVE AXLE CPT-ABS RH VALVE   | WABCO        | 3              | 641098             | 641098  |
| C245 | DRIVE AXLE CPT-ABS RH SENSOR  | DEUTSCH      | 2              | 562486             | 562485  |
| C246 | DRIVE AXLE CPT-ABS SPARE      | PED WP       | 4              | 561610             | 561611  |
| C247 | FR SERVICE CPT-ABS MODULE     | WABCO        | 35             | 561094             | 561094  |
| C248 | DRIVE AXLE CPT-ABS            | PED WP       | 6              | 561606             | 561607  |
| C249 | FR SERVICE CPT-ABS/DDEC       | PED WP       | 2              | 561566             | 561690  |
| C250 | RH SW PANEL-B/UP CANCEL       | SWF          | 8              | 561072             | 561107  |

PREVOST CAR inc.

WIRING DIAGRAM

NO: D060871

P. G 2/2

REVISION  
003

| No.  | LOCATION                     | (NB)<br>TYPE | *PIN<br>CAVITY | *SOCKET<br>HOUSING | HOUSING |
|------|------------------------------|--------------|----------------|--------------------|---------|
| C251 | RH SW PANEL-SEAT HTR         | SWF          | 8              | 561072             | 561107  |
| C252 | LH SW PANEL-SWITCH LT        | SWF          | 2              | 561072             | 561837  |
| C254 | FR SERVICE JCT BOX-ABS       | AMP CPC      | 16             | 561693             | 561695  |
| C255 | RH CONSOLE-RADIO             | AMP MNL      | 9              | 561670             | 561669  |
| C257 | ENGINE COMPT-WATER HEATER    | AMP FF       | 6              | 561552             | 561515  |
| C258 | DRIVER GUARD WATER HTR TIMER | AMP FF       | 8              | 561888             | 562363  |
| C259 | ENGINE COMPT-WATER HEATER    | TC           | 2              | 561597             | 561597  |
| C260 | ENGINE COMPT-WATER HEATER    | TC           | 2              | 561073             | 561073  |
| C261 | ENGINE COMPT-WATER HEATER    | TC           | 2              | 561597             | 561597  |
| C267 | LUGGAGE COMPT. LTS - 1       | AMP MNL      | 2              | 561248             | 561247  |
| C268 | LUGGAGE COMPT. LTS - 2       | AMP MNL      | 2              | 561248             | 561247  |
| C269 | LUGGAGE COMPT. LTS - 3 RH    | AMP MNL      |                |                    |         |