

RELAYS LIST

No	Location	Part #	Function	Page					
R1	RJB	562364	MasterR1	3.1					
R3	RJB	563348	12vlgn/Acc	3.1					
R4	FJB	563332	CutPreHeat	17.1					
R12	Evap_cmpt.	563348	EvaporatorRelay	18.2					
R13	WCLPump	563332	WCLUpperDoorLOCK	36.1					
R14	WCLPump	563332	WCLUpperDoorLOCK	36.1					
R20	Evap_Cmpt	563332	Wat.Pump	17.1					
R21	FJB	561991	24vRelayLatching	3.2					
R22	FJB_VECF	563269	Eculgn	4.1					
R23	FJB_VECF	563269	Shutdown	4.1					
R24	FJB_VECF	563269	Spare12WUP	4.1					
R25	FJB_VECF	563269	24Vlgn	4.2					
R26	Evap_Cmpt	563332	Pre-Heat	18.2					
R27	RHConsole	563332	Wipers	34.1					
R29	RJB	563348	Preheater	14.1					
R30	FJB	563332	12vENGRUN	4.1					
R31	FJB	563332	12vIGN	4.1					
R34	RJB	564218	12vEngEcu	3.2					
R36	FJB	563269	Fire_Extin	9.1					
R37	FJB	563269	Electhorn	9.1					
R47	WCLPump	563332	WCLDoorOpen	36.1					
R55	FJB	563332	StairFanCtrl	18.2					
R60	VECPR	563269	*opt*	5.2					
R61	VECPR	563269	*opt*	5.2					
R62	VECPR	563269	*opt*	5.2					
R63	VECPR	563269	*opt*	5.2					
R210	FJB	561991	24vRelayLatching	5.2					
R_Starter	RJB	564095	StartCtrl	3.2					