

## Wiring diagram pages list

Wiring diagram pages		D		I		S	
Multiplex outputs list	<b>B1</b>	Dash backlighting	19.1	Ignition	3.2	Slide out front left	20.1
Multiplex inputs list	<b>B2</b>	Driver's lights	19.1			Slide out rear left	20.2
Multiplex error messages	<b>B3</b>	Driver window	30.1	<b>K</b>		Slide out	20.3
Layout vehicle - harness	<b>C, C1</b>	Driver seat Electrical Op	30.3	Keyless entry system	29.1	Slide out front right	20.4
Sound system	<b>C2</b>	Docking lights	26.5			Spares wires	8.1
Pins configuration	<b>D</b>					Stop lights	26.2
Circuits list	<b>E</b>	<b>E</b>		<b>L</b>		Steering control ZF	37.2
Circuit breakers list	<b>F</b>	Engine ECU	14.1	Level low	32.1	Steering multifunctions	10.1
Connectors list	<b>G</b>	Engine heater	14.1	Luggage doors lock/unlock	33.1 - 33.2	Step lights	29.1
Diodes list	<b>H</b>	Engine start	3.2	Luggage cmpt. lighting	25.1	Sun visor	41.1
Resistors list	<b>J</b>	Engine & RJB cmpt. Light	25.1				
Relays list	<b>K</b>	Entrance door light	29.1	<b>M</b>			
Fuses list	<b>L</b>	ESP	16.1	Main dist. ignition & batt.	3.1		
Wire identification chart	<b>M</b>	Engine brake	12.1	Markers lights	26.1 - 26.2		
				Mirrors	31.1 - 31.2		
<b>A</b>		<b>F</b>		Multiplex power distribution	7.1	<b>T</b>	
ACB	16.2	Fast idle	14.1	Multiplex network	6.1 - 6.2		
Air dryer	37.1	Fans radiator	13.1			Tail & licence lights	26.2
Alternators	1.1	Fire alarm	9.1 - 38.1			Tire pressure monitor	39.1
		Fire suppression system	38.1	<b>P</b>		Trailer package	26.4
		Flashers	26.1-26.2	Park brake sensor	12.1	Trailer park brake	12.2
<b>B</b>		Fog lights	26.5	Park brake trailer sensor	12.2	Transmission ECU	15.1
Back-up warnings	26.3	Fuel gauge	10.1	Power distribution FJB 12V	4.1		
Batteries & Equalizer	1.1			Power distribution FJB 24V	4.2	<b>U</b>	
Brake pedal sensor	12.1	<b>G</b>		Power distribution RHC 24V	4.3	Urea system	14.2
Back-up camera	28.1	Grounds electronic	2.1	Pwr dist. RJB 12V & 24V	5.1		
		Grounds chassis	2.2	Power outlets 12V	30.2		
<b>C</b>						<b>V</b>	
Clearance lights	26.1-26.2	<b>H</b>		<b>R</b>		Volvo link TGW	37.1
Cluster	10.1	Hazard	26.1	Retarder	12.1 - 15.1		
Cornering lights	26.5	Head lights	26.1	RJB fan	1.1	<b>W</b>	
Converter interface	21.1	Horn	9.1			Windows ajar	27.1
		Hvac defroster	18.1			Wipers & washer	34.1
		Hvac passenger full	18.2			Wheelchair Lift	36.1
		Hvac passenger small	18.3				