



**NOTE:**

CONTROL VALVE OPT. "LOW-BUOY" , "A" OR "B" SETTING:

POSITION "A": VALVE IS OPEN,  
AIR FLOW BETWEEN SUPPLY (S) AND  
DELIVERY (D) , LOW-BUOY IS IN FUNCTION.

POSITION "B": VALVE CLOSED,  
AIR DOES'NT FLOW BETWEEN SUPPLY (S) AND  
DELIVERY (D) , LOW-BUOY IS NOT IN FUNCTION.

TUBE COLOR CODING	
ACTIVE	CIRCUIT
→→ ROUGE	SECONDAIRE
→→ VERDIN	PRIMAIRE & ALIMENTATION
→→ JAUNE	PRENANTER STATIONNEMENT
→→ BLEU	SUSPENSION
→→ NOIR	ACCESSOIRES

BALLOON	PIPE
#1	1/4" O.D. BLACK
#2	3/8" O.D. BLUE
#3	1/4" O.D. BLUE
—	STD PIPING
---	OPTIONAL PIPING

H3-41 & H3-45 COACHES,  
ENGINE 2002 WITH  
FRONT BEAM AXLE

WITH OPTION FRONT KNEELING  
& REAR LOW-BUOY COMBINATION

D140297 P2 REV. E

DATE : 2005/01