



VIDEO DISTRIBUTION

IF Tv Tuner is use without video player, AUX1 must take the place of TRIG5 See P.35.0

TV SAT OR DVD2

OR

FRONT MONITOR